

ROXX NEO fx



USER MANUAL

CONTENT

1. Safety Informations

1.1. General Preventive Measures	4
1.2. Regulations for equipment that connects to power mains	5
1.3. Technical warnsigns and explanation	6

2. Introduction

2.1. About us	7
2.2. NEO fx	7

3. General Product Information

3.1. Scope of delivery	8
3.2. Control Functions	8
3.3. Features	8

4. Installation & Setup

4.1 Physical Installation and Rigging	9
4.2 Connections	10
4.2.1. AC Power	11
4.2.2. DMX Connection	11
4.2.2.1. Cable Connection	11
4.2.2.2. Wireless Connection	11
4.3 NFC (Near Field Communication)	14

5. Operation

5.1 Start up	15
5.2 Control Display	15
5.3 Display Short Cuts	15
5.4 Configuration	17
5.4.1 Set DMX Start Address (Direct Access)	17
5.4.2 Selecting DMX Mode	17
5.4.3 Stand Alone	18
5.4.4 Settings	24
5.4.4.1 Reset functions	28
5.4.6 System Info	29

6. Accessories

6.1 Accessories	30
6.2 Smart-Class Filters	30

7. Technical Data / Diagrams

7.1 Technical drawings and measurements	31
7.2 IP Rating	32
7.3 Technical Data	33
7.4 Section Chart / DMX-Charts / Color Macro Charts / Pixel Charts / CCT Chart	35
7.5 RDM Templates	73

8. Troubleshooting	75
--------------------	----

9. Manufacturer's Declaration	75
-------------------------------	----

1. SAFETY INFORMATION

1.1. General Preventive Measures

- 1.1.1. Please read, understand and follow the instructions.
- 1.1.2. Store the instructions and information in a safe place.
Best solution is the ring binder provided by ROXX.
- 1.1.3. Follow all safety warnings. Under no circumstances remove safety warnings or other information from the equipment.
- 1.1.4. Don't use the equipment for any other intended purpose or manner.
- 1.1.5. Use only stable and compatible stands and/or brackets. Especially when fix installed.
Make sure the wall brackets are properly installed and safe. Make sure the device is securely installed and cannot fall.
- 1.1.6. Check the safety regulations applying for your country before and during installation.
- 1.1.7. Keep the device away from heat! Don't place/install near heaters, ovens or any source of heat.
Make sure that the device always is efficiently cooled and cannot overheat.
- 1.1.8. Always guarantee that ventilation and cooling slots are clean and not blocked.
- 1.1.9. Item must be away minimum 20cm from anything around and above it.
- 1.1.10. Do not use this device close to water.
- 1.1.11. Do not expose this equipment to flammable materials.
- 1.1.12. Make sure that no objects can fall into the device.
- 1.1.13. Only use this device with the accessories recommended by the manufacturer.
- 1.1.14. Always check the equipment for housing damages, so that no water can enter the device.
No containers containing liquids of any kind should be place on top of the unit.
- 1.1.15. Opening or modifying this device is only allowed by authorized and qualified persons.
- 1.1.16. All cables need to be checked after connecting the device in order to prevent damage or accidents.
- 1.1.17. Make sure that the device is transported safe and packed proper in order to prevent damage of any kind.
- 1.1.18. Once you notice improper function of your device due to damage, electric shock or anything similar, immediately unplug the unit from the mains outlet and contact our service department.
- 1.1.19. Clean the device with a dry cloth.

- 1.1.20. Observe all disposal laws applicable in your country. Especially for the packaging.
- 1.1.21. Plastic bags are not a toy! Keep away from children!
- 1.1.22. Please note that changes or modifications which are not approved by the party responsible for compliance will void the user's authority to operate the device.

1.2 Regulations for equipment that connects to power mains

- 1.2.1. If an earthing contact is available in the used power cord, it must be used in combination with a power outlet, providing a protective ground. In no circumstances should the protective ground be deactivated.
- 1.2.2. Do not switch on the device immediately after it has been in strong different temperatures, especially after transport. Let the device acclimatize to the temperature in the room of usage first to prevent moisture and condensation.
- 1.2.3. Verify that the correct voltage and frequency are available in the area of operation, before connecting the unit to the mains outlet.
- 1.2.4. If the plug doesn't fit in your mains outlet, contact your electrician.
- 1.2.5. Make sure your power cord/adaptor/connector does not show signs of kinks/warps or is being stepped on.
- 1.2.6. Always disconnect the unit when not in use or being cleaned. Don't pull on the cord to disconnect. Only touch power connections with dry hands!
- 1.2.7. Don't switch the unit on/off rapidly. This may cause damage.
- 1.2.8. If a fuse needs to be replaced, ALWAYS make sure that exactly the same fuse will be used (type and rating). Repeatedly blown fuses need to be checked by an authorised service technician.
- 1.2.9. In the risk of lightning strike all units need to be unplugged from the mains in order to prevent damage.
- 1.2.10. During installation there must be a voltage free condition.
- 1.2.11. The device needs to be cleaned and serviced regularly and will credit this with a longer life cycle. Dust, dirt, moist, water, smoke, nicotine or anything similar inside the unit will cause damage/malfunction.
- 1.2.12. The unit needs to have at least 0,5m distance to anything flammable.
- 1.2.13. You have to make sure that any electrical installation applies to the laws of your country. Correct power cables and applying standards have to be used.

1.3. Technical warnsigns and explanation



In order to prevent the risk of an electric shock, under no circumstances remove the cover/back or open the unit in any way! No user serviceable parts are inside. Service, maintenance and repairs should only be done by qualified service personnel or the manufacturer.



Dangerous uninsulated voltage inside the device can cause an electrical shock when opened by unqualified personnel.



Important operating and maintenance instructions apply!



Do not operate this device in tropical climates.



CAUTION! Intense LED light source! Risk of eye damage. Do not look into the light source



The housing surface of the spotlight can heat up to temperatures as high as 70 °C in regular use. Ensure that it is not possible to come into contact with the housing unintentionally. Always allow sufficient time for the lamp to cool down before dismantling, carrying out maintenance work or charging etc..



IMPORTANT INFORMATION!

- This is a product which has been developed for professional usage in event technology. It is not suitable as a household lighting.
- NEVER stare, not even temporarily, directly into the light source.
- Don't use magnifiers or any other optical instrument to look at the beam.
- The effects of this device, especially the stroboscope effect, can cause problems for sensitive people or may even cause epileptical seizures.

2. INTRODUCTION

2.1. About us

The name ROXX® came easily.

Combined with the concentrated knowledge and many years of experience, our three founders, who have been leaving their mark in the event and lighting industry for many years already, came together in 2020 to start this outstanding venture.

Product development, sales and marketing as well as the exceptional know-how and the profound rooting in the field of the professional lighting technology belong to our core competences and therefore guarantee extremely innovative and reliable products, excellent support and professional service in every aspect.

Designed & developed in Germany

ROXX® products are developed and designed in Germany. Always in tight consultation with our customers and experts who will eventually be working with these tools. This ensures innovative, easy-to-use and performance-oriented solutions, which provide added value for our customers.

Made to last

Recommended for permanent outdoor use, most ROXX® products feature additional corrosion protection and enhanced IP66 equipment protection, thereby providing that crucial extra for a wider range of applications. In addition to architectural or theme park applications, even fixed installations in coastal or offshore areas with high salt exposure can be reliably implemented over long periods of time.

2.2. NEO fx

The NEO fx is a powerful and versatile LED wash and effect light, designed for the most demanding lighting applications. With its IP65-rated housing, 24x40W RGBL LEDs, and a massive zoom range of 4.5°–70° enabled by two independent zoom levels (patent pending), it sets a new standard for creative lighting versatility. Delivering a luminous flux of 12,000lm (5600K) and an illuminance of 60,000lx (RAW) / 57,000lx (5600K) @ 5m, the NEO fx ensures exceptional brightness and performance in both indoor and outdoor environments.

The fixture stands out with patented features, including a unique zoom effect created when paired with the removable, magnetic Smart Glass Filter. This filter, also patented, adds a dynamic strobe effect and allows seamless transitions between a narrow beam, a wide wash, and stunning graphic effects, opening unparalleled creative possibilities.

Enjoy precise lighting control with single pixel control. The fixture's quiet and fast motorized 188° tilt enhances dynamic lighting design, while numerous built-in effects offer foreground and background color control for easy animation and chase effects.

Its dual-input mode allows control to be split into basic and pixel functions for enhanced flexibility. Advanced wireless capabilities, including an integrated CRMX transceiver, Bluetooth module, and Near Field Communication (NFC), ensure effortless setup and configuration, even without power.

The NEO fx supports DMX, SACN, Art-Net, and RDM, giving you complete control over your lighting setup. Optional accessories include an elliptical holographic filter and touring cases for secure transportation.

With a CRI and TLCI of 85 across the white spectrum, the NEO fx delivers accurate and vibrant color reproduction for professional-grade results.

Whether used as a standalone unit or in combination with multiple fixtures, the NEO fx is the perfect choice for concerts, tours, festivals, live events, and broadcast productions, bringing state-of-the-art lighting effects to every stage.

3. GENERAL PRODUCT INFORMATION


3.1. Scope of delivery

- ⊕ 1x NEO fx
- ⊕ Power cord with plug (EU country specific, if not ordered differently)
- We're offering a wide range of professional accessories (optional).
- Please see under menu 6 or at our website www.roxxlight.com

3.2. Control Functions

- 15CH RGB, 19CH RGB, 26CH RGB, 30CH RGB, 28CH DIRECT, 33CH DIRECT, 81CH PURE, 154CH PURE, 9CH Dual mode, 10CH Dual mode, 95CH FULL ACCESS, 168CH FULL ACCESS
- Stand Alone Functions including cinema effects, various auto programs, customisable scenes, CCT, LEE adjusted color macros and custom color templates
- 6 extra display controls for direct access of wireless settings, dimmer, CCT, color & Gels, Zoom, Tilt and Smart Glass Filter
- Master & Slave (by DMX and Wireless DMX)
- Wireless DMX (Lumenradio CRMX®)
- ROXX App - Bluetooth 5.0
- ROXX NFC App - Near Field Communication


3.3. Features



4. INSTALLATION & SETUP

4.1 Physical Installation and Rigging

ROXX NEO fx may be installed in any orientation. For this purpose the product provides several options:





Standing:

The fixtures is equipped with 4 rubber feet. It allows the luminaire to be used in floor application. With its integrated rubber feet it's designed to ensure a secure stand on every plane surface with 188° tilt movement of the fixtures head.

Hanging:

On the bottom 3x Camlock 1/4 turn connectors are installed. Here it's possible to click in the ROXX Omega Bracket ST (optional accessory) equipped with any suitable clamp.




Insert the two fasteners and turn each 90° clockwise to lock them. Please be sure that the fasteners are turned fully and snapped in.


Use a safety wire matching the local official regulations. We recommend using the safety eye on the bottom of the fixture.



Please note that it's not allowed to use the side camlocks to mount the unit horizontally to a vertical truss or similar.



4.2 Connections*



A: IP65 Power I/O connectors with rubber sealing cap.

Connect using the provided power cable (when not in use, always close with rubber sealing cap)

B: DMX IN

C: DMX OUT

D: Direct Acces to Dimmer, CCT, Gels, Wireless, Connectivity, Tilt/Zoom, Smart Glass

E: Firmware / USB: when not in use, always close with rubber sealing cap

F: Network In

G: Network Out

H: Gore-tex Valve

ⓘ *Note:

In order to provide protection from spraying water, in accordance with protection class IP65, special IP65-rated XLR connectors must be used correctly with the DMX input and output sockets, or they must be closed using the rubber sealing caps. When connected correctly, or when sealed correctly with the rubber sealing caps, the POWER IN and POWER OUT sockets are protected from spraying water, as in accordance with IP65.

4.2.1. AC Power

The NEO fx operates on any 100–260 V, 50/60 Hz AC mains power supply with a maximum power consumption of 1234W at Boost mode and 1000W at Illumination Mode. Connect the fixture to AC power using the supplied cable or a similar one with Neutrik powerCON TRUE1 NAC3FX-W or a compatible type, to ensure the correct ingress protection (IP).

For temporary installations, the mains cable must be fitted with a grounded connector intended for exterior use. The fixture must be grounded/earthed and be able to be isolated from AC power. The AC power supply must incorporate a fuse or circuit breaker for fault protection.

Wire Color (EU models)	Wire Color (US models)	Conductor	Symbol
Brown	Black	Live	L
Blue	White	Neutral	N
Yellow / Green	Green	Ground (earth)	⊕ or ≍



Warning!
Read “Safety Informations” starting on page 3 before connecting the fixtures to AC mains power!
Do not connect the fixture to an electrical dimmer system, as doing so may cause damage that is not covered by the product warranty!

4.2.2 DMX Connection

NEO fx is fully controllable by DMX (USITT DMX512-A standard, based on RS-485) Art-Net, sACN and RDM. It can be connected using either DMX cables or via the built-in LumenRadio CRMX wireless system.

4.2.2.1. Cable Connection

If using a cabled DMX system, connect the DMX IN cable to the input connector (male 5-pin XLR connector) and DMX OUT cable to the output (female 5-pin XLR connectors).

For outdoor installations, use only IP65-rated XLR connectors.
Use shielded twisted pair cable designed for RS-485 devices. The cables are daisy chained between the fixtures, and up to 32 fixtures can be connected to the same DMX link. Up to 300 meters (1000ft.) of cable is achievable with high quality DMX cables. All DMX links must be terminated in the last fixture by connecting a DMX termination plug to the last fixture’s 5 pin DMX out connector.
Standard microphone cable is not suitable for transmitting DMX.

DMX Termination on last fixture DMX out

XLR pin out



4.2.2.2. Wireless Connection*

NEO fx is equipped with a LumenRadio™ Transceiver module. This enables the fixture to work with the following connectivity options:

- ☞ Working in Receiver Mode: receive wireless DMX- and RDM Signals via CRMX
- ☞ Working in Transmitter Mode: transmit DMX (1 universe) to other units via CRMX
- ☞ Full Control via Bluetooth 5.0 and ROXX App

The Fixture is able to send DMX-data received by CRMX or Bluetooth to its physical DMX-Output XLR Connector and hereafter, plugged in by cable, to any DMX-capable unit. For this please enable "Pass to DMX Out" inside Wireless DMX Settings.

NEO fx can act as a fully operative CRMX Receiver and be paired to an active wireless transmitter (CRMX) simultaneously as being connected to a cabled DMX. The device will prioritize cabled DMX input over wireless DMX and over Bluetooth. A small indicator in front of "DMX", "CRMX" or "BLE" gives an easy overview which protocol is currently active. Please see the display graphics below.

If using a wireless DMX system, ensure that the DMX input and the DMX output are properly sealed. Connect both DMX IN and DMX OUT, or seal, in order to maintain the fixture's IP65 rating.

ⓘ ***Note: If you are using XLR for DMX and not Bluetooth we recommend to not connect to Bluetooth unless you need to since it can cause a few dropped DMX packets. BLE and CRMX RX are not available simultaneously.**

- If CRMX RX is enabled and BLE will be enabled after, CRMX automatically changes to TX mode.
- If CRMX TX operating mode is changed to RX, BLE will be disabled automatically.

26 CH
RGB

1
Next
(27)

•DMX

CRMX	Disabled
Operation Mode	n.a.
Linked	No
Receive Reset	No
DMX	Enabled
BLE (Bluetooth)	Disabled

The indicator infront of "DMX" shows that DMX is active.

26 CH
RGB

1
Next
(27)

• CRMX(RX)
DMX

CRMX	Enabled
Operation Mode	RX
Linked	No
Receive Reset	Yes
DMX	Disconnect
BLE (Bluetooth)	Disabled

The indicator infront of "CRMX (RX)" shows that the fixture is now working in wireless DMX receive mode.

"(RX)"= CRMX operating mode is set to receive

26 CH
RGB

1
Next
(27)

• CRMX(TX)
DMX

CRMX	Enabled
Operation Mode	TX
Linked	No
Receive Reset	Yes
DMX	Disconnect
BLE (Bluetooth)	Disabled

The indicator infront of "CRMX (TX)" shows that the fixture is now working in wireless DMX transmit mode.

"(TX)"= CRMX operating mode is set to transmit

26 CH
RGB

1
Next
(27)

• CRMX(RX)
DMX

CRMX	Enabled
Operation Mode	RX
Linked	Yes
Receive Reset	Yes
DMX	Disconnect
BLE (Bluetooth)	Disabled

Once the fixture is linked to an external transmitter, the CRMX signal-symbol appears on upper left side.

1 dash= 1-30% signal strength
2 dashes= 31-70% signal strength
3 dashes= 71-100% signal strength


4.2.3.2. Wireless Connection



26 CH
RGB

1
Next
(27)


• CRMX(TX)
DMX



26 CH
RGB

1
Next
(27)

• CRMX(RX)
DMX



26 CH
RGB


1
Next
(27)

• CRMX(RX)
DMX

26 CH
RGB

1
Next
(27)


• BLE
DMX



26 CH
RGB

1
Next
(27)


CRMX(TX)
• BLE
DMX



26 CH
RGB

1
Next
(27)

CRMX(TX)
BLE
DMX



26 CH
RGB

1
Next
(27)

CRMX(TX)
BLE
• DMX

CRMX	Enabled	Once the fixture is linked to an external transmitter, the CRMX signal-symbol appears on upper left side. 1 dash= 1-30% signal strength 2 dashes= 31-70% signal strength 3 dashes= 71-100% signal strength
Operation Mode	TX	
Linked	Yes	
Receive Reset	Yes	
DMX	Disconnect	
BLE (Bluetooth)	Disabled	

CRMX	Enabled	In case the external transmitter is switched off or out of signal range the signal-symbol starts to blink.
Operation Mode	RX	
Linked	Yes, out of range	
Receive Reset	Yes	
DMX	Disconnect	
BLE (Bluetooth)	Disabled	

CRMX	Enabled	An exclamation appears and blinks although the external transmitter is switched on and is inside the signal range but no DMX is connected to the external transmitter.
Operation Mode	RX	
Linked	Yes, but no DMX	
Receive Reset	Yes	
DMX	Disconnect	
BLE (Bluetooth)	Disabled	

CRMX	Disabled	The indicator in front of "BLE" shows that the fixture is now working in Bluetooth mode and is paired to ROXX App.
Operation Mode	n.a.	
Linked	No	
Receive Reset	No	
DMX	Disconnect	
BLE (Bluetooth)	Enabled + Paired	

CRMX	Enabled	The indicator in front of "BLE" shows that the fixture is now working in Bluetooth mode and is paired to ROXX App. As CRMX TX is enabled and linked a full DMX universe is sent out by CRMX (wireless DMX).
Operation Mode	TX	
Linked	Yes	
Receive Reset	No	
DMX	Disconnect	
BLE (Bluetooth)	Enabled + Paired	


CRMX	Enabled	No indicator in front of "BLE", fixture is not paired to ROXX App.
Operation Mode	TX	
Linked	Yes	
Receive Reset	No	
DMX	Disconnect	
BLE (Bluetooth)	Enabled, not paired	

CRMX	Enabled	DMX is active. As CRMX TX is enabled and linked a full DMX universe is sent out by CRMX (wireless DMX).
Operation Mode	TX	
Linked	Yes	
Receive Reset	No	
DMX	Connect	
BLE (Bluetooth)	Enabled	

4.3. NFC (Near Field Communication)

NEO fx integrates a NFC chip (Near Field Communication) and allows in conjunction with ROXX NFC App to address and configure the fixtures wirelessly even when the fixture power is not prevent. Additionally, the fixtures firmware can be read out and updated to latest version. For this please make sure NEO fx stays AC powered during update process.

The NFC chip is based on it's lower housing part, close to the CRMX antenna. To get a proper connection between your mobile phone and NEO fx, please make sure that your phone is very close to the NFC.




5. OPERATION

5.1 Start up*

Once the fixture is connected to AC power, the boot process starts and the following information will appear on the display:

"Ready to ROXX", the product name and the current software version.



After this process, the fixture is ready for operation, and starts in the previously enabled mode.

***Note:**

During boot process the fan spins up quickly to blow out some possible dust from last use.

5.2 Control Display*

2.0" TFT Display with ten backlit control buttons



Press ENTER to access the selection menu for system settings or confirm changes.



Press ESC to take a step back in the menu.



Press arrows to scroll up and down inside the menu and change values, such as DMX address.

***Note:**

After approximately 1 minute of inactivity inside the menu settings, the display will automatically jump back to home screen.

5.3 Display Short Cuts*

Short Cuts

For some always recurring functions the fixture allows quick and user-friendly access at home screen over some display control short-cuts:

User Reset or Factory Reset*



Pressing ESC+ENTER simultaneously a Factory Reset or User Reset can be started.
By using the up/down arrows the Factory- or User Reset can be selected.
For confirming press ENTER, to jump back please press ESC.

*Note:

For detailed information about the different reset options please refer to chapter "5.4.6.1 Reset functions"

Pressing ESC+ENTER simultaneously a Factory Reset or User Reset can be started.
By using the up/down arrows the Factory- or User Reset can be selected.
For confirming press ENTER, to jump back please press ESC.

*Note:

For detailed information about the different reset options please refer to chapter "5.4.6.1 Reset functions"

Display Off



Pressing ESC + arrow down simultaneously the display backlight function will set to off and the display will turn off immediately. Once a control is pressed the display backlight will turn on.

Manual display flip function*



The fixture includes an auto display flip function by default.
To use the manual display flip function please disable the auto flip function under Settings / Display first. Once the auto display flip function is disabled you can use the manual display flip function by pressing arrow up + arrow down simultaneously. The display will rotate 180. By pressing both arrows simultaneously again the display will flip back.

*Note:

Once the display is flipped both Up / Down controls will work according to the display rotation.

5.4 Configuration

Home Screen

After boot process the fixture is ready for operation and starts in the previously enabled mode. At home screen the following information will appear, depending on the current operating mode:


- A** DMX Address
- B** Operating Mode (DMX Mode, Quick Light or Standalone Mode)
- C** Next available DMX address depending on the fixtures DMX footprint
- D** External Data protocol (CRMX, DMX, BLE).
- E** CRMX status and strength
- F** The dot indicates the active protocol

Note:

CRMX (RX) CRMX Receiving Mode

CRMX (TX) CRMX Transmit Mode

BLE Bluetooth enabled



5.4.1 Set DMX Start Address (Direct Access)

At Home Screen the DMX address can be changed directly by using the up and down arrows. During this process the DMX address starts blinking, once it's confirmed by pressing ENTER it stops blinking.

If the DMX address will not be confirmed by ENTER within 10 seconds, the display will jump back and show the DMX address from before and stops blinking.

5.4.2 Selecting DMX Mode*

At home screen please press ENTER to access to the main menu (level 1).

While using UP / DOWN arrows, please select the menu item "DMX Mode" and confirm by pressing ENTER.

In the following sub-menu (level 2), you can now choose between 16 different DMX operating modes while using the UP/Down arrows and confirm by pressing ENTER or jump back by pressing ESC.

After confirmation the display will jump back to main menu (level 1). Press ESC for homescreen, here the selected DMX mode will be displayed.

***Note:**

For detailed information about the several DMX modes including channel assignment please see our DMX Control chart.

Level 1

Menu
<ul style="list-style-type: none"> ➡ DMX Mode Stand Alone Settings System Info

Level 2

DMX Mode
<ul style="list-style-type: none"> ➡ 15CH RGB mode 19CH RGB mode 26CH RGB mode 30CH RGB mode 28CH DIRECT mode 33CH DIRECT mode 81CH PURE mode (Dual) 154CH PURE mode (Dual) 9CH Dual mode 10CH Dual mode 95CH FULL ACCESS mode (Dual) 168CH FULL ACCESS mode (Dual)

5.4.3 Stand Alone*

Press ENTER to access to main menu (level 1).

While using the UP / DOWN arrows, please select the menu item "Stand Alone" and confirm by pressing ENTER.

In the following sub-menu (level 2), you can now choose between 6 different Stand Alone operating modes (Auto, Editor, Color Macro, Quick Color, Tunable White, User Color) ,Stop Stand Alone, Timer and Color Settings functions while using the UP/Down arrows and confirm by pressing ENTER or jump back by pressing ESC.

To finally use Stand Alone programs please make sure either DMX, CRMX RX or BLE is connected to the fixture, as these protocols have priority.

Stop Stand Alone

To stop a running Stand Alone mode immediately, please select "Stop Stand Alone" and confirm by pressing ENTER. The display will automatically jump back to level 1.

Level 1

Menu
<ul style="list-style-type: none"> DMX Mode ➡ Stand Alone Settings System Info

Level 2

Stand Alone Mode
<ul style="list-style-type: none"> ➡ Stop Stand Alone Auto FX Editor Color Macro Quick Color Tunable White User Color Timer Color Settings

Auto*

Select "Auto" by using the up/down arrows and press ENTER.

Here at sub-menu (level 3), you can choose between Dimmer, Speed, Tilt, Zoom, Smart Glass Filter and Effect. Using the Up/Down arrows at "Effect" (level 4) you can select one of the 30 auto programs and confirm by pressing ENTER or step back by ESC.

For all Pattern effects you can select the Colors for Pattern and Backlight on level 5, Dimmer and Pattern X-fade on level 6

Once it's confirmed or denied the display will automatically jump back to level 3. To stop running a selected auto program please chose "Stop Program" at level 3 or "Stop Stand Alone" at level 2. For returning back to homescreen please press ESC three times. At homescreen the selected Stand Alone mode "Auto" and the selected program will be displayed.

***Note: Using arrows UP /DOWN at homescreen Auto programs can be directly changed according to the list.**

Level 1

Menu
DMX Mode
➡ Stand Alone
Slave
Settings
System Info

Level 2

Stand Alone Mode
Stop Stand Alone
➡ Auto FX
Editor
Color Macro
Quick Color
Tunable White
User Color
Timer
Color Settings

Level 3

Auto
➡ Dimmer <0-100>
Speed <0-100>
(default 85)
Tilt <0-100>
Zoom <0-100>
Smart Filter <0-100>
Effect
Stop Program

Level 4

Effect
➡ 7-Color Fade
7-Color Jump
15-Color Fade
15-Color Jump
Police RB
Police B
Candle Light
Fireworks
Red Carpet
Welding
Pulse A1
Pulse A2
Pulse A3
Bounce A1
Bounce A2
Bounce A3
2 Blocks Chase
Random
Fill In
Fill Out
Rotor A2/2
Rotor B1/2
Snake A2
Snake A4H
Pulse A1V
Circus 03
Chase XDS1
Rotor A1/4 MIR
Bounce A1 / INV
Bounce A1/2

Level 5

Effect Color
➡ Pattern - Color Macro (LED Blue as default)
Backlight - Color Macro (Orange LEE 105 as default)

Level 6

Effect Settings
➡ Dimmer Pattern.
<0-100>
Dimmer Backlight.
<0-100>
Pattern X-Fade
<0-100>

Editor*

At Editor you have up to three customizable programs which can be defined and run from the menus.

Each of the three values contains twenty four user-definable scenes with its own values for RGBL (RAW) or RGB (Calibrated) and shutter, playing continuously in a loop. Each scene has a definable fade-in time for the transition from one color to the other and wait-time. To define a program please press ENTER to access to main menu (level 1).

Level 1

Menu
DMX Mode
➤ Stand Alone
Slave
Settings
System Info

Level 2

Stand Alone Mode
Stop Stand Alone
Auto
➤ Editor
Color Macro
Quick Color
Tunable White
User Color
Timer
Color Settings

While using the UP / DOWN arrows, please select the menu item "Stand Alone" and confirm by pressing ENTER.

Select "Editor" by using the up down arrows and press ENTER.

Here at sub-menu (level 3) you can choose between Program 1-3, Dimmer and Stop Program. Using the Up/Down arrows you can select program 1, 2 or 3 and confirm by pressing ENTER or step back by ESC. After confirming your preferred program, you can now choose between Scene 1-24. Select one of the scenes and press ENTER or step back by ESC. At level

5 you can now set your dimmer, shutter, color, Tilt, Zoom, Smart Filter and fade / wait time in minutes and seconds. For creating a color jump please set value for "Fade Time" to 0, and "Wait Time" to at least 1 second.

Once it's set your first scene is programmed.

You can now jump back to level 3 by using ESC. Here your program will starts automatically. For creating more scenes please use the same procedure. To stop an active program please press ESC and select "Stop Program" at level 3 or "Stop Stand Alone" at level 2. To start again, please re-select your preferred program, it will starts automatically again. To adjust the master brightness for program 1-3, you can use the item "Dimmer" at level 3 and select between 000-100 and confirm by ENTER or jump back by ESC.

***Note:** Once "Factory Calibration" is selected under "Color Settings" inside Stand Alone, only values for RGB are available here. Using UP / DOWN arrows at homescreen Editor program can be directly changed according to the list. For choosing the right strobe effect please follow the Strobe Channel from our DMX chart at the end of this manual.

***Note:** Tilt and Zoom speed will be set according to your selected fade and wait time.

Level 3

Editor
Program 1
➤ Program 2
Program 3
Stop Program

Level 4

Program
➤ Scene 1
Scene 2
Scene 3
...max. 24 Scenes

Level 5

Scene	
Dimmer	<0-100>
Shutter	<0-255>
Red	<0-255>
Green	<0-255>
Blue	<0-255>
Lime	<0-255>
Tilt	<0-100>
Zoom	<0-100>
Smart Filter	<0-100>
Fade Time (min.)	<0-480>
Fade Time (sec.)	<0-59>
Wait Time (min.)	<0-720>
Wait Time (sec.)	<0-59>

Color Macro*

46 different color macros (34x matched LEE color filters, 6 LED colors and 6 different Whites) are available as presets. For each the brightness can be adjusted separately.

Level 1

Menu
DMX Mode
■ Stand Alone
Slave
Settings
System Info

Level 2

Stand Alone Mode
Stop Stand Alone
Auto
Editor
■ Color Macro
Quick Color
Tunable White
User Color
Timer
Color Settings

Level 3

Color Macro
Color Off
■ Dimmer <0-100>
Tilt. <0-100>
Zoom <0-100>
Smart Filter <0-100>
Color macros 1-47
(Reference Gels - Color Macros)

To select a color macro please press ENTER to access to main menu (level 1). While using the UP / DOWN arrows select the menu item "Stand Alone" and confirm by pressing ENTER. After please select the item "Color Macro" by using the up/down arrows and press ENTER again.

Using UP and DOWN controls, select your desired color preset and confirm with ENTER.

At level 3 you can adjust the brightness for the color preset between 000-100. Confirm by ENTER. For color blackout choose the item "Color Off".

Note: Using UP / DOWN arrows at homescreen Color Macros can be changed according to the list.

Level 4

Gels - Color Macros for Standalone Mode			Gels - Color Macros for Standalone Mode			Gels - Color Macros for Standalone Mode		
Pos.	Gel Name	Color Number	Pos.	Gel Name	Color Number	Pos.	Gel Name	Color Number
1	Red	100% Red LED	17	Jade	LEE 323	33	Special Med Lavender	LEE 343
2	Fire	LEE 019	18	Blue	100% Blue LED	34	Ultimate Violet	LEE 707
3	Medium Red	LEE 027	19	Sky Blue	LEE 068	35	Magical Magenta	LEE 795
4	Primary Red	LEE 106	20	Tokyo Blue	LEE 071	36	Chrysalis Pink	LEE 798
5	Med Amber	LEE 020	21	Light Blue	LEE 118	37	Specia KH Lavender	LEE 799
6	Dark Amber	LEE 022	22	Marine Blue	LEE 131	38	Bulb White	2700K / High CRI
7	Deep Amber	LEE 104	23	Med Blue	LEE 132	39	Halogen White	3200K / High CRI
8	Orange	LEE 105	24	Congo Blue	LEE 181	40	Neutral White	4200K / High CRI
9	Deep Golden Amber	LEE 135	25	Mikkel Blue	LEE 716	41	Daylight White	5600K / High CRI
10	Yellow	LEE 101	26	Rose Pink	LEE 002	42	Cold White I	6000K / High CRI
11	Green	100% Green LED	27	Med Pink	LEE 036	43	Cold White II	6300K / High CRI
12	Lime Green	LEE 088	28	Light Lavender	LEE 052	44	Amber (only if available)	100% Amber LED
13	Moss Green	LEE 089	29	Lavender	LEE 058	45	Lime (only if available)	100% Lime LED
14	LEE Green	LEE 121	30	Magenta	LEE 113	46	Cyan (only if available)	100% Cyan LED
15	Primary Green	LEE 139	31	Mauve	LEE 126			
16	Jas Green	LEE 738	32	Smokey Pink	LEE 127			

Quick Color*

The standalone mode “Quick Color” allows a direct adjustment of the single LED colors R, G, B, L, Dimmer and Shutter.

Level 1

Menu
DMX Mode
■ Stand Alone
Slave
Settings
System Info

Level 2

Stand Alone Mode
Stop Stand Alone
Auto
Editor
Color Macro
■ Quick Color
Tunable White
User Color
Timer
Color Settings

Level 3

Quick Color	
Dimmer	<0- 100 >
Shutter	<0- 255 >
Tilt.	< 0 -100>
Zoom	< 0 -100>
Smart Filter	< 0 -100>
Red	< 0 -255>
Green	< 0 -255>
Blue	< 0 -255>
Lime	< 0 -255>

To adjust your Quick Color please press ENTER to access to main menu (level 1).

While using the UP / DOWN arrows select the menu item “Stand Alone” and confirm

by pressing ENTER. After please select the item “Quick Color” by using the up/down arrows and press ENTER again.

Using UP and DOWN controls, select your desired color and confirm with ENTER.

After you can adjust the brightness for the color between 000-255 and confirm by ENTER.

Besides the individual color mix also a master dimmer can be adjusted between 000-100.

For strobe effects please adjust the Shutter value between 000-255.

ⓘ ***Note: Please see detailed explanation for strobe effects inside DMX chart at the end of this manual.**
If “Factory Calibration” is selected in “Color Settings” only R,G,B is available here.

Using UP/DOWN arrows at homescreen you can change Quick Color’s dimmer value.

Tunable White*

The standalone mode “Tuneable White” allows the color temperature (CCT) to be adjusted from 2.000K – 10.000K in 100K steps. Besides brightness and shutter also a +/- green and magenta correction is available.

Level 1

Menu
DMX Mode
■ Stand Alone
Slave
Settings
System Info

Level 2

Stand Alone Mode
Stop Stand Alone
Auto
Editor
Color Macro
Quick Color
■ Tunable White
User Color
Timer
Color Settings

Level 3

Tunable White	
Dimmer	<0- 100 >
Shutter	<0- 255 >
Tilt.	< 0 -100>
Zoom	< 0 -100>
Smart Filter	< 0 -100>
CCT	<2000K-10.000> (default 5600K)
Tint	< 000 > +/-127

Starting from home screen press ENTER to access to main menu (level 1).

While using the UP / DOWN arrows select the menu item “Stand Alone” and confirm by pressing ENTER.

After please select the item “Tunable White” by using the up/down arrows and press ENTER again.

Using UP and DOWN controls to select your desired menu item, confirm by ENTER and adjust the desired value by up and down controls and confirm all entries with ENTER.

***Note:**

Tint values

000 = no function/neutral
001 - 127 = + green
-001 to - 127 = - green

***Note:** Using UP/DOWN arrows at homescreen the selected CCT value can be changed in +/- 100K steps.
Shutter: Please see detailed explanation for strobe effects inside DMX chart at the end of this manual.

User Color*

The standalone mode “User Color” allows to store up to 5 customized color presets out of Red, Green, Blue, Lime, brightness and shutter.

Level 1	Level 2	Level 3	Level 4
Menu	Stand Alone Mode	User Color	User Color
DMX Mode ■ Stand Alone Slave Settings System Info	Stop Stand Alone Auto Editor Color Macro Quick Color Tunable White ■ User Color Timer Color Settings	Color 1 Color 2 Color 3 Color 4 Color 5	Dimmer <0- 100 > Shutter <0- 255 > Tilt. < 0 -100> Zoom < 0 -100> Smart Filter < 0 -100> Red < 0 -255> Green < 0 -255> Blue < 0 -255> Lime < 0 -255>

To define a User Color please press ENTER to access to main menu (level 1).

While using the UP / DOWN arrows, please select the menu item “Stand Alone” and confirm by pressing ENTER.

Select the item menu “User Color” by using the up/down controls and press ENTER.

Using UP and DOWN select your desired preset number (Color 1 -5) and confirm with ENTER.

Use UP and DOWN controls to select your desired color, confirm by ENTER and adjust the value by up and down controls between 000-255 and confirm all entries with ENTER.

With dimmer you can adjust the allover brightness of your User Color. Shutter allows several strobe effects. Once your color mix is ready, jump back by ESC. Your individual color is stored under the selected color preset now.

***Note:** All five User Colors are also available by DMX at Color Macro channel. Using one of the RGB DMX modes, only User Colors mixed out of RGB values are available. For Direct modes, both RGB and RGLB User Colors are available. For detailed information please see Color Macro Chart at the end of this manual. Using UP/DOWN arrows at homescreen the Color Macros can be changed according to the list.

Shutter: Please see detailed explanation for strobe effects inside DMX chart at the end of this manual.

Timer*

Via the internal timer function, all Stand Alone modes except "Auto" and "Editor" can be conveniently faded in and out after the function is enabled in the previously activated standalone mode, without the need for an external controller. Also it remains active even the fixture is switched off and restarted. SimultaNEO fxusly, the timer function is available via cable as well as via wireless DMX for master & slave operation. The fade-in time can be set from 0 to 60 minutes, the dwell time from 1 to 24 hours and the fade-out time from 0 to 60 minutes.

To select "Timer" please press ENTER to access to main menu (level 1). While using the UP / DOWN arrows, please select the menu item "Stand Alone" and confirm by pressing ENTER.

Level 1

Menu
DMX Mode
➤ Stand Alone
Settings
System Info

Level 2

Stand Alone Mode
Stop Stand Alone
Auto
Editor
Color Macro
Quick Color
Tunable White
User Color
➤ Timer
Color Settings

Level 3

Timer
Timer <On / Off >
Fade In < 0 -60 min> 1 minute steps
Dwell Time < 1 -24h> 1 hour steps
Fade Out < 0 -60 min> 1 minute steps

Select the item menu "Timer" by using the up/down controls and press ENTER. Now you can activate / deactivate the Timer function, select "Fade In", "Dwell Time" or "Fade Out" for the individual settings and confirm with ENTER. In each case a three-digit number field will be displayed. Use UP and DOWN to set the value as required from 000 to 060 minutes for "Fade In" and "Fade Out", or 001 to 024 hours for the "Dwell Time". Confirm by pressing ENTER again. After all time settings have been configured, please activate the timer function by selecting the submenu item "Timer On/Off" using UP and DOWN, confirm with ENTER, select "On" and confirm with ENTER again.

To disable the timer function, please select "Off" and confirm by ENTER.

❗ ***Note: Please don't forget to select one of the Stand Alone modes for "Startup Mode" at "Settings".**

Color Settings*

Here at "Color Settings" you can chose your preferred working color mode for all Stand Alone color modes. Either Factory Calibrated or RAW. Factory color calibration of R, G, B, L for a maximum of color consistency from unit to unit. Please note If this function is activated only RGB is available at User Color and Quick Color. For a maximum of saturation please chose RAW mode.

Level 1

Menu
DMX Mode
➤ Stand Alone
Settings
System Info

Level 2

Stand Alone Mode
Stop Stand Alone
Auto
Editor
Color Macro
Quick Color
Tunable White
User Color
Timer
➤ Color Settings

Level 3

Color Settings
➤ Color Calibration
RAW

5.4.4 Settings

Level 1

Menu
DMX Mode
Stand Alone
➤ Settings
System Info

Main Menu	Menu level 2	Menu level 3	Menu level 4	Description
Settings	Wireless DMX	CRMX	<on/off>	On=CRMX enabled / Off= CRMX disabled
		Operating Mode	<receive/transmit>	Receive= CRMX module as Receiver Transmit= CRMX module as Transmitter
		Transmit Link	<no/yes>	Yes= pair with CRMX devices. CRMX must be activated on all devices and the pairing must be picked up by a transmitter (Receive Reset). No= Linking disabled
		Receive Reset	<no/yes>	Yes = retain transmitter pairing No = do not retain transmitter pairing
		Pass to DMX Out	<no/yes>	Yes= incoming wireless DMX and BLE signal will be passed to wired DMX out No= incoming wireless DMX and BLE signal will not be passed to wired DMX out
		Signal Strength	0-100	CRMX signal strength
		BLE	<on/off>	On= BLE enabled / Off= BLE disabled
		BLE Link	<no/yes>	Link = starts bluetooth advertising for at least 1 minute
		BLE Password	<000000>	Set 6-digits user Password for connection to your mobile device (ROXXAPP)
	Protocol	DMX		enables DMX protocol
		Art-Net		
		sACN		
		Dual	DMX (Main) + Artnet (Pixel)	
			DMX (Main) + sACN (Pixel)	
			Artnet only (Main + Pixel)	
			sACN only (Main + Pixel)	
		Slave		
	Ethernet	IP Address	xxx.xxx.xxx.xxx	
		Subnet Mask	xxx.xxx.xxx.xxx	
		Art-Net	Main Universe	000-254
		sACN	Main Universe Group	000-127
			Pixel Universe	000-254
			Pixel Universe Group	000-127
			Pixel Address	001-xxx
			Send Main Universe to DMX	On / Off


Main Menu	Menu level 2	Menu level 3	Menu level 4	Description
Settings	Display	Auto Flip	<on/off>	On= Auto-Display-Flip-Function enabled Off= Auto-Display-Flip-Function disbaled
		Backlight	<on/off>	On= controls permanent on, display itself will deactivate after 60 minues of incativity Off= controls and display deactivation after approximately 1 minute of inactivity
		Auto Lock	<on/off>	On= Automatically locks the controls after approximately 1 minute of inactivity. After attempted input the display shows: „Locked!“ Unlock process: press arrows up, down, up, down consecutively
	Startup Mode (using last adjust-ments of specific Standalone Modes)	DMX		Select your default operating mode when fixture is powered on
		Art-Net		
		sACN		
		Dual		
		Auto		
		Editor (Program 1-3)		
		Color Macro		
		Quick Color		
		Tunable White		
		User Color (User Color 1-5)		
	DMX Fail	Hold (factory default)		Hold= last command retains
		Blackout		Blackout= Activates Blackout
		Emergency Light		Emergency Light= Fixtures changes according to Tunable White" settings at Stand Alone mode, by default to 5600K.
	Dimmer Curve	Linear		Linear= Light intensity increases linear with DMX value
		Exponential		Exponential= Light intensity can be set more smooth at lower DMX values and broadly at higher DMX values.
		Logarithmic		Light intensity can be broadly adjusted at lower DMX values and more smooth at higher DMX values
		S-Curve		Light intensity can be adjusted smoothly at lower and higher DMX values and broadly at medium DMX values
	Dimmer Response	LED		The LED responds abruptly to it's DMX values
		Halogen		The LED responds similar to a halogen fixture with soft changes at brightness.
	Color Calibration	Normal CRI		Colors & CCT calibrated, normal CRI mode
		High CRI		Colors & CCT calibrated, high CRI mode
	RAW Balance (affects RAW Mode in DMX and Stand-alone control)	User Calibration	Red <0-255>	Individual color calibration for R,G,B,L
			Green <0-255>	
			Blue <0-255>	
			Lime <0-255>	

Main Menu	Menu level 2	Menu level 3	Menu level 4	Description
Settings	LED Frequency	800 Hz	Select preferred LED PWM frequency	
		1300 Hz		
		2000 Hz		
		3600 Hz		
		12000 Hz		
		25000 Hz		
	Fan	Auto 1		Adjust fan speed relative to internal fixture temperature, maximum 2500rpm
		Auto 2		Adjust fan speed relative to internal fixture temperature, maximum 3000rpm
		Silent		Low fan speed for silent operation, maximum 1800rpm
		Studio		Low fan speed for silent operation, maximum 1500rpm
		Fan Off		Fan Off
		Max Power		High fan speed for maximum cooling effect, maximum 3000rpm
	Redshift	On / Off	On= Activates Redshift, Off= Deactivates Redshift	Redshift function simulate traditional halogen fixtures while dimming down. Redshift affects only between 2700-3500K.
	Pixel Invert / Swap	Invert	On / Off	Inverts the pixel layout of the fixture
		Swap	On / Off	Swaps the pixel layout of the fixture
	Tilt	Tilt Invert	On / Off	On: Enables Tilt Invert (Frontside to Backside Rotation / Off: Disables Tilt Invert (Backside to Frontside Rotation)
		Tilt Position Auto Correction	On / Off	On: Enables Tilt-Position Auto Correction / Off: Disables Tilt-Position Auto Correction. If you need to return tilt to its correct position, you must perform a reset.
		Tilt Motor Disable	On / Off	On: Disables Tilt Motor current / Off: Enables Tilt Motor Current. Note: When changing from enabled (On) back to disabled (Off) to re-enable tilt movement, you must activate a tilt-reset before you can operate tilt normally.
		Tilt Motor Calibration	127+ to 127-	On: Disables Tilt Motor current / Off: Enables Tilt Motor Current. Note: When changing from enabled (On) back to disabled (Off) to re-enable tilt movement, you must activate a tilt-reset before you can operate tilt normally.
	Zoom	Invert	On / Off	
		Zoom Calibration	127+ to 127-	
	LED Mode	Illumination		Normal output for constant illumination
		Boost		Boost for temporarily highest output for blinder and strobe effects
	USB Update	Auto		Runs firmware update automatically, once USB stick gets plugged in
		Manual		Runs firmware update manually after USB stick gets plugged in
		No		Do not run firmware update via USB port


Main Menu	Menu level 2	Menu level 3	Menu level 4	Menu Level 5
Settings	Factory / User Reset For more and detailed information about the different reset options please refer to chapter "5.4.6.1 Reset functions"	Factory Reset	Are you sure to reset? / Confirm by pressing ENTER, cancel with ESC	Restores all factory defaults , but not User defaults and no User Colors
		User Reset	Are you sure to reset? / Confirm by pressing ENTER, cancel with ESC	Restores all User Reset according to the User Preset List. User Colors will not set back. Timer Function and DMX adress restore to Factory default. Once User Reset is activated a fixture self test will start. Self Test is not available while activating User Rest by DMX Settings.
		User Reset List	DMX Mode <15CH RGB mode, 19CH RGB mode, 26CH RGB mode , 30CH RGB mode, 28CH DIRECT mode, 33CH DIRECT mode, 81CH Pure mode, 154CH Pure mode, 9CH Dual mode, 10CH Dual mode, 95CH FULL ACCESS mode, 168CH FULL ACCESS mode>	
			CRMX <on/off>	
			CRMX Operating Mode <receive/transmit>	
			CRMX Receive Reset <no/yes>	
			BLE <on/off>	
			BLE Link <no/yes>	
			BLE Password <000000>	
			CRMX Pass to DMX Out <no/yes>	
			Display Flip <on/off>	
			Backlight <on/off>	
			Auto Lock <on/off>	
			Startup Mode <DMX/ Art-Net/ sACN/ Dual /Slave/ Auto/Editor/ Color Macro, Quick Color, Tunable White/ User Color>	
			DMX Fail <Hold/Blackout/Emergency (5600K)>	
			Dimmer Curve <Linear, Exponential, Logarithmic, S-Curve>	
			Dimmer Response <LED, Halogen>	
			Color Calibration <Normal CRI / High CRI>	
			RAW Balance <RAW / User Calibration>	
			LED Frequency <800Hz, 1300Hz , 2000Hz, 3600Hz, 12000Hz, 25000Hz>	
			Fan <Auto 1 , Auto 2, Silent, Studio, Fan Off, Max. Power>	
			Redshift <on/off>	
			Pixel Invert Mapping <on/off>	
			Pixel Swap Mapping <on/off>	
			Tilt Invert <on/off>	
			Tilt-Position Auto Correction <on/off>	
			Tilt Motor Disable <on/off>	
			Zoom Invert <on/off>	
			LED mode <Illumination, Boost>	
			USB Update <Auto, Manual , No>	

Dimmer Curves


Linear




Exponential



Logarithmic



S-Curve



5.4.4.1 Reset Functions

	DMX Address and Mode	Ethernet settings (if available)	Stand Alone User Colors	User Reset List	Other Settings	LED + Fan Test	Note
DMX: Factory Reset	keep	keep	reset to default	keep	reset to default	no	starts only if shutter channel has DMX value "250"
DMX: User Reset	keep	keep	keep	keep	set corresponding to user reset list settings	no	starts only if shutter channel has DMX value "250"
RDM: Factory Reset	keep	keep	reset to default	keep	reset to default	no	
RDM: User Reset	keep	keep	keep	keep	set corresponding to user reset list settings	no	
RDM: Factory Defaults	reset to default	reset to default	reset to default	keep	reset to default	no	
Menu: Factory Reset (change DMX Address/ Mode)	reset to default	reset to default	reset to default	keep	reset to default	yes	
Menu: Factory Reset (keep DMX Address/ Mode)	keep	keep	reset to default	keep	reset to default	yes	
Menu: User Reset (change DMX Address/ Mode)	reset Address to default, DMX Mode corresponding to user reset list settings	reset to default	keep	keep	set corresponding to user reset list settings	yes	
Menu: User Reset (keep DMX Address/Mode)	keep	keep	keep	keep	set corresponding to user reset list settings	yes	
After USB Firmware Update: Reset (change DMX Address/Mode)	reset to default	reset to default	reset to default	keep	reset to default	no	
After USB Firmware Update: Reset (keep DMX Address/Mode)	keep	keep	keep	keep	keep	no	

5.4.5 System Info

Level 1

Menu
DMX Mode
Stand Alone
Slave
Settings
■ System Info

Main Menu	Menu level 2	Menu level 3	Menu level 4
System Info	Firmware Version	Main CPU	Display installed firmware version
		LED Baord	
	Serial Number	136xxxxxxxx	
	RDM UID	0X6a6axxxxxxxx	Display unique RDM ID for identification
	Temperatures	Celsius LED : XXX°C or Fahrenheit LED : XXX °F	Display fixture temperature by celsius and fahrenheit
	Power on Time	Total: xxxxxhours	Display fixture total power on time
	LED on Time	Total: xxxxxhours	Display LED total power on time
	Fan Speed	Head	Display the current fan speed from head
		PSU	Display the current fan speed from Base / PSU
	Errors	Errors information	Display error codes

6. ACCESSORIES

6.1 Accessories



Smart Glass Filter
Art.: 14906201



Elliptical Horizontal Filter
Art.: 14906301




Omega Bracket ST
Art.: 90900002



Cases
TBA

6.2 Smart-Glass Filter




***Note:**

Depending on the used filter respectively on the frost intensity of the Smart Glass Filter there will be a slight shift of the adjusted color temperature.

The filter contacts and front headlight contacts should be dry before installation.








Lift handle to insert an release safety cable.



When connecting the safety cable, make sure the handle returns to the flat position.


7. TECHNICAL DATA / DIAGRAMS

7.1 Technical drawings and measurements



7.2 IP Rating

ROXX products conform to officially classified IP standard levels. NEO fx is rated to IP65 when using the covers for the housing parts. IP stands for Ingress Protection and IP65, according to classified standard, means shielded against dust and high-pressure jets of water from any side.



7.3 Technical Data

Photometrics	
LED expected lifetime	50.000 hours
Lightsource	24x 40W RGBL
Type of optical system	Lightrond & PC Zoom lens
LED PWM Frequency	selectable 800Hz, 1.300Hz, 2.000Hz, 3.600Hz, 12kHz, 25kHz
Total Zoom Beam / Field angle	4,5° - 70° (50% beam) / 6,9° - 142° (10% field)
Optical (Motor) Zoom Beam / Field angle	4,5° - 30° (50%) / 6,9° - 40° (10% field)
Color temperature range	2000-10.000K
CRI/Ra @ 5600K	76 @ Normal CRI / 85 @ High CRI
TLCI @ 5600K	63 @ Normal CRI / 75 @ High CRI
TLCI mixed @ 11.000K	85
Luminous flux @ 5600K (wide zoom / normal CRI)	12.300lm
illuminance Lux @ 5m / 16,4ft (@ Full / RAW) @ narrow zoom	59.820lx
illuminance Lux @ 5m / 16,4ft (@ 5600K Normal CRI) @ narrow zoom	56.790lx
illuminance Lux @ 5m / 16,4ft (@ 5600K High CRI) @ narrow zoom	34.780lx
Efficacy @ Full 230V (max)	12.30 lm/W
Dimensions & Weight	
IP class	IP65
IK class	IK08
Body material	Magnesium, Aluminum, Nylon
Lens material	Tempered glass front
Net dimensions (w x h x d) - head straight up	521 x 347 x 245
Net dimensions inches - head straight up	20,52 x 13,66 x 9,65
Net weight	24.15 kg / + Filter 24.8 kg
Tilt	188°
Tilt Locking System	Mechanical locking system
Thermal Characteristics	
Cooling	Active, Forced Air, Temperature-regulated
Humidity (max.)	95%
Temperature range, Operating	-40°C to 45°C
Temperature range, Start-Up	-20° to 45°C
Temperature range, Storage	-40°C to 80°C
Thermal Protection	Automatic overtemperature protection
Electrical Data	
AC Power, max	90 – 285V 50/60Hz
AC Power, nominal	100 – 240V 50/60Hz
Electrical protection	Overload protection with automatic recover
Max. power consumption (Boost Mode)	1234W @ 230V / 1310W @ 100V
Constant power consumption (Illumination Mode)	1000W @ 230V / 1055W @ 100V
Power Max. Out @ Max. Power Consumption (Boost Mode)	5,55A @ 230V (1234W) / 13,44A @ 100V (1310W)

7.3 Technical Data

Electrical Data	
Power Max. Out @ Constant Power Consumption (Illumination Mode)	4,44A @ 230V (1000W) / 10,6A @ 100V (1055W)
Power Linking @ Max. Power Consumption (Boost Mode)	2 units @ 230V / 1 units @ 100V
Power Linking @ Constant Power Consumption (Illumination Mode)	2 units @ 230V / 1 units @ 100V
Power Factor @ Max. Power Consumption (Boost Mode)	0.993PF @ 100V / 0.976PF @ 230V
Power Factor @ Constant Power Consumption (Illumination Mode)	0.994PF @ 100V / 0.976PF @ 230V
Standby Power	40W
Power Supply Unit	Inbuilt auto-ranging electronic switch-mode
Operator & Controller	
DMX channels	15CH RGB, 19CH RGB, 26CH RGB, 30CH RGB, 28CH DIRECT, 33CH DIRECT, 81CH PURE, 154CH PURE, 9CH Dual mode, 10CH Dual mode, 95CH FULL ACCESS, 168CH FULL ACCESS
DMX modes	12
Protocol	USITT DMX512A
	RDM ANSI E1.20
	Art-Net
	sACN
	CRMX, W-DMX™ G2, W-DMX™ G3, W-DMX™ G4, W-DMX™ G4S
	Bluetooth (Low Energy)
Setting and addressing	2.0" TFTdisplay / 10 controls
	RDM ANSI E1.20
	Near Field Control (NFC)
Standalone mode	Auto Program, Color Macro, Quick Color, Tunable White, User Color
Wireless DMX	Lumen Radio transmitt & receive function (CRMX)
indicator	2.0" TFT display
controls	10 backlighted controls
Strobe LED	0-30Hz
Strobe Smart-Glass	0-5Hz
DMX I/O	IP65 XLR 5-pin male/female
Ethernet I/O	IP65 RJ45 Ethernet male/female
Power In	TRUE1 compatible input & link-thru sockets
USB Firmware Update	IP65 USB socket
Installation	
Mounting point on fixture bottom side	3x 1/4 turn Omega Bracket
Mounting point on fixture Yoke side	1x 1/4 turn Omega Bracket
Orientation	Any
Rigging possibilities	hanging direct
Safety features	1x bottom mount for fixtures safety wire / 2x head-mount (handle) for accessory safety wires
Minimum distance from flammable materials	0,3 meters (11,8 inch)

7.4 DMX-Charts / Color Macro Charts / CCT Chart / Pixel Chart

15CH RGB	28CH DIRECT	9CH Dual Mode
19CH RGB	33CH DIRECT	10CH Dual Mode
26CH RGB / Default Mode	81CH Pure Mode	95CH Full Access Mode
30CH RGB	154CH Pure Mode	168CH Full Access Mode

Channel	15CH RGB	19CH RGB	26CH RGB (default)	30CH RGB	28CH DIRECT	33CH DIRECT
1	Master Dimmer	Master Dimmer	Master Dimmer	Master Dimmer	Master Dimmer	Master Dimmer
2	Shutter	Master Dimmer fine	Shutter	Master Dimmer fine	Shutter	Master Dimmer fine
3	Tilt	Shutter	Duration	Shutter	Duration	Shutter
4	Tilt fine	Tilt	Tilt	Duration	Tilt	Duration
5	Zoom	Tilt fine	Tilt fine	Tilt	Tilt fine	Tilt
6	Smart Filter	Zoom	Zoom	Tilt fine	Zoom	Tilt fine
7	Total Zoom	SmartFilter	Smart Filter	Zoom	Smart Filter	Zoom
8	Red	Total Zoom	Smart Filter Shutter	Smart Filter	Smart Filter Shutter	SmartFilter
9	Green	Red	Total Zoom	Smart Filter Shutter	Total Zoom	Smart Filter Shutter
10	Blue	Red fine	Red	Total Zoom	Red	Total Zoom
11	CTC	Green	Green	Red	Green	Red
12	Tint	Green fine	Blue	Red fine	Blue	Red fine
13	Color Macro	Blue	CTC	Green	Lime	Green
14	Color Macro Crossfade	Blue fine	Tint	Green fine	CTC	Green fine
15	Device Settings	CTC	Color Macro	Blue	Tint	Blue
16		Tint	Color Macro Crossfade	Blue fine	Color Macro	Blue fine
17		Color Macro	Pattern Dimmer	CTC	Color Macro Crossfade	Lime
18		Color Macro Crossfade	Pattern Shutter	Tint	Pattern Dimmer	Lime fine
19		Device Settings	Pattern selection	Color Macro	Pattern Shutter	CTC
20			Pattern selection X-fade	Color Macro Crossfade	Pattern selection	Tint
21			Pattern speed	Pattern Dimmer	Pattern selection X-fade	Color Macro
22			Pattern X-fade	Pattern Shutter	Pattern speed	Color Macro Cross-fade
23			Pattern Red	Pattern selection	Pattern X-fade	Pattern Dimmer
24			Pattern Green	Pattern selection X-fade	Pattern Red	Pattern Shutter
25			Pattern Blue	Pattern speed	Pattern Green	Pattern selection
26			Device Settings	Pattern X-fade	Pattern Blue	Pattern selection X-fade

Channel	15CH RGB	19CH RGB	26CH RGB (default)	30CH RGB	28CH DIRECT	33CH DIRECT
27				Pattern Red	Pattern Lime	Pattern speed
28				Pattern Green	Device Settings	Pattern X-fade
29				Pattern Blue		Pattern Red
30				Device Settings		Pattern Green
31						Pattern Blue
32						Pattern Lime
33						Device Settings

Ch.	9CH DUAL MODE	10CH DUAL MODE	Ch.	81CH PURE MODE	Ch.	154CH PURE MODE	Ch.	95CH FULL ACCESS	Ch.	168CH FULL ACCESS
1	Master Dimmer	Master Dimmer	1	Master Dimmer	1	Master Dimmer	1	Master Dimmer	1	Master Dimmer
2	Shutter	Master Dimmer fine	2	Shutter	2	Master Dimmer fine	2	Shutter	2	Master Dimmer fine
3	Duration	Shutter	3	Duration	3	Shutter	3	Duration	3	Shutter
4	Tilt	Duration	4	Tilt	4	Duration	4	Tilt	4	Duration
5	Tilt fine	Tilt	5	Tilt fine	5	Tilt	5	Tilt fine	5	Tilt
6	Zoom	Tilt fine	6	Zoom	6	Tilt fine	6	Zoom	6	Tilt fine
7	SmartFilter	Zoom	7	Smart Filter	7	Zoom	7	Smart Filter	7	Zoom
8	Smart Filter Shutter	SmartFilter	8	Smart Filter Shutter	8	SmartFilter	8	Smart Filter Shutter	8	Smart Filter
9	Device Settings	Smart Filter Shutter	9	Red 1	9	Smart Filter Shutter	9	Total Zoom	9	Smart Filter Shutter
10		Device Settings	10	Green 1	10	Red 1	10	CTC	10	Total Zoom
			11	Blue 1	11	Red 1 fine	11	Tint	11	CTC
			12	Red 2	12	Green 1	12	Color Macro	12	Tint
			13	Green 2	13	Green 1 fine	13	Color Macro Crossfade	13	Color Macro
			14	Blue 2	14	Blue 1	14	Pattern Dimmer	14	Color Macro Crossfade
			15	Red 3	15	Blue 1 fine	15	Pattern Shut- ter	15	Pattern Dimmer
			16	Green 3	16	Red 2	16	Pattern selec- tion	16	Pattern Shutter
			17	Blue 3	17	Red 2 fine	17	Pattern selec- tion X-fade	17	Pattern selec- tion
			18	Red 4	18	Green 2	18	Pattern speed	18	Pattern selec- tion X-fade
			19	Green 4	19	Green 2 fine	19	Pattern X-fade	19	Pattern speed
			20	Blue 4	20	Blue 2	20	Pattern Red	20	Pattern X-fade
			21	Red 5	21	Blue 2 fine	21	Pattern Green	21	Pattern Red
			22	Green 5	22	Red 3	22	Pattern Blue	22	Pattern Green

			23	Blue 5	23	Red 3 fine	23	Red 1	23	Pattern Blue
			24	Red 6	24	Green 3	24	Green 1	24	Red 1
			25	Green 6	25	Green 3 fine	25	Blue 1	25	Red 1 fine
			26	Blue 6	26	Blue 3	26	Red 2	26	Green 1
			27	Red 7	27	Blue 3 fine	27	Green 2	27	Green 1 fine
			28	Green 7	28	Red 4	28	Blue 2	28	Blue 1
			29	Blue 7	29	Red 4 fine	29	Red 3	29	Blue 1 fine
			30	Red 8	30	Green 4	30	Green 3	30	Red 2
			31	Green 8	31	Green 4 fine	31	Blue 3	31	Red 2 fine
			32	Blue 8	32	Blue 4	32	Red 4	32	Green 2
			...80	...Blue 24	33	Blue 4 fine	33	Green 4	33	Green 2 fine
			81	Device Settings	...153	...Blue 24 fine	34	Blue 4	34	Blue 2
					154	Device Settings	35	Red 5	35	Blue 2 fine
							36	Green 5	36	Red 3
							37	Blue 5	37	Red 3 fine
							38	Red 6	38	Green 3
							39	Green 6	39	Green 3 fine
							40	Blue 6	40	Blue 3
							41	Red 7	41	Blue 3 fine
							42	Green 7	42	Red 4
							43	Blue 7	43	Red 4 fine
							44	Red 8	44	Green 4
							45	Green 8	45	Green 4 fine
							46	Blue 8	46	Blue 4
							...94	...Blue 24	46	Blue 4 fine
							95	Device Settings	...168	...Blue 24 fine
									169	Device Settings

7.4 DMX-Charts / Color Macro Charts / CCT Chart / Pixel Chart

15CH RGB	28CH DIRECT	9CH Dual Mode
19CH RGB	33CH DIRECT	10CH Dual Mode
26CH RGB / Default Mode	81CH Pure Mode	95CH Full Access Mode
30CH RGB	154CH Pure Mode	168CH Full Access Mode

15 CH RGB Mode - 8bit					
Ch.	Function	Value	Setting	Default	
1	Master Dimmer	000-255	0 - 100%	20	
2	Shutter	000 - 019	Shutter close		
		020 - 024	Shutter open		
		025 - 064	Strobe 1 (fast ⊕ slow)		
		065 - 069	Shutter open		
		070 - 084	Strobe 2: opening pulse (fast ⊕ slow)		
		085 - 089	Shutter open		
		090 - 104	Strobe 3: closing pulse (fast ⊕ slow)		
		105 - 109	Shutter open		
		110 - 124	Strobe 4: random strobe (fast ⊕ slow)		
		125 - 129	Shutter open		
		130 - 144	Strobe 5: random opening pulse (fast ⊕ slow)		
		145 - 149	Shutter open		
		150 - 164	Strobe 6:random closing pulse (fast ⊕ slow)		
		165 - 169	Shutter open		
		170 - 184	Strobe 7: burst pulse (fast ⊕ slow)		
		185 - 189	Shutter open		
		190 - 204	Strobe 8: random burst pulse (fast ⊕ slow)		
		205 - 209	Shutter open		
		210 - 224	Strobe 9:sine wave (fast ⊕ slow)		
225 - 229	Shutter open				
230 - 244	Strobe 10: burst (fast ⊕ slow)				
245 - 255	Shutter open				
3	Tilt	000-255	0 - 100% Back - Front	128	
4	Tilt fine	000-255	0 - 100% Back - Front	255	
5	Zoom	000-255	0 - 100% Narrow - Wide	0	
6	Smart Filter	000-255	0 - 100% Clear - Frosted	0	
7	Total Zoom (override Zoom + SG Filter)	000-005	no function	0	
		006 - 255	0 - 100% Narrow - Wide (Zoom + Frost)		
8	Red	000-255	0 - 100%	affects main & pattern background color	255
9	Green	000-255	0 - 100%		255
10	Blue	000-255	0 - 100%		255

11	CTC (affects RGB)	000 - 004	5600K	according to CTC chart	0
		005-226	2000K-6500K linear in 20-21K steps (please see detailed CTC chart)		
		182-182	5600K		
		226-226	6500K		
		227-255	6621K-10.000K linear in 120-121K steps (please see detailed CTC chart)		
12	Tint (affects CTC and RGB)	0	no function	0	0
		001-127	Magenta -> Neutral		
		128-128	Neutral		
		129-255	Neutral -> Green		
13	Color Macro (override RGB/CTC)		please use color macros from ROXX color macro chart		0
14	Color Macro Crossfade (Transition Time between Color Macros)	000 - 005	no function	0	0
		006-105	0,1s - 10s (0,1s steps)		
		106-214	11s - 119s (1s steps)		
		215-244	2m - 6m50s (10s steps)		
		245-255	7m - 17m (1m steps)		
15	Device Settings (please see remark *1)		According to our Device Settings chart RGB mode		0

19CH RGB Mode - 16bit

Ch.	Function	Value	Setting	Default
1	Master Dimmer	000-255	0 - 100%	0
2	Master Dimmer fine	000-255	0 - 100%	0
3	Shutter	000 - 019	Shutter close	20
		020 - 024	Shutter open	
		025 - 064	Strobe 1 (fast ⊕ slow)	
		065 - 069	Shutter open	
		070 - 084	Strobe 2: opening pulse (fast ⊕ slow)	
		085 - 089	Shutter open	
		090 - 104	Strobe 3: closing pulse (fast ⊕ slow)	
		105 - 109	Shutter open	
		110 - 124	Strobe 4: random strobe (fast ⊕ slow)	
		125 - 129	Shutter open	
		130 - 144	Strobe 5: random opening pulse (fast ⊕ slow)	
		145 - 149	Shutter open	
		150 - 164	Strobe 6: random closing pulse (fast ⊕ slow)	
		165 - 169	Shutter open	
		170 - 184	Strobe 7: burst pulse (fast ⊕ slow)	
		185 - 189	Shutter open	
		190 - 204	Strobe 8: random burst pulse (fast ⊕ slow)	

19CH RGB Mode - 16bit

3	Shutter	205 - 209	Shutter open		20
		210 - 224	Strobe 9:sine wave (fast ☉ slow)		
		225 - 229	Shutter open		
		230 - 244	Strobe 10: burst (fast ☉ slow)		
		245 - 255	Shutter open		
4	Tilt	000-255	0 - 100% Back - Front		127
5	Tilt fine	000-255	0 - 100% Back - Front		255
6	Zoom	000-255	0 - 100% Narrow - Wide		0
7	SmartFilter	000-255	0 - 100% Clear - Frosted		0
8	Total Zoom (override Zoom + SG Filter)	000-005	no function		0
		006 - 255	0 - 100% Narrow - Wide (Zoom + Frost)		
9	Red	000-255	0 - 100%	affects main & pattern background color	255
10	Red fine	000-255	0 - 100%		255
11	Green	000-255	0 - 100%		255
12	Green fine	000-255	0 - 100%		255
13	Blue	000-255	0 - 100%		255
14	Blue fine	000-255	0 - 100%		255
15	CTC (affects RGB)	000 - 004	5600K	according to CTC chart	0
		005-226	2000K-6500K linear in 20-21K steps (please see detailed CTC chart)		
		182-182	5600K		
		226-226	6500K		
		227-255	6621K-10.000K linear in 120-121K steps (please see detailed CTC chart)		
16	Tint (affects CTC and RGB)	0	no function		0
		001-127	Magenta -> Neutral		
		128-128	Neutral		
		129-255	Neutral -> Green		
17	Color Macro (override RGB/CTC)		please use color macros from ROXX color macro chart		0
18	Color Macro Crossfade (Transition Time between Color Macros)	000 - 005	no function		0
		006-105	0,1s - 10s (0,1s steps)		
		106-214	11s - 119s (1s steps)		
		215-244	2m - 6m50s (10s steps)		
		245-255	7m - 17m (1m steps)		
19	Device Settings (please see remark *1)		According to our Device Settings chart RGB mode		0

26CH RGB Mode -8bit (Default Mode)

Ch.	Function	Value	Setting	Default
1	Master Dimmer	000-255	0 - 100%	0
2	Shutter	000 - 019	Shutter close	20
		020 - 024	Shutter open	
		025 - 064	Strobe 1 (fast ⊕ slow)	
		065 - 069	Shutter open	
		070 - 084	Strobe 2: opening pulse (fast ⊕ slow)	
		085 - 089	Shutter open	
		090 - 104	Strobe 3: closing pulse (fast ⊕ slow)	
		105 - 109	Shutter open	
		110 - 124	Strobe 4: random strobe (fast ⊕ slow)	
		125 - 129	Shutter open	
		130 - 144	Strobe 5: random opening pulse (fast ⊕ slow)	
		145 - 149	Shutter open	
		150 - 164	Strobe 6: random closing pulse (fast ⊕ slow)	
		165 - 169	Shutter open	
		170 - 184	Strobe 7: burst pulse (fast ⊕ slow)	
		185 - 189	Shutter open	
		190 - 204	Strobe 8: random burst pulse (fast ⊕ slow)	
		205 - 209	Shutter open	
		210 - 224	Strobe 9: sine wave (fast ⊕ slow)	
		225 - 229	Shutter open	
		230 - 244	Strobe 10: burst (fast ⊕ slow)	
		245 - 255	Shutter open	
3	Duration	000-255	0 - 100% (only affects to channel 2 - Strobe 1 - 025-064)	0
4	Tilt	000-255	0 - 100% Back - Front	127
5	Tilt fine	000-255	0 - 100% Back - Front	255
6	Zoom	000-255	0 - 100% Narrow - Wide	0
7	Smart Filter	000-255	0 - 100% Clear - Frosted	0
8	Smart Filter Shutter	000 - 019	Shutter close	20
		020 - 024	Shutter open	
		025 - 064	Strobe 1 (fast ⊕ slow)	
		065 - 069	Shutter open	
		070 - 084	Strobe 2: opening pulse (fast ⊕ slow)	
		085 - 089	Shutter open	
		090 - 104	Strobe 3: closing pulse (fast ⊕ slow)	
		105 - 109	Shutter open	
		110 - 124	Strobe 4: random strobe (fast ⊕ slow)	
		125 - 129	Shutter open	
		130 - 144	Strobe 5: random opening pulse (fast ⊕ slow)	
		145 - 149	Shutter open	
		150 - 164	Strobe 6: random closing pulse (fast ⊕ slow)	
		165 - 169	Shutter open	

26CH RGB Mode -8bit (Default Mode)

8	Smart Filter Shutter	165 - 169	Shutter open		20
		170 - 184	Strobe 7: burst pulse (fast ⊕ slow)		
		185 - 189	Shutter open		
		190 - 204	Strobe 8: random burst pulse (fast ⊕ slow)		
		205 - 209	Shutter open		
		210 - 224	Strobe 9:sine wave (fast ⊕ slow)		
		225 - 229	Shutter open		
		230 - 244	Strobe 10: burst (fast ⊕ slow)		
		245 - 255	Shutter open		
9	Total Zoom (override Zoom + SG Filter)	000-005	no function		0
		006 - 255	0 - 100% Narrow - Wide (Zoom + Frost)		
10	Red	000-255	0 - 100%		255
11	Green	000-255	0 - 100%	affects main & pattern background color	255
12	Blue	000-255	0 - 100%		255
13	CTC (affects RGB)	000 - 004	5600K	according to CTC chart	0
		005-226	2000K-6500K linear in 20-21K steps (please see detailed CTC chart)		
		182-182	5600K		
		226-226	6500K		
		227-255	6621K-10.000K linear in 120-121K steps (please see detailed CTC chart)		
14	Tint (affects CTC and RGB)	0	no function		0
		001-127	Magenta -> Neutral		
		128-128	Neutral		
		129-255	Neutral -> Green		
15	Color Macro (override RGB/CTC)		please use color macros from ROXX color macro chart	affects main & pattern background color	0
16	Color Macro Crossfade (Transition Time between Color Macros)	000 - 005	no function		0
		006-105	0,1s - 10s (0,1s steps)		
		106-214	11s - 119s (1s steps)		
		215-244	2m - 6m50s (10s steps)		
		245-255	7m - 17m (1m steps)		
17	Pattern Dimmer	000-255			0
18	Pattern Shutter	000 - 019	Shutter close		0
		020 - 024	Shutter open		
		025 - 064	Strobe 1 (fast ⊕ slow)		
		065 - 069	Shutter open		
		070 - 084	Strobe 2: opening pulse (fast ⊕ slow)		
		085 - 089	Shutter open		
		090 - 104	Strobe 3: closing pulse (fast ⊕ slow)		
		105 - 109	Shutter open		
		110 - 124	Strobe 4: random strobe (fast ⊕ slow)		
		125 - 129	Shutter open		

26CH RGB Mode -8bit (Default Mode)

18	Pattern Shutter	130 - 144	Strobe 5: random opening pulse (fast ⊕ slow)	20
		145 - 149	Shutter open	
		150 - 164	Strobe 6: random closing pulse (fast ⊕ slow)	
		165 - 169	Shutter open	
		170 - 184	Strobe 7: burst pulse (fast ⊕ slow)	
		185 - 189	Shutter open	
		190 - 204	Strobe 8: random burst pulse (fast ⊕ slow)	
		205 - 209	Shutter open	
		210 - 224	Strobe 9: sine wave (fast ⊕ slow)	
		225 - 229	Shutter open	
		230 - 244	Strobe 10: burst (fast ⊕ slow)	
		245 - 255	Shutter open	
19	Pattern selection	000-255	according to Pattern chart	0
20	Pattern selection X-fade	000 - 005	no function	0
		006-255	1s - 250s (1s steps)	
21	Pattern speed	000-005	No Function	0
		006-124	Left to Right / Fast to slow	
		125-130	No Function	
		131-249	Right to Left / Slow to fast	
		250-255	No Function	
22	Pattern X-fade	000-005	Snap from cell to cell	0
		006-255	Fade Duration short to long	
23	Pattern Red	000-255	0 - 100%	255
24	Pattern Green	000-255	0 - 100%	255
25	Pattern Blue	000-255	0 - 100%	255
26	Device Settings (please see remark *1)		According to our Device Settings chart RGB mode	0

30CH RGB Mode - 16bit

Ch.	Function	Value	Setting	Default
1	Master Dimmer	000-255	0 - 100%	0
2	Master Dimmer fine	000-255	0 - 100%	0
3	Shutter	000 - 019	Shutter close	20
		020 - 024	Shutter open	
		025 - 064	Strobe 1 (fast ⊕ slow)	
		065 - 069	Shutter open	
		070 - 084	Strobe 2: opening pulse (fast ⊕ slow)	
		085 - 089	Shutter open	
		090 - 104	Strobe 3: closing pulse (fast ⊕ slow)	
		105 - 109	Shutter open	
		110 - 124	Strobe 4: random strobe (fast ⊕ slow)	

30CH RGB Mode - 16bit

3	Shutter	125 - 129	Shutter open		20
		130 - 144	Strobe 5: random opening pulse (fast ⊕ slow)		
		145 - 149	Shutter open		
		150 - 164	Strobe 6:random closing pulse (fast ⊕ slow)		
		165 - 169	Shutter open		
		170 - 184	Strobe 7: burst pulse (fast ⊕ slow)		
		185 - 189	Shutter open		
		190 - 204	Strobe 8: random burst pulse (fast ⊕ slow)		
		205 - 209	Shutter open		
		210 - 224	Strobe 9:sine wave (fast ⊕ slow)		
		225 - 229	Shutter open		
		230 - 244	Strobe 10: burst (fast ⊕ slow)		
		245 - 255	Shutter open		
4	Duration	000-255	0 - 100%	(only affects to channel 2 - Strobe 1 - 025-064)	0
5	Tilt	000-255	0 - 100% Back - Front		127
6	Tilt fine	000-255	0 - 100% Back - Front		255
7	Zoom	000-255	0 - 100% Narrow - Wide		0
8	Smart Filter	000-255	0 - 100% Clear - Frosted		0
9	Smart Filter Shutter	000 - 019	Shutter close		20
		020 - 024	Shutter open		
		025 - 064	Strobe 1 (fast ⊕ slow)		
		065 - 069	Shutter open		
		070 - 084	Strobe 2: opening pulse (fast ⊕ slow)		
		085 - 089	Shutter open		
		090 - 104	Strobe 3: closing pulse (fast ⊕ slow)		
		105 - 109	Shutter open		
		110 - 124	Strobe 4: random strobe (fast ⊕ slow)		
		125 - 129	Shutter open		
		130 - 144	Strobe 5: random opening pulse (fast ⊕ slow)		
		145 - 149	Shutter open		
		150 - 164	Strobe 6:random closing pulse (fast ⊕ slow)		
		165 - 169	Shutter open		
		170 - 184	Strobe 7: burst pulse (fast ⊕ slow)		
		185 - 189	Shutter open		
		190 - 204	Strobe 8: random burst pulse (fast ⊕ slow)		
		205 - 209	Shutter open		
		210 - 224	Strobe 9:sine wave (fast ⊕ slow)		
		225 - 229	Shutter open		
		230 - 244	Strobe 10: burst (fast ⊕ slow)		
		245 - 255	Shutter open		

30CH RGB Mode - 16bit

10	Total Zoom (override Zoom + SG Filter)	000-005	no function		0
		006 - 255	0 - 100% Narrow - Wide (Zoom + Frost)		
11	Red	000-255	0 - 100%	affects main & pattern background color	255
12	Red fine	000-255	0 - 100%		255
13	Green	000-255	0 - 100%		255
14	Green fine	000-255	0 - 100%		255
15	Blue	000-255	0 - 100%		255
16	Blue fine	000-255	0 - 100%		255
17	CTC (affects RGB)	000 - 004	5600K	according to CTC chart	0
		005-226	2000K-6500K linear in 20-21K steps (please see detailed CTC chart)		
		182-182	5600K		
		226-226	6500K		
		227-255	6621K-10.000K linear in 120-121K steps (please see detailed CTC chart)		
18	Taccording to Pat- tern chart	0	no function		0
		001-127	Magenta -> Neutral		
		128-128	Neutral		
		129-255	Neutral -> Green		
19	Color Macro (override RGB/CTC)		please use color macros from ROXX color macro chart		0
20	Color Macro Crossfade (Transition Time between Color Macros)	000 - 005	no function		0
		006-105	0,1s - 10s (0,1s steps)		
		106-214	11s - 119s (1s steps)		
		215-244	2m - 6m50s (10s steps)		
		245-255	7m - 17m (1m steps)		
21	Pattern Dimmer	000-255			0
22	Pattern Shutter	000 - 019	Shutter close		20
		020 - 024	Shutter open		
		025 - 064	Strobe 1 (fast ⊕ slow)		
		065 - 069	Shutter open		
		070 - 084	Strobe 2: opening pulse (fast ⊕ slow)		
		085 - 089	Shutter open		
		090 - 104	Strobe 3: closing pulse (fast ⊕ slow)		
		105 - 109	Shutter open		
		110 - 124	Strobe 4: random strobe (fast ⊕ slow)		
		125 - 129	Shutter open		
		130 - 144	Strobe 5: random opening pulse (fast ⊕ slow)		
		145 - 149	Shutter open		
		150 - 164	Strobe 6:random closing pulse (fast ⊕ slow)		
		165 - 169	Shutter open		

30CH RGB Mode - 16bit				
22	Pattern Shutter	170 - 184	Strobe 7: burst pulse (fast ⊕ slow)	20
		185 - 189	Shutter open	
		190 - 204	Strobe 8: random burst pulse (fast ⊕ slow)	
		205 - 209	Shutter open	
		210 - 224	Strobe 9: sine wave (fast ⊕ slow)	
		225 - 229	Shutter open	
		230 - 244	Strobe 10: burst (fast ⊕ slow)	
		245 - 255	Shutter open	
23	Pattern selection	000-255	according to Pattern chart	0
24	Pattern selection X-fade	000 - 005	no function	0
		006-255	1s - 250s (1s steps)	
25	Pattern speed	000-005	No Function	0
		006-124	Left to Right / Fast to slow	
		125-130	No Function	
		131-249	Right to Left / Slow to fast	
		250-255	No Function	
26	Pattern X-fade	000-005	Snap from cell to cell	0
		006-255	Fade Duration short to long	
27	Pattern Red	000-255	0 - 100%	255
28	Pattern Green	000-255	0 - 100%	255
29	Pattern Blue	000-255	0 - 100%	255
30	Device Settings (please see remark *1)		According to our Device Settings chart RGB mode	0
28CH DIRECT Mode - 8bit				
Ch.	Function	Value	Setting	Default
1	Master Dimmer	000-255	0 - 100%	0
2	Shutter	000 - 019	Shutter close	20
		020 - 024	Shutter open	
		025 - 064	Strobe 1 (fast ⊕ slow)	
		065 - 069	Shutter open	
		070 - 084	Strobe 2: opening pulse (fast ⊕ slow)	
		085 - 089	Shutter open	
		090 - 104	Strobe 3: closing pulse (fast ⊕ slow)	
		105 - 109	Shutter open	
		110 - 124	Strobe 4: random strobe (fast ⊕ slow)	
		125 - 129	Shutter open	
		130 - 144	Strobe 5: random opening pulse (fast ⊕ slow)	
		145 - 149	Shutter open	
		150 - 164	Strobe 6: random closing pulse (fast ⊕ slow)	
		165 - 169	Shutter open	
		170 - 184	Strobe 7: burst pulse (fast ⊕ slow)	

28CH DIRECT Mode - 8bit

2	Shutter	185 - 189	Shutter open		20
		190 - 204	Strobe 8: random burst pulse (fast ⊕ slow)		
		205 - 209	Shutter open		
		210 - 224	Strobe 9:sine wave (fast ⊕ slow)		
		225 - 229	Shutter open		
		230 - 244	Strobe 10: burst (fast ⊕ slow)		
		245 - 255	Shutter open		
3	Duration	000-255	0 - 100%	(only affects to channel 2 - Strobe 1 - 025-064)	0
4	Tilt	000-255	0 - 100% Back - Front		128
5	Tilt fine	000-255	0 - 100% Back - Front		255
6	Zoom	000-255	0 - 100% Narrow - Wide		0
7	Smart Filter	000-255	0 - 100% Clear - Frosted		0
8	Smart Filter Shutter	000 - 019	Shutter close		20
		020 - 024	Shutter open		
		025 - 064	Strobe 1 (fast ⊕ slow)		
		065 - 069	Shutter open		
		070 - 084	Strobe 2: opening pulse (fast ⊕ slow)		
		085 - 089	Shutter open		
		090 - 104	Strobe 3: closing pulse (fast ⊕ slow)		
		105 - 109	Shutter open		
		110 - 124	Strobe 4: random strobe (fast ⊕ slow)		
		125 - 129	Shutter open		
		130 - 144	Strobe 5: random opening pulse (fast ⊕ slow)		
		145 - 149	Shutter open		
		150 - 164	Strobe 6:random closing pulse (fast ⊕ slow)		
		165 - 169	Shutter open		
		170 - 184	Strobe 7: burst pulse (fast ⊕ slow)		
		185 - 189	Shutter open		
		190 - 204	Strobe 8: random burst pulse (fast ⊕ slow)		
		205 - 209	Shutter open		
		210 - 224	Strobe 9:sine wave (fast ⊕ slow)		
		225 - 229	Shutter open		
		230 - 244	Strobe 10: burst (fast ⊕ slow)		
		245 - 255	Shutter open		
9	Total Zoom (override Zoom + SG Filter)	000-005	no function		0
		006 - 255	0 - 100% Narrow - Wide (Zoom + Frost)		
10	Red	000-255	0 - 100%	affects main & pattern background color	250
11	Green	000-255	0 - 100%		255
12	Blue	000-255	0 - 100%		88
13	Lime	000-255	0 - 100%		255

28CH DIRECT Mode - 8bit

14	CTC (affects RGB)	000 - 004	5600K	according to CTC chart	0
		005-226	2000K-6500K linear in 20-21K steps (please see detailed CTC chart)		
		182-182	5600K		
		226-226	6500K		
		227-255	6621K-10.000K linear in 120-121K steps (please see detailed CTC chart)		
15	Tint (affects CTC and RGB)	0	no function		0
		001-127	Magenta -> Neutral		
		128-128	Neutral		
		129-255	Neutral -> Green		
16	Color Macro (override RGB/CTC)		please use color macros from ROXX color macro chart	affects main & pattern background color	0
17	Color Macro Crossfade (Transition Time between Color Macros)	000 - 005	no function		0
		006-105	0,1s - 10s (0,1s steps)		
		106-214	11s - 119s (1s steps)		
		215-244	2m - 6m50s (10s steps)		
		245-255	7m - 17m (1m steps)		
18	Pattern Dimmer	000-255			0
19	Pattern Shutter	000 - 019	Shutter close		20
		020 - 024	Shutter open		
		025 - 064	Strobe 1 (fast ⊕ slow)		
		065 - 069	Shutter open		
		070 - 084	Strobe 2: opening pulse (fast ⊕ slow)		
		085 - 089	Shutter open		
		090 - 104	Strobe 3: closing pulse (fast ⊕ slow)		
		105 - 109	Shutter open		
		110 - 124	Strobe 4: random strobe (fast ⊕ slow)		
		125 - 129	Shutter open		
		130 - 144	Strobe 5: random opening pulse (fast ⊕ slow)		
		145 - 149	Shutter open		
		150 - 164	Strobe 6:random closing pulse (fast ⊕ slow)		
		165 - 169	Shutter open		
		170 - 184	Strobe 7: burst pulse (fast ⊕ slow)		
		185 - 189	Shutter open		
		190 - 204	Strobe 8: random burst pulse (fast ⊕ slow)		
		205 - 209	Shutter open		
		210 - 224	Strobe 9:sine wave (fast ⊕ slow)		
		225 - 229	Shutter open		
		230 - 244	Strobe 10: burst (fast ⊕ slow)		
		245 - 255	Shutter open		

28CH DIRECT Mode - 8bit

20	Pattern selection	000-255	according to Pattern chart	0
21	Pattern selection X-fade	000 - 005	no function	0
		006-255	1s - 250s (1s steps)	
22	Pattern speed	000-005	No Function	0
		006-124	Left to Right / Fast to slow	
		125-130	No Function	
		131-249	Right to Left / Slow to fast	
		250-255	No Function	
23	Pattern X-fade	000-005	Snap from cell to cell	0
		006-255	Fade Duration short to long	
24	Pattern Red	000-255	0 - 100%	255
25	Pattern Green	000-255	0 - 100%	255
26	Pattern Blue	000-255	0 - 100%	255
27	Pattern Lime	000-255	0 - 100%	255
28	Device Settings (please see remark *1)		According to our Device Settings chart Direct modes	0

33CH DIRECT Mode - 16 bit

Ch.	Function	Value	Setting	Default
1	Master Dimmer	000-255	0 - 100%	0
2	Master Dimmer fine	000-255	0 - 100%	0
3	Shutter	000 - 019	Shutter close	20
		020 - 024	Shutter open	
		025 - 064	Strobe 1 (fast ⊕ slow)	
		065 - 069	Shutter open	
		070 - 084	Strobe 2: opening pulse (fast ⊕ slow)	
		085 - 089	Shutter open	
		090 - 104	Strobe 3: closing pulse (fast ⊕ slow)	
		105 - 109	Shutter open	
		110 - 124	Strobe 4: random strobe (fast ⊕ slow)	
		125 - 129	Shutter open	
		130 - 144	Strobe 5: random opening pulse (fast ⊕ slow)	
		145 - 149	Shutter open	
		150 - 164	Strobe 6: random closing pulse (fast ⊕ slow)	
		165 - 169	Shutter open	
		170 - 184	Strobe 7: burst pulse (fast ⊕ slow)	
		185 - 189	Shutter open	
		190 - 204	Strobe 8: random burst pulse (fast ⊕ slow)	
		205 - 209	Shutter open	
		210 - 224	Strobe 9: sine wave (fast ⊕ slow)	
		225 - 229	Shutter open	

33CH DIRECT Mode - 16 bit

3	Shutter	230 - 244	Strobe 10: burst (fast ⊕ slow)		20
		245 - 255	Shutter open		
4	Duration	000-255	0 - 100%	(only affects to channel 2 - Strobe 1 - 025-064)	0
5	Tilt	000-255	0 - 100% Back - Front		127
6	Tilt fine	000-255	0 - 100% Back - Front		255
7	Zoom	000-255	0 - 100% Narrow - Wide		0
8	SmartFilter	000-255	0 - 100% Clear - Frosted		0
9	Smart Filter Shutter	000 - 019	Shutter close		20
		020 - 024	Shutter open		
		025 - 064	Strobe 1 (fast ⊕ slow)		
		065 - 069	Shutter open		
		070 - 084	Strobe 2: opening pulse (fast ⊕ slow)		
		085 - 089	Shutter open		
		090 - 104	Strobe 3: closing pulse (fast ⊕ slow)		
		105 - 109	Shutter open		
		110 - 124	Strobe 4: random strobe (fast ⊕ slow)		
		125 - 129	Shutter open		
		130 - 144	Strobe 5: random opening pulse (fast ⊕ slow)		
		145 - 149	Shutter open		
		150 - 164	Strobe 6:random closing pulse (fast ⊕ slow)		
		165 - 169	Shutter open		
		170 - 184	Strobe 7: burst pulse (fast ⊕ slow)		
		185 - 189	Shutter open		
		190 - 204	Strobe 8: random burst pulse (fast ⊕ slow)		
		205 - 209	Shutter open		
		210 - 224	Strobe 9:sine wave (fast ⊕ slow)		
		225 - 229	Shutter open		
		230 - 244	Strobe 10: burst (fast ⊕ slow)		
		245 - 255	Shutter open		
10	Total Zoom (override Zoom + SG Filter)	000-005	no function		0
		006 - 255	0 - 100% Narrow - Wide (Zoom + Frost)		
11	Red	000-255	0 - 100%	affects main & pattern background color	250
12	Red fine	000-255	0 - 100%		255
13	Green	000-255	0 - 100%		255
14	Green fine	000-255	0 - 100%		255
15	Blue	000-255	0 - 100%		88
16	Blue fine	000-255	0 - 100%		255
17	Lime	000-255	0 - 100%		255
18	Lime fine	000-255	0 - 100%		255

33CH DIRECT Mode - 16 bit

19	CTC (affects RGB)	000 - 004	5600K	according to CTC chart	0
		005-226	2000K-6500K linear in 20-21K steps (please see detailed CTC chart)		
		182-182	5600K		
		226-226	6500K		
		227-255	6621K-10.000K linear in 120-121K steps (please see detailed CTC chart)		
20	Tint (affects CTC and RGB)	0	no function		0
		001-127	Magenta -> Neutral		
		128-128	Neutral		
		129-255	Neutral -> Green		
21	Color Macro (override RGB/CTC)		please use color macros from ROXX color macro chart	affects main & pattern background color	0
22	Color Macro Crossfade (Transition Time between Color Macros)	000 - 005	no function		0
		006-105	0,1s - 10s (0,1s steps)		
		106-214	11s - 119s (1s steps)		
		215-244	2m - 6m50s (10s steps)		
		245-255	7m - 17m (1m steps)		
23	Pattern Dimmer	000-255			0
24	Pattern Shutter	000 - 019	Shutter close		20
		020 - 024	Shutter open		
		025 - 064	Strobe 1 (fast ⊕ slow)		
		065 - 069	Shutter open		
		070 - 084	Strobe 2: opening pulse (fast ⊕ slow)		
		085 - 089	Shutter open		
		090 - 104	Strobe 3: closing pulse (fast ⊕ slow)		
		105 - 109	Shutter open		
		110 - 124	Strobe 4: random strobe (fast ⊕ slow)		
		125 - 129	Shutter open		
		130 - 144	Strobe 5: random opening pulse (fast ⊕ slow)		
		145 - 149	Shutter open		
		150 - 164	Strobe 6:random closing pulse (fast ⊕ slow)		
		165 - 169	Shutter open		
		170 - 184	Strobe 7: burst pulse (fast ⊕ slow)		
		185 - 189	Shutter open		
		190 - 204	Strobe 8: random burst pulse (fast ⊕ slow)		
		205 - 209	Shutter open		
		210 - 224	Strobe 9:sine wave (fast ⊕ slow)		
		225 - 229	Shutter open		
		230 - 244	Strobe 10: burst (fast ⊕ slow)		
		245 - 255	Shutter open		

33CH DIRECT Mode - 16 bit

25	Pattern selection	000-255	according to Pattern chart	0
26	Pattern selection X-fade	000 - 005	no function	0
		006-255	1s - 250s (1s steps)	
27	Pattern speed	000-005	No Function	0
		006-124	Left to Right / Fast to slow	
		125-130	No Function	
		131-249	Right to Left / Slow to fast	
		250-255	No Function	
28	Pattern X-fade	000-005	Snap from cell to cell	0
		006-255	Fade Duration short to long	
29	Pattern Red	000-255	0 - 100%	255
30	Pattern Green	000-255	0 - 100%	255
31	Pattern Blue	000-255	0 - 100%	255
32	Pattern Lime	000-255	0 - 100%	255
33	Device Settings (please see remark *1)		According to our Device Settings chart Direct modes	0

81CH Pure Mode - 8bit

Ch.	Function	Value	Setting	Default
1	Master Dimmer	000-255	0 - 100%	0
2	Shutter	000 - 019	Shutter close	20
		020 - 024	Shutter open	
		025 - 064	Strobe 1 (fast ⊕ slow)	
		065 - 069	Shutter open	
		070 - 084	Strobe 2: opening pulse (fast ⊕ slow)	
		085 - 089	Shutter open	
		090 - 104	Strobe 3: closing pulse (fast ⊕ slow)	
		105 - 109	Shutter open	
		110 - 124	Strobe 4: random strobe (fast ⊕ slow)	
		125 - 129	Shutter open	
		130 - 144	Strobe 5: random opening pulse (fast ⊕ slow)	
		145 - 149	Shutter open	
		150 - 164	Strobe 6: random closing pulse (fast ⊕ slow)	
		165 - 169	Shutter open	
		170 - 184	Strobe 7: burst pulse (fast ⊕ slow)	
		185 - 189	Shutter open	
		190 - 204	Strobe 8: random burst pulse (fast ⊕ slow)	
		205 - 209	Shutter open	
		210 - 224	Strobe 9: sine wave (fast ⊕ slow)	
		225 - 229	Shutter open	
		230 - 244	Strobe 10: burst (fast ⊕ slow)	
		245 - 255	Shutter open	

81CH Pure Mode - 8bit						
3	Duration	000-255	0 - 100%	(only affects to channel 2 - Strobe 1 - 025-064)	0	
4	Tilt	000-255	0 - 100% Back - Front			128
5	Tilt fine	000-255	0 - 100% Back - Front			255
6	Zoom	000-255	0 - 100% Narrow - Wide			0
7	Smart Filter	000-255	0 - 100% Clear - Frosted			0
8	Smart Filter Shutter	000 - 019	Shutter close			20
		020 - 024	Shutter open			
		025 - 064	Strobe 1 (fast ⊕ slow)			
		065 - 069	Shutter open			
		070 - 084	Strobe 2: opening pulse (fast ⊕ slow)			
		085 - 089	Shutter open			
		090 - 104	Strobe 3: closing pulse (fast ⊕ slow)			
		105 - 109	Shutter open			
		110 - 124	Strobe 4: random strobe (fast ⊕ slow)			
		125 - 129	Shutter open			
		130 - 144	Strobe 5: random opening pulse (fast ⊕ slow)			
		145 - 149	Shutter open			
		150 - 164	Strobe 6:random closing pulse (fast ⊕ slow)			
		165 - 169	Shutter open			
		170 - 184	Strobe 7: burst pulse (fast ⊕ slow)			
		185 - 189	Shutter open			
		190 - 204	Strobe 8: random burst pulse (fast ⊕ slow)			
		205 - 209	Shutter open			
		210 - 224	Strobe 9:sine wave (fast ⊕ slow)			
		225 - 229	Shutter open			
		230 - 244	Strobe 10: burst (fast ⊕ slow)			
		245 - 255	Shutter open			
9	Red 1	000-255	0 - 100%			255
10	Green 1	000-255	0 - 100%			255
11	Blue 1	000-255	0 - 100%			255
12	Red 2	000-255	0 - 100%			255
13	Green 2	000-255	0 - 100%			255
14	Blue 2	000-255	0 - 100%			255
15	Red 3	000-255	0 - 100%			255
16	Green 3	000-255	0 - 100%			255
17	Blue 3	000-255	0 - 100%			255
18	Red 4	000-255	0 - 100%			255
19	Green 4	000-255	0 - 100%			255

81CH Pure Mode - 8bit

20	Blue 4	000-255	0 - 100%	255
21	Red 5	000-255	0 - 100%	255
22	Green 5	000-255	0 - 100%	255
23	Blue 5	000-255	0 - 100%	255
24	Red 6	000-255	0 - 100%	255
25	Green 6	000-255	0 - 100%	255
26	Blue 6	000-255	0 - 100%	255
27	Red 7	000-255	0 - 100%	255
28	Green 7	000-255	0 - 100%	255
29	Blue 7	000-255	0 - 100%	255
30	Red 8	000-255	0 - 100%	255
31	Green 8	000-255	0 - 100%	255
32	Blue 8	000-255	0 - 100%	255
...80Blue 24	000-255	0 - 100%	255
81	Device Settings (please see remark *1)		According to our Device Settings chart RGB mode	0

154CH Pure Mode - 16 bit

Ch.	Function	Value	Setting	Default
1	Master Dimmer	000-255	0 - 100%	0
2	Master Dimmer fine	000-255	0 - 100%	0
3	Shutter	000 - 019	Shutter close	20
		020 - 024	Shutter open	
		025 - 064	Strobe 1 (fast ⊕ slow)	
		065 - 069	Shutter open	
		070 - 084	Strobe 2: opening pulse (fast ⊕ slow)	
		085 - 089	Shutter open	
		090 - 104	Strobe 3: closing pulse (fast ⊕ slow)	
		105 - 109	Shutter open	
		110 - 124	Strobe 4: random strobe (fast ⊕ slow)	
		125 - 129	Shutter open	
		130 - 144	Strobe 5: random opening pulse (fast ⊕ slow)	
		145 - 149	Shutter open	
		150 - 164	Strobe 6: random closing pulse (fast ⊕ slow)	
		165 - 169	Shutter open	
		170 - 184	Strobe 7: burst pulse (fast ⊕ slow)	
		185 - 189	Shutter open	
		190 - 204	Strobe 8: random burst pulse (fast ⊕ slow)	
		205 - 209	Shutter open	
		210 - 224	Strobe 9: sine wave (fast ⊕ slow)	
		225 - 229	Shutter open	

154CH Pure Mode - 16 bit

3	Shutter	230 - 244	Strobe 10: burst (fast ⊕ slow)		20
		245 - 255	Shutter open		
4	Duration	000-255	0 - 100%	(only affects to channel 2 - Strobe 1 - 025-064)	0
5	Tilt	000-255	0 - 100% Back - Front		127
6	Tilt fine	000-255	0 - 100% Back - Front		255
7	Zoom	000-255	0 - 100% Narrow - Wide		0
8	Smart Filter	000-255	0 - 100% Clear - Frosted		0
9	Smart Filter Shutter	000 - 019	Shutter close		20
		020 - 024	Shutter open		
		025 - 064	Strobe 1 (fast ⊕ slow)		
		065 - 069	Shutter open		
		070 - 084	Strobe 2: opening pulse (fast ⊕ slow)		
		085 - 089	Shutter open		
		090 - 104	Strobe 3: closing pulse (fast ⊕ slow)		
		105 - 109	Shutter open		
		110 - 124	Strobe 4: random strobe (fast ⊕ slow)		
		125 - 129	Shutter open		
		130 - 144	Strobe 5: random opening pulse (fast ⊕ slow)		
		145 - 149	Shutter open		
		150 - 164	Strobe 6:random closing pulse (fast ⊕ slow)		
		165 - 169	Shutter open		
		170 - 184	Strobe 7: burst pulse (fast ⊕ slow)		
		185 - 189	Shutter open		
		190 - 204	Strobe 8: random burst pulse (fast ⊕ slow)		
		205 - 209	Shutter open		
		210 - 224	Strobe 9:sine wave (fast ⊕ slow)		
		225 - 229	Shutter open		
		230 - 244	Strobe 10: burst (fast ⊕ slow)		
		245 - 255	Shutter open		
10	Red 1	000-255	0 - 100%		255
11	Red 1 fine	000-255	0 - 100%		255
12	Green 1	000-255	0 - 100%		255
13	Green 1 fine	000-255	0 - 100%		255
14	Blue 1	000-255	0 - 100%		255
15	Blue 1 fine	000-255	0 - 100%		255
16	Red 2	000-255	0 - 100%		255
17	Red 2 fine	000-255	0 - 100%		255
18	Green 2	000-255	0 - 100%		255
19	Green 2 fine	000-255	0 - 100%		255
20	Blue 2	000-255	0 - 100%		255
21	Blue 2 fine	000-255	0 - 100%		255
22	Red 3	000-255	0 - 100%		255

154CH Pure Mode - 16 bit

23	Red 3 fine	000-255	0 - 100%	255
24	Green 3	000-255	0 - 100%	255
25	Green 3 fine	000-255	0 - 100%	255
26	Blue 3	000-255	0 - 100%	255
27	Blue 3 fine	000-255	0 - 100%	255
28	Red 4	000-255	0 - 100%	255
29	Red 4 fine	000-255	0 - 100%	255
30	Green 4	000-255	0 - 100%	255
31	Green 4 fine	000-255	0 - 100%	255
32	Blue 4	000-255	0 - 100%	255
33	Blue 4 fine	000-255	0 - 100%	255
...153	...Blue 24 fine	000-255	0 - 100%	255
154	Device Settings (please see remark *1)		According to our Device Settings chart RGB mode	0

9CH Dual Mode - 8 bit

Ch.	Function	Value	Setting	Default
1	Master Dimmer	000-255	0 - 100%	0
2	Shutter	000 - 019	Shutter close	20
		020 - 024	Shutter open	
		025 - 064	Strobe 1 (fast ⊕ slow)	
		065 - 069	Shutter open	
		070 - 084	Strobe 2: opening pulse (fast ⊕ slow)	
		085 - 089	Shutter open	
		090 - 104	Strobe 3: closing pulse (fast ⊕ slow)	
		105 - 109	Shutter open	
		110 - 124	Strobe 4: random strobe (fast ⊕ slow)	
		125 - 129	Shutter open	
		130 - 144	Strobe 5: random opening pulse (fast ⊕ slow)	
		145 - 149	Shutter open	
		150 - 164	Strobe 6: random closing pulse (fast ⊕ slow)	
		165 - 169	Shutter open	
		170 - 184	Strobe 7: burst pulse (fast ⊕ slow)	
		185 - 189	Shutter open	
		190 - 204	Strobe 8: random burst pulse (fast ⊕ slow)	
		205 - 209	Shutter open	
		210 - 224	Strobe 9: sine wave (fast ⊕ slow)	
		225 - 229	Shutter open	
		230 - 244	Strobe 10: burst (fast ⊕ slow)	
		245 - 255	Shutter open	

9CH Dual Mode - 8 bit

3	Duration	000-255	0 - 100%	(only affects to channel 2 - Strobe 1 - 025-064)	0
4	Tilt	000-255	0 - 100% Back - Front		127
5	Tilt fine	000-255	0 - 100% Back - Front		255
6	Zoom	000-255	0 - 100% Narrow - Wide		0
7	SmartFilter	000-255	0 - 100% Clear - Frosted		0
8	Smart Filter Shutter	000 - 019	Shutter close		20
		020 - 024	Shutter open		
		025 - 064	Strobe 1 (fast ⊕ slow)		
		065 - 069	Shutter open		
		070 - 084	Strobe 2: opening pulse (fast ⊕ slow)		
		085 - 089	Shutter open		
		090 - 104	Strobe 3: closing pulse (fast ⊕ slow)		
		105 - 109	Shutter open		
		110 - 124	Strobe 4: random strobe (fast ⊕ slow)		
		125 - 129	Shutter open		
		130 - 144	Strobe 5: random opening pulse (fast ⊕ slow)		
		145 - 149	Shutter open		
		150 - 164	Strobe 6: random closing pulse (fast ⊕ slow)		
		165 - 169	Shutter open		
		170 - 184	Strobe 7: burst pulse (fast ⊕ slow)		
		185 - 189	Shutter open		
		190 - 204	Strobe 8: random burst pulse (fast ⊕ slow)		
		205 - 209	Shutter open		
		210 - 224	Strobe 9: sine wave (fast ⊕ slow)		
		225 - 229	Shutter open		
		230 - 244	Strobe 10: burst (fast ⊕ slow)		
		245 - 255	Shutter open		
9	Device Settings (please see remark *1)		According to our Device Settings chart RGB mode		0

10CH Dual Mode - 16 bit

Ch.	Function	Value	Setting	Default
1	Master Dimmer	000-255	0 - 100%	0
2	Master Dimmer fine	000-255	0 - 100%	0
3	Shutter	000 - 019	Shutter close	20
		020 - 024	Shutter open	
		025 - 064	Strobe 1 (fast ⊕ slow)	
		065 - 069	Shutter open	
		070 - 084	Strobe 2: opening pulse (fast ⊕ slow)	
		085 - 089	Shutter open	

10CH Dual Mode - 16 bit

3	Shutter	090 - 104	Strobe 3: closing pulse (fast ⊕ slow)	20
		105 - 109	Shutter open	
		110 - 124	Strobe 4: random strobe (fast ⊕ slow)	
		125 - 129	Shutter open	
		130 - 144	Strobe 5: random opening pulse (fast ⊕ slow)	
		145 - 149	Shutter open	
		150 - 164	Strobe 6: random closing pulse (fast ⊕ slow)	
		165 - 169	Shutter open	
		170 - 184	Strobe 7: burst pulse (fast ⊕ slow)	
		185 - 189	Shutter open	
		190 - 204	Strobe 8: random burst pulse (fast ⊕ slow)	
		205 - 209	Shutter open	
		210 - 224	Strobe 9: sine wave (fast ⊕ slow)	
		225 - 229	Shutter open	
		230 - 244	Strobe 10: burst (fast ⊕ slow)	
		245 - 255	Shutter open	
4	Duration	000-255	0 - 100%	0
5	Tilt	000-255	0 - 100% Back - Front	127
6	Tilt fine	000-255	0 - 100% Back - Front	255
7	Zoom	000-255	0 - 100% Narrow - Wide	0
8	SmartFilter	000-255	0 - 100% Clear - Frosted	0
9	Smart Filter Shutter	000 - 019	Shutter close	20
		020 - 024	Shutter open	
		025 - 064	Strobe 1 (fast ⊕ slow)	
		065 - 069	Shutter open	
		070 - 084	Strobe 2: opening pulse (fast ⊕ slow)	
		085 - 089	Shutter open	
		090 - 104	Strobe 3: closing pulse (fast ⊕ slow)	
		105 - 109	Shutter open	
		110 - 124	Strobe 4: random strobe (fast ⊕ slow)	
		125 - 129	Shutter open	
		130 - 144	Strobe 5: random opening pulse (fast ⊕ slow)	
		145 - 149	Shutter open	
		150 - 164	Strobe 6: random closing pulse (fast ⊕ slow)	
		165 - 169	Shutter open	
		170 - 184	Strobe 7: burst pulse (fast ⊕ slow)	
		185 - 189	Shutter open	
		190 - 204	Strobe 8: random burst pulse (fast ⊕ slow)	
		205 - 209	Shutter open	
		210 - 224	Strobe 9: sine wave (fast ⊕ slow)	
		225 - 229	Shutter open	

10CH Dual Mode - 16 bit

9	Smart Filter Shutter	230 - 244	Strobe 10: burst (fast ⊕ slow)	20
		245 - 255	Shutter open	
10	Device Settings (please see remark *1)		According to our Device Settings chart RGB mode	0

95CH Full Access Mode - 8 bit

Ch.	Function	Value	Setting	Default
1	Master Dimmer	000-255	0 - 100%	0
2	Shutter	000 - 019	Shutter close	20
		020 - 024	Shutter open	
		025 - 064	Strobe 1 (fast ⊕ slow)	
		065 - 069	Shutter open	
		070 - 084	Strobe 2: opening pulse (fast ⊕ slow)	
		085 - 089	Shutter open	
		090 - 104	Strobe 3: closing pulse (fast ⊕ slow)	
		105 - 109	Shutter open	
		110 - 124	Strobe 4: random strobe (fast ⊕ slow)	
		125 - 129	Shutter open	
		130 - 144	Strobe 5: random opening pulse (fast ⊕ slow)	
		145 - 149	Shutter open	
		150 - 164	Strobe 6: random closing pulse (fast ⊕ slow)	
		165 - 169	Shutter open	
		170 - 184	Strobe 7: burst pulse (fast ⊕ slow)	
		185 - 189	Shutter open	
		190 - 204	Strobe 8: random burst pulse (fast ⊕ slow)	
		205 - 209	Shutter open	
		210 - 224	Strobe 9: sine wave (fast ⊕ slow)	
		225 - 229	Shutter open	
		230 - 244	Strobe 10: burst (fast ⊕ slow)	
		245 - 255	Shutter open	
3	Duration	000-255	0 - 100% (only affects to channel 2 - Strobe 1 - 025-064)	0
4	Tilt	000-255	0 - 100% Back - Front	128
6	Tilt fine	000-255	0 - 100% Back - Front	255
6	Zoom	000-255	0 - 100% Narrow - Wide	0
7	Smart Filter	000-255	0 - 100% Clear - Frosted	0
8	Smart Filter Shutter	000 - 019	Shutter close	20
		020 - 024	Shutter open	
		025 - 064	Strobe 1 (fast ⊕ slow)	
		065 - 069	Shutter open	
		070 - 084	Strobe 2: opening pulse (fast ⊕ slow)	
		085 - 089	Shutter open	

95CH Full Access Mode - 8 bit

8	Smart Filter Shutter	090 - 104	Strobe 3: closing pulse (fast ⊕ slow)		20
		105 - 109	Shutter open		
		110 - 124	Strobe 4: random strobe (fast ⊕ slow)		
		125 - 129	Shutter open		
		130 - 144	Strobe 5: random opening pulse (fast ⊕ slow)		
		145 - 149	Shutter open		
		150 - 164	Strobe 6:random closing pulse (fast ⊕ slow)		
		165 - 169	Shutter open		
		170 - 184	Strobe 7: burst pulse (fast ⊕ slow)		
		185 - 189	Shutter open		
		190 - 204	Strobe 8: random burst pulse (fast ⊕ slow)		
		205 - 209	Shutter open		
		210 - 224	Strobe 9:sine wave (fast ⊕ slow)		
		225 - 229	Shutter open		
		230 - 244	Strobe 10: burst (fast ⊕ slow)		
		245 - 255	Shutter open		
9	Total Zoom (override Zoom + SG Filter)	000-005	no function		0
		006 - 255	0 - 100% Narrow - Wide (Zoom + Frost)		
10	CTC (affects RGB)	000 - 004	5600K	according to CTC chart	0
		005-226	2000K-6500K linear in 20-21K steps (please see detailed CTC chart)		
		182-182	5600K		
		226-226	6500K		
		227-255	6621K-10.000K linear in 120-121K steps (please see detailed CTC chart)		
11	Tint (affects CTC and RGB)	0	no function		0
		001-127	Magenta -> Neutral		
		128-128	Neutral		
		129-255	Neutral -> Green		
12	Color Macro (override RGB/CTC)		please use color macros from ROXX color macro chart	affects main & pattern background color	0
13	Color Macro Crossfade (Transi- tion Time between Color Macros)	000 - 005	no function		0
		006-105	0,1s - 10s (0,1s steps)		
		106-214	11s - 119s (1s steps)		
		215-244	2m - 6m50s (10s steps)		
		245-255	7m - 17m (1m steps)		
14	Pattern Dimmer	000-255			0
15	Pattern Shutter	000 - 019	Shutter close		20
		020 - 024	Shutter open		
		025 - 064	Strobe 1 (fast ⊕ slow)		
		065 - 069	Shutter open		
		070 - 084	Strobe 2: opening pulse (fast ⊕ slow)		

95CH Full Access Mode - 8 bit

15	Pattern Shutter	085 - 089	Shutter open	20
		090 - 104	Strobe 3: closing pulse (fast ⊕ slow)	
		105 - 109	Shutter open	
		110 - 124	Strobe 4: random strobe (fast ⊕ slow)	
		125 - 129	Shutter open	
		130 - 144	Strobe 5: random opening pulse (fast ⊕ slow)	
		145 - 149	Shutter open	
		150 - 164	Strobe 6: random closing pulse (fast ⊕ slow)	
		165 - 169	Shutter open	
		170 - 184	Strobe 7: burst pulse (fast ⊕ slow)	
		185 - 189	Shutter open	
		190 - 204	Strobe 8: random burst pulse (fast ⊕ slow)	
		205 - 209	Shutter open	
		210 - 224	Strobe 9:sine wave (fast ⊕ slow)	
		225 - 229	Shutter open	
		230 - 244	Strobe 10: burst (fast ⊕ slow)	
		245 - 255	Shutter open	
16	Pattern selection	000-255	according to Pattern chart	0
17	Pattern selection X-fade	000 - 005	no function	0
		006-255	1s - 250s (1s steps)	
18	Pattern speed	000-005	No Function	0
		006-124	Left to Right / Fast to slow	
		125-130	No Function	
		131-249	Right to Left / Slow to fast	
		250-255	No Function	
19	Pattern X-fade	000-005	Snap from cell to cell	0
		006-255	Fade Duration short to long	
20	Pattern Red	000-255	0 - 100%	255
21	Pattern Green	000-255	0 - 100%	255
22	Pattern Blue	000-255	0 - 100%	255
23	Red 1	000-255	0 - 100%	255
24	Green 1	000-255	0 - 100%	255
25	Blue 1	000-255	0 - 100%	255
26	Red 2	000-255	0 - 100%	255
27	Green 2	000-255	0 - 100%	255
28	Blue 2	000-255	0 - 100%	255
29	Red 3	000-255	0 - 100%	255
30	Green 3	000-255	0 - 100%	255
31	Blue 3	000-255	0 - 100%	255
32	Red 4	000-255	0 - 100%	255
33	Green 4	000-255	0 - 100%	255
34	Blue 4	000-255	0 - 100%	255

35	Red 5	000-255	0 - 100%	255
36	Green 5	000-255	0 - 100%	255
37	Blue 5	000-255	0 - 100%	255
38	Red 6	000-255	0 - 100%	255
39	Green 6	000-255	0 - 100%	255
40	Blue 6	000-255	0 - 100%	255
41	Red 7	000-255	0 - 100%	255
42	Green 7	000-255	0 - 100%	255
43	Blue 7	000-255	0 - 100%	255
44	Red 8	000-255	0 - 100%	255
45	Green 8	000-255	0 - 100%	255
46	Blue 8	000-255	0 - 100%	255
...94	...Blue 24	000-255	0 - 100%	255
95	Device Settings (please see remark *1)		According to our Device Settings chart RGB mode	0

168CH Full Access Mode - 16 bit

Ch.	Function	Value	Setting	Default
1	Master Dimmer	000-255	0 - 100%	0
2	Master Dimmer fine	000-255	0 - 100%	0
3	Shutter	000 - 019	Shutter close	20
		020 - 024	Shutter open	
		025 - 064	Strobe 1 (fast ⊕ slow)	
		065 - 069	Shutter open	
		070 - 084	Strobe 2: opening pulse (fast ⊕ slow)	
		085 - 089	Shutter open	
		090 - 104	Strobe 3: closing pulse (fast ⊕ slow)	
		105 - 109	Shutter open	
		110 - 124	Strobe 4: random strobe (fast ⊕ slow)	
		125 - 129	Shutter open	
		130 - 144	Strobe 5: random opening pulse (fast ⊕ slow)	
		145 - 149	Shutter open	
		150 - 164	Strobe 6: random closing pulse (fast ⊕ slow)	
		165 - 169	Shutter open	
		170 - 184	Strobe 7: burst pulse (fast ⊕ slow)	
		185 - 189	Shutter open	
		190 - 204	Strobe 8: random burst pulse (fast ⊕ slow)	
		205 - 209	Shutter open	
		210 - 224	Strobe 9: sine wave (fast ⊕ slow)	
		225 - 229	Shutter open	
		230 - 244	Strobe 10: burst (fast ⊕ slow)	
		245 - 255	Shutter open	

168CH Full Access Mode - 16 bit						
4	Duration	000-255	0 - 100%	(only affects to channel 2 - Strobe 1 - 025-064)	0	
5	Tilt	000-255	0 - 100% Back - Front			127
6	Tilt fine	000-255	0 - 100% Back - Front			255
7	Zoom	000-255	0 - 100% Narrow - Wide			0
8	Smart Filter	000-255	0 - 100% Clear - Frosted			0
9	Smart Filter Shutter	000 - 019	Shutter close		20	
		020 - 024	Shutter open			
		025 - 064	Strobe 1 (fast ⊕ slow)			
		065 - 069	Shutter open			
		070 - 084	Strobe 2: opening pulse (fast ⊕ slow)			
		085 - 089	Shutter open			
		090 - 104	Strobe 3: closing pulse (fast ⊕ slow)			
		105 - 109	Shutter open			
		110 - 124	Strobe 4: random strobe (fast ⊕ slow)			
		125 - 129	Shutter open			
		130 - 144	Strobe 5: random opening pulse (fast ⊕ slow)			
		145 - 149	Shutter open			
		150 - 164	Strobe 6:random closing pulse (fast ⊕ slow)			
		165 - 169	Shutter open			
		170 - 184	Strobe 7: burst pulse (fast ⊕ slow)			
		185 - 189	Shutter open			
		190 - 204	Strobe 8: random burst pulse (fast ⊕ slow)			
		205 - 209	Shutter open			
		210 - 224	Strobe 9:sine wave (fast ⊕ slow)			
		225 - 229	Shutter open			
		230 - 244	Strobe 10: burst (fast ⊕ slow)			
		245 - 255	Shutter open			
10	Total Zoom (override Zoom + SG Filter)	000-005	no function			0
		006 - 255	0 - 100% Narrow - Wide (Zoom + Frost)			
11	CTC (affects RGB)	000 - 004	5600K	according to CTC chart	0	
		005-226	2000K-6500K linear in 20-21K steps (please see detailed CTC chart)			
		182-182	5600K			
		226-226	6500K			
		227-255	6621K-10.000K linear in 120-121K steps (please see detailed CTC chart)			
12	Tint (affects CTC and RGB)	0	no function			0
		001-127	Magenta -> Neutral			
		128-128	Neutral			
		129-255	Neutral -> Green			
13	Color Macro (override RGB/CTC)		please use color macros from ROXX color macro chart	affects main & pattern background color	0	

168CH Full Access Mode - 16 bit

14	Color Macro Crossfade (Transition Time between Color Macros)	000 - 005	no function	0
		006-105	0,1s - 10s (0,1s steps)	
		106-214	11s - 119s (1s steps)	
		215-244	2m - 6m50s (10s steps)	
		245-255	7m - 17m (1m steps)	
15	Pattern Dimmer	000-255	according to Pattern chart	0
16	Pattern Shutter	000 - 019	Shutter close	20
		020 - 024	Shutter open	
		025 - 064	Strobe 1 (fast ⊕ slow)	
		065 - 069	Shutter open	
		070 - 084	Strobe 2: opening pulse (fast ⊕ slow)	
		085 - 089	Shutter open	
		090 - 104	Strobe 3: closing pulse (fast ⊕ slow)	
		105 - 109	Shutter open	
		110 - 124	Strobe 4: random strobe (fast ⊕ slow)	
		125 - 129	Shutter open	
		130 - 144	Strobe 5: random opening pulse (fast ⊕ slow)	
		145 - 149	Shutter open	
		150 - 164	Strobe 6: random closing pulse (fast ⊕ slow)	
		165 - 169	Shutter open	
		170 - 184	Strobe 7: burst pulse (fast ⊕ slow)	
		185 - 189	Shutter open	
		190 - 204	Strobe 8: random burst pulse (fast ⊕ slow)	
		205 - 209	Shutter open	
		210 - 224	Strobe 9: sine wave (fast ⊕ slow)	
		225 - 229	Shutter open	
		230 - 244	Strobe 10: burst (fast ⊕ slow)	
		245 - 255	Shutter open	
17	Pattern selection	000-255		0
18	Pattern selection X-fade	000 - 005	no function	0
		006-255	1s - 250s (1s steps)	
19	Pattern speed	000-005	No Function	0
		006-124	Left to Right / Fast to slow	
		125-130	No Function	
		131-249	Right to Left / Slow to fast	
		250-255	No Function	
20	Pattern X-fade	000-005	Snap from cell to cell	0
		006-255	Fade Duration short to long	
21	Pattern Red	000-255	0 - 100%	255
22	Pattern Green	000-255	0 - 100%	255
23	Pattern Blue	000-255	0 - 100%	255

168CH Full Access Mode - 16 bit

24	Red 1	000-255	0 - 100%	
25	Red 1 fine	000-255	0 - 100%	255
26	Green 1	000-255	0 - 100%	255
27	Green 1 fine	000-255	0 - 100%	255
28	Blue 1	000-255	0 - 100%	255
29	Blue 1 fine	000-255	0 - 100%	255
30	Red 2	000-255	0 - 100%	255
31	Red 2 fine	000-255	0 - 100%	255
32	Green 2	000-255	0 - 100%	255
33	Green 2 fine	000-255	0 - 100%	255
34	Blue 2	000-255	0 - 100%	255
35	Blue 2 fine	000-255	0 - 100%	255
36	Red 3	000-255	0 - 100%	255
37	Red 3 fine	000-255	0 - 100%	255
38	Green 3	000-255	0 - 100%	255
39	Green 3 fine	000-255	0 - 100%	255
40	Blue 3	000-255	0 - 100%	255
41	Blue 3 fine	000-255	0 - 100%	255
42	Red 4	000-255	0 - 100%	255
43	Red 4 fine	000-255	0 - 100%	255
44	Green 4	000-255	0 - 100%	255
45	Green 4 fine	000-255	0 - 100%	255
46	Blue 4	000-255	0 - 100%	255
47	Blue 4 fine	000-255	0 - 100%	255
...168	...Blue 24 fine	000-255	0 - 100%	255
169	Device Settings (please see remark *1)		According to our Device Settings chart RGB mode	0

remark 1: After adjustments please set the value back to 000 to avoid any disturbance by endless function call.

Device Setting RGB Modes

Ch.	Settings	DMX Value	Function	remark
	Device Settings (please see remark *1)	000-005	No function	
		6	Display Backlight On (hold 3s)	
		7	Display Backlight Off (hold 3s)	
		8	Display Lock On (hold 3s)	
		9	Display Lock Off (hold 3s)	
		010-014	reserved / no function	
		15	DMX Fail - Blackout (hold 3s)	
		16	DMX Fail - Hold (hold 3s)	
		17	DMX Fail - Emergency Light (hold 3s)	
		018-022	reserved / no function	
		23	Linear Dimmer Curve (hold 3s)	
		24	Exponential Dimmer Curve (hold 3s)	
		25	Logarithmic Dimmer Curve (hold 3s)	
		26	S-Curve Dimmer Curve (hold 3s)	
		027-031	reserved / no function	
		32	Dimmer Response LED / fast (hold 3s)	
		33	no function	
		34	Dimmer Respononse Halogen / slow (hold 3s)	
		035-039	reserved / no function	
		40	Calibration - High CRI (Colors & CCT / hold 3s)	
		41	Calibration - Normal CRI (Colors & CCT / hold 3s)	
		042-046	reserved / no function	
		47	LED Frequency 800Hz (hold 3s)	
		48	LED Frequency 1200Hz (hold 3s)	
		49	LED Frequency 2000Hz (hold 3s)	
		50	LED Frequency 3600Hz (hold 3s)	
		51	LED Frequency 12kHz (hold 3s)	
		52	LED Frequency 25kHz (hold 3s)	
		053-057	reserved / no function	
		58	Fan Auto 1 (hold 3s)	
		59	Fan Auto 2 (hold 3s)	
		60	Fan Silent (hold 3s)	
		61	Fan Studio (hold 3s)	
		62	Fan Off (hold 3s)	

Device Setting RGB Modes

		63	Fan High Power (hold 3s)	
		064-068	reserved / no function	
		69	Redshift On (hold 3s)	
		70	Redshift Off (hold 3s)	
		071-093	reserved / no function	
		94	Invert Mapping On (hold 3s)	
		95	Invert Mapping Off (hold 3s)	
		96-113	reserved / no function	
		114	Swap Mapping On (hold 3s)	
		115	Swap Mapping Off (hold 3s)	
		116-128	reserved / no function	
		129	LED Modes - Boost (hold 3s)	
		130	LED Modes - Illumination (hold 3s)	
		131-135	reserved / no function	
		136	Tilt Invert On (hold 3s)	
		137	Tilt Invert Off (hold 3s)	
		138-142	reserved / no function	
		143	Tilt Position Auto Correction On (hold 3s)	
		144	Tilt Position Auto Correction Off (hold 3s)	
		145-149	reserved / no function	
		150	Tilt Motor Disable On (hold 3s)	
		151	Tilt Motor Disable Off (hold 3s)	
		152-156	reserved / no function	
		157	Zoom Invert On (hold 3s)	
		158	Zoom Invert Off (hold 3s)	
		159-244	reserved / no function	
		245	Snapshot (hold 3s)	
		246-248	reserved / no function	
		249	User Reset (hold 3s)	No Change of DMX Address and Mode! / Reset activates only if Shutter is set to DMX 250
		250	Factory Reset (hold 3s)	No Change of DMX Address and Mode! / Reset activates only if Shutter is set to DMX 250
		251 - 255 reserved	No Function	

Device Setting DIRECT Modes

Ch.	Settings	DMX Value	Function	remark
	Device Settings (please see remark *1)	000-005	No function	
		6	Display Backlight On (hold 3s)	
		7	Display Backlight Off (hold 3s)	
		8	Display Lock On (hold 3s)	
		9	Display Lock Off (hold 3s)	
		010-014	reserved / no function	
		15	DMX Fail - Blackout (hold 3s)	
		16	DMX Fail - Hold (hold 3s)	
		17	DMX Fail - Emergency Light (hold 3s)	
		018-022	reserved / no function	
		23	Linear Dimmer Curve (hold 3s)	
		24	Exponential Dimmer Curve (hold 3s)	
		25	Logarithmic Dimmer Curve (hold 3s)	
		26	S-Curve Dimmer Curve (hold 3s)	
		027-031	reserved / no function	
		32	Dimmer Response LED / fast (hold 3s)	
		33	no function	
		34	Dimmer Respononse Halogen / slow (hold 3s)	
		035-039	reserved / no function	
		40	RAW mode (hold 3s)	
		41	User Calibration (hold 3s)	
		042-046	reserved / no function	
		47	LED Frequency 800Hz (hold 3s)	
		48	LED Frequency 1200Hz (hold 3s)	
		49	LED Frequency 2000Hz (hold 3s)	
		50	LED Frequency 3600Hz (hold 3s)	
		51	LED Frequency 12kHz (hold 3s)	
		52	LED Frequency 25kHz (hold 3s)	
		053-057	reserved / no function	
		58	Fan Auto 1 (hold 3s)	
		59	Fan Auto 2 (hold 3s)	
		60	Fan Silent (hold 3s)	
		61	Fan Studio (hold 3s)	
		62	Fan Off (hold 3s)	

Device Setting DIRECT Modes

Ch.	Settings	DMX Value	Function	remark
Device Settings (please see remark *1)		63	Fan High Power (hold 3s)	
		064-068	reserved / no function	
		69	Redshift On (hold 3s)	
		70	Redshift Off (hold 3s)	
		071-093	reserved / no function	
		94	Invert Mapping On (hold 3s)	
		95	Invert Mapping Off (hold 3s)	
		96-113	reserved / no function	
		114	Swap Mapping On (hold 3s)	
		115	Swap Mapping Off (hold 3s)	
		116-128	reserved / no function	
		129	LED Modes - Boost (hold 3s)	
		130	LED Modes - Illumination (hold 3s)	
		131-135	reserved / no function	
		136	Tilt Invert On (hold 3s)	
		137	Tilt Invert Off (hold 3s)	
		138-142	reserved / no function	
		143	Tilt Position Auto Correction On (hold 3s)	
		144	Tilt Position Auto Correction Off (hold 3s)	
		145-149	reserved / no function	
		150	Tilt Motor Disable On (hold 3s)	
		151	Tilt Motor Disable Off (hold 3s)	
		152-156	reserved / no function	
		157	Zoom Invert On (hold 3s)	
		158	Zoom Invert Off (hold 3s)	
		159-244	reserved / no function	
		245	Snapshot (hold 3s)	
		246-248	reserved / no function	
		249	User Reset (hold 3s)	No Change of DMX Address and Mode! / Reset activates only if Shutter is set to DMX 250
		250	Factory Reset (hold 3s)	No Change of DMX Address and Mode! / Reset activates only if Shutter is set to DMX 250
		251 - 255 reserved	No Function	

Color Macro Chart

Gels - Color Macros for Standalone Mode		
Position	Gel Name	Color Number
1	Red	100% Red LED
2	Fire	LEE 019
3	Medium Red	LEE 027
4	Primary Red	LEE 106
5	Med Amber	LEE 020
6	Dark Amber	LEE 022
7	Deep Amber	LEE 104
8	Orange	LEE 105
9	Deep Golden Amber	LEE 135
10	Yellow	LEE 101
11	Green	100% Green LED
12	Lime Green	LEE 088
13	Moss Green	LEE 089
14	LEE Green	LEE 121
15	Primary Green	LEE 139
16	Jas Green	LEE 738
17	Jade	LEE 323
18	Blue	100% Blue LED
19	Sky Blue	LEE 068
20	Tokyo Blue	LEE 071
21	Light Blue	LEE 118
22	Marine Blue	LEE 131
23	Med Blue	LEE 132
24	Congo Blue	LEE 181
25	Mikkel Blue	LEE 716
26	Rose Pink	LEE 002
27	Med Pink	LEE 036
28	Light Lavender	LEE 052

Gels - Color Macros for Standalone Mode		
Position	Gel Name	Color Number
29	Lavender	LEE 058
30	Magenta	LEE 113
31	Mauve	LEE 126
32	Smokey Pink	LEE 127
33	Special Med Lavender	LEE 343
34	Ultimate Violet	LEE 707
35	Magical Magenta	LEE 795
36	Chrysalis Pink	LEE 798
37	Specia KH Lavender	LEE 799
38	Bulb White	2700K / High CRI
39	Halogen White	3200K / High CRI
40	Neutral White	4200K / High CRI
41	Daylight White	5600K / High CRI
42	Cold White I	6000 / High CRI
43	Cold White II	6300K / High CRI
44	White (only if available)	100% White LED
45	Amber (only if available)	100% Amber LED
46	Lime (only if available)	100% Lime LED
47	Cyan (only if available)	100% Cyan LED

Pixel Charts

Standard



Invert




Swap



Invert/Swap



CTC channel
DMX / Color temperature



CTC-Chart

DMX (Step)	Color Temp (°K)	DMX (Step)	Color Temp (°K)	DMX (Step)	Color Temp (°K)	DMX (Step)	Color Temp (°K)	DMX (Step)	Color Temp (°K)	DMX (Step)	Color Temp (°K)
0	5600	43	2774	86	3649	129	4525	172	5400	215	6276
1	5600	44	2794	87	3670	130	4545	173	5421	216	6296
2	5600	45	2814	88	3690	131	4566	174	5441	217	6317
3	5600	46	2835	89	3710	132	4586	175	5462	218	6337
4	5600	47	2855	90	3731	133	4606	176	5482	219	6357
5	2000	48	2876	91	3751	134	4627	177	5502	220	6378
6	2020	49	2896	92	3771	135	4647	178	5523	221	6398
7	2041	50	2916	93	3792	136	4667	179	5543	222	6419
8	2061	51	2937	94	3812	137	4688	180	5563	223	6439
9	2081	52	2957	95	3833	138	4708	181	5584	224	6459
10	2102	53	2977	96	3853	139	4729	182	5604	225	6480
11	2122	54	2998	97	3873	140	4749	183	5624	226	6500
12	2143	55	3018	98	3894	141	4769	184	5645	227	6621
13	2163	56	3038	99	3914	142	4790	185	5665	228	6741
14	2183	57	3059	100	3934	143	4810	186	5686	229	6862
15	2204	58	3079	101	3955	144	4830	187	5706	230	6983
16	2224	59	3100	102	3975	145	4851	188	5726	231	7103
17	2244	60	3120	103	3995	146	4871	189	5747	232	7224
18	2265	61	3140	104	4016	147	4891	190	5767	233	7345
19	2285	62	3161	105	4036	148	4912	191	5787	234	7466
20	2305	63	3181	106	4057	149	4932	192	5808	235	7586
21	2326	64	3201	107	4077	150	4952	193	5828	236	7707
22	2346	65	3222	108	4097	151	4973	194	5848	237	7828
23	2367	66	3242	109	4118	152	4993	195	5869	238	7948
24	2387	67	3262	110	4138	153	5014	196	5889	239	8069
25	2407	68	3283	111	4158	154	5034	197	5910	240	8190
26	2428	69	3303	112	4179	155	5054	198	5930	241	8310
27	2448	70	3324	113	4199	156	5075	199	5950	242	8431
28	2468	71	3344	114	4219	157	5095	200	5971	243	8552
29	2489	72	3364	115	4240	158	5115	201	5991	244	8672
30	2509	73	3385	116	4260	159	5136	202	6011	245	8793
31	2529	74	3405	117	4281	160	5156	203	6032	246	8914
32	2550	75	3425	118	4301	161	5176	204	6052	247	9034
33	2570	76	3446	119	4301	162	5197	205	6072	248	9155
34	2590	77	3466	120	4342	163	5217	206	6093	249	9276
35	2611	78	3486	121	4362	164	5238	207	6113	250	9397
36	2631	79	3507	122	4382	165	5258	208	6133	251	9517
37	2652	80	3527	123	4403	166	5278	209	6154	252	9638
38	2672	81	3548	124	4423	167	5299	210	6174	253	9759
39	2692	82	3568	125	4443	168	5319	211	6195	254	9879
40	2713	83	3588	126	4464	169	5339	212	6215	255	10000
41	2733	84	3609	127	4484	170	5360	213	6235		
42	2753	85	3629	128	4505	171	5380	214	6256		

7.5 RDM Templates*

The ROXX NEO fx features support for various RDM functions. RDM (Remote Device Management) is a protocol enhancement to USITT DMX512 that allows bi-directional communication between the fixtures and the controller over a standard DMX line. This protocol will allow configuration, status monitoring and management. You will need a RDM controller to get control over the supported parameters. See the tables below for supported RDM features.

Label:	ROXX NEO fx
Model:	NEO fx
Manufacturer:	ROXX
ID:	6A6Ah
Device ID:	0136 xxxx

***Note: During RDM identifying process NEO fx flashes white to blue color alternately.**

RDM functions

For easy identifying ROXX NEO fx during RDM process the unit will jump from white color to blue color every second.

PID	Function	Action	Values
0x00F0	DMX Start Adress	Set	001-512
0x00E0	DMX Personality	Set	DMX modes
0x00E1	DMX Slots	Read	Channels
0x8010	Fan Mode	Set	1= Auto 1 / 2= Auto 2 / 3= Silent / 4= Studio / 5= Fan Off / 6= Max. Power
0x8030	Dimmer Curve	Set	1= Linear / 2= Exponential / 3= Logarithmic / 4= S-Curve
0x8031	Dimmer Response	Set	1= LED / 2= Halogen
0x8032	Redshift	Set	0= Off / 1= On
0x8033	Color Calibration	Set	0= Normal CRI / 1= High CRI
0x8034	RAW Balance	Set	0= RAW / 1= User Calibration
0x8035	User Calibration- Red	Set	000-255
0x8036	User Calibration- Green	Set	000-255
0x8037	User Calibration- Blue	Set	000-255
0x8038	User Calibration- Lime	Set	000-255
0x8040	LED Frequency (PWM)	Set	1= 800Hz / 2= 1200Hz / 3= 2000Hz / 4= 3600Hz / 5= 12kHz / 6= 25kHz
0x8041	Startup Mode	Set	0= DMX / 1= AUTO FX / 2= Editor / 3= Color Macro / 4= Quick Color / 5= Tunable White / 6= User Color
0x8011	DMX Fail	Set	1= Hold / 2= Blackout / 3= Emergency
0x8012	Display Backlight	Set	0= Off / 1= On
0x8013	Display Auto Flip	Set	0= Off / 1= On
0x8017	Display Lock	Set	0= Off / 1= On
0x8018	CRMX Operating Mode	Set	0= RX / 1= TX
0x8019	CRMX Receive Reset	Set	0= No / 1= Yes
0x801A	CRMX Transmit Link	Set	0= No / 1= Yes
0x801B	CRMX Pass to DMX out	Set	0= No / 1= Yes
0x801C	Bluetooth	Set	0= Off / 1= On
0x801D	Bluetooth Link	Set	0= No / 1= Yes
0x8048	Protocol	Set	1=DMX / 2= Artnet / 3=sACN / 4=Slave
0x8045	Invert Pixel Mapping	Set	0= Off / 1= On

PID	Function	Action	Values
0x8049	Swap Pixel Mapping	Set	0= Off / 1= On
0x0601	Tilt Invert	Set	0= Off / 1= On
0x804C	Tilt Position Auto Correction	Set	0= Off / 1= On
0x804D	Tilt Motor Disable	Set	0= Off / 1= On
0x804E	Zoom Invert	Set	0= Off / 1= On
0x804F	LED Mode	Set	0= Illumination / 1= Boost
0x801E	Factory Reset	Set	0= No / 1= Yes
0x801F	User Reset	Set	0= No / 1= Yes
0x00C0	Firmware Version	Read	n.a.
0x0082	Serial Number	Read	n.a.
0x0400	Device Power on Time	Read	n.a.
0x0401	LED on Time	Read	n.a.
Sensor1	LED Temperature	Read	n.a.
Sensor2	Fan Speed	Read	n.a.

* For more and detailed information about the different reset options please refer to chapter "5.4.6.1 Reset functions"

Sensors

RDM enables various readouts for remote device monitoring. See the table below for sensors and sensor types. Please note: The RDM controller communicates with the fixtures to show only the available sensors for this fixture. The table is subject to change without notice.

Name	
Temperature	xx°C / xxx°F
Software Version	SW-Version
Errors	

8. TROUBLESHOOTING

Did you try turning the device off and on again?

Problem	Reason	Solution
Device is not responding.	No power.	Check cable connections and conform that power is switched on.
	Fuse defect.	Contact your qualified service technician / manufacturer.
Device has turned off.	Power failure or power was turned off.	Check power supply, fuse, connections, switches.
Device has stopped responding.	DMX cable correct?	Check cables.
	Wireless connection got cut off.	Check wireless transmitter and connection signals.
Device operates strangely.	DMX cable inverted (pins correct?)	Use a phase inverter or different cables.
	DMX cable terminated?	If not, install DMX termination at the end of the cable.
	Stand Alone program running?	Stop internal Stand Alone.
No Bluetooth Connectivity	No Bluetooth Connectivity	Please make sure your mobile device is inside the connectivity range of maximum 10-15m.
	Bluetooth is disabled at your mobile device	Please enable Bluetooth at your mobile device settings.
	Mobile device has wrong Bluetooth Pin	Please use same Bluetooth Pin to connect ROXX APP with the fixture. Current BLE Pin can be read out inside fixture's wireless DMX settings.
	Mobile device has different Bluetooth connectivity	As only one Bluetooth connectivity can be active, please make sure your mobile device is currently not connected to some other devices.
	Different mobile device is still connected to the fixture	Please disconnect other mobile device from fixture.
	No Bluetooth Advertisement	Please send new BLE advertisement by enable "BLE Link" inside Settings of the fixture.
	Bluetooth module has hang up	Please enable Factory Reset at the fixture to re-start the Bluetooth module.

9. MANUFACTURER'S DECLARATION

Manufacturer's Warranty & Limitations of Liability

Please find our warranty conditions and limitations of liability inside our manufacturer's declaration at www.roxxlight.com/support

Requesting Warranty-Service

To request warranty service for your product, please contact:

ROXX GmbH,

Hansestr. 91, 51149 Köln

Email: info@roxxlight.com or the ROXX authorized reseller in your country, from where you purchased your product.

Correct Disposal of this product



This is for the European Union and European countries with electrical waste collection systems. When this label is shown on the product or brochure it means that the item cannot be disposed with household waste. In order to

prevent damage to the environment or human health please do not dispose this product uncontrolled. Make sure to act responsible, recycle this product separately from other types of waste to enable lasting reuse of resources. Private users please contact the retailer where you purchased this product or your local authorities to find out where and how proper recycling of this item is possible. Business users please contact your supplier or check the terms and conditions of your purchasing contract. Make sure not to mix this product with other commercial waste.

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

The equipment complies with FCC Radiation exposure limits set forth for uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

CE Compliance

The equipment marketed by ROXX GmbH complies (where applicable) with the essential requirements and other specifications of the following Directives:

- 2014/53/EU (RED)
- 2014/30/EU (EMC)
- 2014/35/EU (LVD)
- 2011/65/EU (RoHS)

The complete EU- and UK-Declaration of Conformity can be found at www.roxxlight.com/support, or you can also request it at info@roxxlight.com

