Lenovo 10w User Guide



Read this first

Before using this documentation and the product it supports, ensure that you read and understand the following:

- Safety and Warranty Guide
- Setup Guide
- Generic Safety and Compliance Notices

First Edition (March 2022)

© Copyright Lenovo 2022.

LIMITED AND RESTRICTED RIGHTS NOTICE: If data or software is delivered pursuant to a General Services Administration "GSA" contract, use, reproduction, or disclosure is subject to restrictions set forth in Contract No. GS-35F-05925.

Contents

Discover your Lenovo tablet iii	Enter the UEFI BIOS setup utility 17
	Change the startup sequence
Chapter 1. Meet your tablet 1	Change the hotkey mode
Overview	Enable or disable the Always On USB
Specifications	function
USB specifications 2	Use passwords
	Password types
Chapter 2. Get started with your	Set an administrator password 18
tablet	Change or remove the administrator
Access networks	password
Connect to Wi-Fi networks 5	Set a user password
Interact with your tablet 5	Change or remove the user password 18
Connect to an external display 5	Enable the power on password 19
Lenovo 10w Detachable Keyboard (for	Set a hard disk password 19
selected models) 6	Change or remove the hard disk password 19
Use the touch screen 9	Install a Windows operating system and drivers 20
Use Lenovo Integrated Pen (for selected models)	Use firewalls programs
Pen dummy (for selected models) 11	Chapter 5. Help and support 23
Chanter 2 Evalera vevr tablet 42	Frequently asked questions
Chapter 3. Explore your tablet 13	Self-help resources
Use the Vantage app	Windows label
Manage power	What are CRUs
Check the battery status	Call Lenovo
Charge the battery	Before you contact Lenovo
Change the power settings	Lenovo Customer Support Center
Manage the disk	Lenovo Gustomer Support Genter
Transfer data	Appendix A. Compliance
Set up a Bluetooth connection	information 29
Chapter 4. Configure advanced	Appendix B. Notices and
settings 17	trademarks
UEFI BIOS setup utility	

Discover your Lenovo tablet

Thank you for choosing a Lenovo® tablet! We are dedicated to delivering the best solution to you.

Before starting your tour, please read the following information:

- Illustrations in this documentation might look different from your product.
- Depending on the model, some optional accessories, features, software programs, and user interface instructions might not be applicable to your tablet.
- Documentation content is subject to change without notice. To get the latest documentation, go to https://pcsupport.lenovo.com.

Chapter 1. Meet your tablet

Overview



*	Lenovo Integrated Pen*	<u></u>	Microphone
Ô	Camera	<u></u>	Webcam privacy shutter
<u>*</u>	Touch screen	Ф	Power button
□7,	Volume button	0	Audio connector
Ģ	Power connector / USB-C® 3.2 connector Gen 1	J ®	Speakers
	Pogo interface connector		

^{*} for selected models

Webcam privacy shutter

Slide the webcam privacy shutter to cover or uncover the camera lens. It is designed to protect your privacy.

Related topics

- "USB specifications" on page 2
- "Use the touch screen" on page 9
- "Use Lenovo 10w Detachable Keyboard(for selected models)" on page 7
- "Use Lenovo Integrated Pen (for selected models)" on page 10
- "Charge the battery" on page 13





Rear Camera

Specifications

For detailed specifications of your tablet, go to https://psref.lenovo.com and search by product.

Memory	LPDDR4X, soldered on board, up to 8 GB		
Storage device	Embedded Multi Media Card (eMMC), up to 128 GB		
Display	 Color display with In-Plane Switching (IPS) technology Display ratio: 16:10 Display resolution: 1200 x 1920 pixels Multi-touch technology 		
Security features	Firmware Trusted Platform Module (fTPM) (for selected models)		
Wireless features	Bluetooth Wireless LAN		

USB specifications

Note: Depending on the model, some USB connectors might not be available on your tablet.

Description



Connect USB-compatible devices, such as a USB keyboard, USB mouse, USB storage device, or USB printer.

- USB 2.0 connector
- SS USB 3.2 connector Gen 1
- 10 USB 3.2 connector Gen 2



- USB-C (3.2 Gen 1) connector
- USB-C (3.2 Gen 2) connector
- USB-C (Thunderbolt 3) connector
- USB-C (Thunderbolt 4) connector
- USB-C
- USB 4 connector

- · Charge USB-C compatible devices with the output voltage and current of 5 V and 3 A.
- Connect to an external display:
 - USB-C to VGA: up to 1920 x 1200 pixels, 60 Hz
 - USB-C to DP: up to 2560 x 1440 pixels, 60 Hz
- Connect to USB-C accessories to help expand your tablet functionality. To purchase USB-C accessories, go to https:// www.lenovo.com/accessories.

Statement on USB transfer rate

Depending on many factors such as the processing capability of the host and peripheral devices, file attributes, and other factors related to system configuration and operating environments, the actual transfer rate using the various USB connectors on this device will vary and will be slower than the data rate listed below for each corresponding device.

USB device	Data rate (Gbit/s)	
3.2 Gen 1 / 3.1 Gen 1	5	
3.2 Gen 2 / 3.1 Gen 2	10	
3.2 Gen 2 × 2	20	
4 Gen 2 × 2	20	
4 Gen 3 × 2	40	
Thunderbolt 3	40	
Thunderbolt 4	40	


Chapter 2. Get started with your tablet

Access networks

This section helps you connect to a wireless or wired network.

Connect to Wi-Fi networks

Click the network icon in the Windows® notification area, and then select a network for connection. Provide required information, if needed.



Interact with your tablet


Your tablet provides you various ways to navigate the screen.

Connect to an external display

Connect your tablet to a projector or a monitor to give presentations or expand your workspace.

Connect to a wired display

If your tablet cannot detect the external display, right-click a blank area on the desktop and select display settings. Then follow the on-screen instructions to detect the external display.



© Copyright Lenovo 2022 5

Supported resolution

The following table lists the supported maximum resolution of the external display.


Connect the external display to	Supported resolution
USB-C (3.2 Gen1) connector	Up to 2560 x 1440 pixels / 60 Hz

Connect to a wireless display

To use a wireless display, ensure that both your tablet and the external display support the Miracast® feature.

Press Windows logo key + K and then select a wireless display to connect with.

Set the display mode



Change display settings


- 1. Right-click a blank area on the desktop and select display settings.
- 2. Select the display that you want to configure and change display settings of your preference.

You can change the settings for both the tablet display and the external display. For example, you can define which one is the main display and which one is the secondary display. You also can change the resolution and orientation.

Lenovo 10w Detachable Keyboard (for selected models)

Depending on the model, your tablet might come with a Lenovo 10w Detachable Keyboard (referred to as keyboard). Attach the keyboard to your tablet so that you can transform your tablet into a portable notebook computer.

Overview



Use Lenovo 10w Detachable Keyboard(for selected models)

Attach your tablet in the keyboard folio

Align the keyboard guide pins with the tablet guide pin connectors in the direction shown by the arrows. When the keyboard gets close enough, it magnetically attaches to your tablet. Then, you can adjust the tablet to your preferred viewing angle (within 180 degrees).





To detach your computer, you can easily remove the keyboard by pulling it away.

Use Hotkeys

Some keys on the keyboard are printed with icons. These keys are called hotkeys and can be pressed alone or in combination with the Fn key to access certain functions or settings quickly. The functions of hotkeys are symbolized by the icons printed on them.

Hotkey	Function
	Mute / unmute the speakers.
M	If you mute the speakers and turn off your tablet, the speakers remain muted when you turn on your tablet.
4 -/ 4 +	Decrease / increase the volume.
×	Mute / unmute the microphones.
C	Refresh the current window.
E	Enable / disable the touchpad.
+	Turn on / turn off the airplane mode.
Ħ	Open the Windows Calculator.
А	Lock the current user account.
₽ ■	Manage external displays.
☆- / ☆+	Decrease / increase display brightness.
Fn +	Equal the Home key.

Use the hotkey mode

Some hotkeys share keys with functions keys (F1 to F12). The hotkey mode is a UEFI BIOS setting that changes how hotkeys (or function keys) are used.

- When the hotkey mode is enabled, press Fn together with the hotkey to use the hotkey.
- When the hotkey mode is disabled, press the hotkey directly.

Use the touch screen

If your tablet display supports the multi-touch function, you can navigate the screen with simple touch gestures. For more touch gestures, refer to https://support.microsoft.com/windows

Note: Some gestures might not be available depending on the app you use.



Tap once to single click



Tap and hold to right-click



Zoom out



Tap twice quickly to double-click



Slide to scroll through items



Zoom in



Swipe from the left: view all open windows (Windows 10)

Swipe from the left: open widget panel (Windows 11)




Swipe from the right: open action center (Windows 10)

Swipe from the right: open notification center (Windows 11)



Drag



Swipe downwards shortly: show title bar


Swipe downwards: close the current app

Maintenance tips:

- Turn off the tablet before cleaning the multi-touch screen.
- Use a dry, soft, and lint-free cloth or a piece of absorbent cotton to remove fingerprints or dust from the multi-touch screen. Do not apply solvents to the cloth.
- The multi-touch screen is a glass panel covered with a plastic film. Do not apply pressure or place any metallic object on the screen, which might damage the touch panel or cause it to malfunction.
- Do not use fingernails, gloved fingers, or inanimate objects for input on the screen.
- Regularly calibrate the accuracy of the finger input to avoid a discrepancy.

Use Lenovo Integrated Pen (for selected models)

The following information refers to the Lenovo Integrated Pen, model: WG 13. The garaged rechargeable electronic Lenovo Integrated Pen enables a more precise and easier way of writing and sketching.



Note: The default function of each button might vary in different applications.

Lenovo Integrated Pen is not waterproof. Keep the pen away from water and excessive moisture. To purchase Lenovo Integrated Pen, go to https://www.lenovo.com/accessories.

Charge Lenovo Integrated Pen

- 1. Ensure that your tablet is on or in sleep mode.
- 2. Insert the pen back into the pen slot. The pen is 80% charged in about 15 seconds and 100% charged in about five minutes.



Set Lenovo Integrated Pen

You can configure the Lenovo Integrated Pen in Lenovo Pen Settings. Do as following to configure your pen:

- 1. To download the latest version of Lenovo Pen Settings, go to http://www.wacomeng.com.
- 2. Install and open Lenovo Pen Settings.
- 3. Configure the settings as you prefer.

Pen dummy (for selected models)

Depending on models, your tablet might come with a pen dummy. If you need replace the pen dummy with a Lenovo integrated pen, do as following to remove it:

Prerequisite

Before you start, read <u>Generic Safety and Compliance Notices</u> and print the following instructions.

Removal procedure

Use a tool as shown to release the pen dummy, then remove it.



Chapter 3. Explore your tablet

Use the Vantage app

The preinstalled Vantage app is a customized one-stop solution to help you maintain your tablet with automated updates and fixes, configure hardware settings, and get personalized support.

To access the Vantage app, type Vantage in the Windows search box.

Key features

The Vantage app enables you to:

- Know the device status easily and customize device settings.
- Download and install UEFI BIOS, firmware, and driver updates to keep your tablet up-to-date.
- Look up warranty status (online).
- Access User Guide.

Notes:

- The available features vary depending on the tablet model.
- The Vantage app makes periodic updates of the features to keep improving your experience with your tablet. The description of features might be different from that on your actual user interface.

Manage power

Use the information in this section to achieve the best balance between performance and power efficiency.

Check the battery status

Go to **Settings** → **System** to check the battery status. For more details about your battery, refer to the Vantage app.

Charge the battery

Power source of the ac power adapter:

- Power: 45 W
- Sine-wave input at 50 Hz to 60 Hz
- Input rating of the ac power adapter: 100 V to 240 V ac, 50 Hz to 60 Hz

When the battery power is low, charge your battery by connecting your tablet to ac power. The actual charging time depends on the battery size, the physical environment, and whether you are using the tablet.



Notes: To maximize the life of the battery:

- Use the battery until the charge is depleted and recharge the battery completely before using it. Once the battery is fully charged, it must discharge to 94% or lower before it will be allowed to recharge again.
- The battery may optimize its full charge capacity based on your usage. After prolonged periods of limited
 use, full battery capacity may not be available until you discharge to as low as 20% and recharge
 completely. For more information, refer to the power section of the Vantage app.

Change the power settings

For ENERGY STAR® compliant tablets, the following power plan takes effect when your tablet has been idle for a specified duration:

- Turn off the display: After 10 minutes
- Put the tablet to sleep: After 10 minutes

To reset the power plan:

- 1. Go to Control Panel and view by Large icons or Small icons.
- 2. Click Power Options.
- 3. Choose or customize a power plan of your preference.

To reset the power button function:

- 1. Go to Control Panel and view by Large icons or Small icons.
- 2. Click **Power Options**, and then click **Choose what the power buttons do** on the left pane.
- 3. Change the settings as you prefer.

Manage the disk

Attention: Lenovo 10w has quantities of partitions with BIOS and firmware stored in them in Disk Management. Do not install or use third-party Disk Management tool to delete or modify the partitions. Otherwise the device system will not start up normally in next startup, and constantly stays in black screen.

Transfer data

Quickly share your files using the built-in Bluetooth technology among devices with the same features.

Set up a Bluetooth connection

You can connect all types of Bluetooth-enabled devices to your tablet, such as a keyboard, a mouse, a smartphone, or speakers. To ensure successful connection, place the devices at most 10 meters (33 feet) from the tablet.

- 1. Type Bluetooth in the Windows search box and then press Enter.
- 2. Turn on Bluetooth, if it is off.
- 3. Select a Bluetooth device, and then follow the on-screen instructions.

Chapter 4. Configure advanced settings

UEFI BIOS setup utility

UEFI BIOS setup utility is the first program that the tablet runs. When the tablet turns on, UEFI BIOS setup utility performs a self test to make sure that various devices in the tablet are functioning.

Enter the UEFI BIOS setup utility

Restart the tablet. When the logo screen is displayed, press F2 to enter the UEFI BIOS setup utility.

Change the startup sequence

You might need to change the startup sequence to allow the tablet to start from another device or a network location.

- 1. Enter the setup utility.
- 2. Navigate to the Boot menu.
- 3. Follow the on-screen instructions to change the order of devices under Boot Priority Order.

Note: You can also change the startup sequence temporarily without opening the setup utility. To do so, start the tablet. When the logo screen is displayed, press F12.

Change the hotkey mode

- 1. Open the setup utility.
- 2. Select Configuration → Hotkey Mode and press Enter.
- 3. Change the setting to **Disabled** or **Enabled**.
- Select Exit → Exit Saving Changes.

Enable or disable the Always On USB function

For tablet models with the Always On USB connector, the always-on function can be enabled or disabled in the setup utility.

- 1. Open the setup utility.
- Select Configuration → Always On USB and press Enter.
- 3. Change the setting to **Disabled** or **Enabled**.
- Select Exit → Exit Saving Changes.

Use passwords

This section introduces the types of passwords that you can set in the setup utility.

Password types

You can set various types of passwords in the UEFI BIOS setup utility.

Notes:

- All passwords set in the setup utility consist of alphanumeric characters only.
- If you start the setup utility using the user password, you can only change a few settings.

Password type Pre-requisite		Usage	
Administrator password	No	Use the administrator password to enter the setup utility.	
User password	The administrator password must be set.	Use the user password to enter the setup utility.	

Set an administrator password

You can set the administrator password to prevent unauthorized access to the setup utility.

Attention: If you forget the administrator password, a Lenovo authorized service personnel cannot reset your password. You must take your tablet to a Lenovo authorized service personnel to have the system board replaced. Proof of purchase is required and a fee will be charged for parts and service.

- 1. Enter the setup utility.
- 2. Select Security → Set Administrator Password and press Enter.
- 3. Enter a password string that contains only lower case letters and numbers and then press Enter.
- 4. Enter the password again and press Enter.
- 5. Select Exit → Exit Saving Changes.

Next time you turn on the tablet, you should enter the administrator password to enter the setup utility.

Change or remove the administrator password

Only the administrator can change or remove the administrator password.

- 1. Enter the setup utility.
- 2. Select Security → Set Administrator Password and press Enter.
- 3. Enter the current password.
- 4. In the **Enter New Password** field, enter the new password.
- 5. In the **Confirm New Password** field, enter the new password again.

Note: If you want to remove the password, leave both fields blank, and press Enter twice.

6. Select Exit → Exit Saving Changes.

If you remove the administrator password, the user password is also removed.

Set a user password

You must set the administrator password before you can set the user password. The system administrator might need to set a user password so that other users can access the tablet.

- 1. Enter the setup utility.
- 2. Select **Security** → **Set User Password** and press Enter.
- 3. Enter a password string that contains only letters and numbers and then press Enter.

Note: The user password should be different from the administrator password.

- 4. Enter the password again and press Enter.
- 5. Select Exit → Exit Saving Changes.

Change or remove the user password

1. Enter the setup utility.

- 2. Select **Security** → **Set User Password** and press Enter.
- 3. Enter the current password.
- 4. In the **Enter New Password** field, enter the new password.
- 5. In the Confirm New Password field, enter the new password again.

Note: If you want to remove the password, select **Security → Clear User Password** and press Enter.

Select Exit → Exit Saving Changes.

Enable the power on password

If the administrator password has been set, you can enable the power on password to enforce stronger security.

- 1. Enter the setup utility.
- Select Security → Power-on Password and press Enter.

Note: The administrator password must be set in advance.

- 3. Change the setting to **Enabled**.
- 4. Select Exit → Exit Saving Changes.

If the power on password is enabled, you must enter the administrator password or user password every time you enter the setup utility.

Set a hard disk password

You can set a hard disk password in the setup utility to prevent unauthorized access to your data.

Attention: Be extremely careful when setting a hard disk password. If you forget the master hard disk password, a Lenovo authorized service personnel cannot reset your password or recover data from the hard disk. You must take your tablet to a Lenovo authorized service personnel to have the hard disk drive replaced. Proof of purchase is required and a fee will be charged for parts and service.

Notes:

- If you start the setup utility using the user password, you cannot set the hard disk password.
- The master hard disk password and user hard disk password must be set at the same time.
- 1. Enter the setup utility.
- 2. Select Security → Set Hard Disk Password and press Enter.
- Follow the on-screen instructions to set both the master hard disk password and user hard disk password.
- Select Exit → Exit Saving Changes.

If the hard disk password is set, you must enter the password to enter the setup utility or the operating system.

Change or remove the hard disk password

- 1. Enter the setup utility.
- 2. Select Security.
- 3. To change or remove the hard disk password, do one of the following:
 - To change or remove the master hard disk password, select Change Master Password and press Enter.

Notes:

- If you remove the master hard disk password, the user hard disk password is also removed.
- The user hard disk password cannot be removed separately.
- To change the user hard disk password, select Change User Password and press Enter.
- 4. Select Exit → Exit Saving Changes.

Install a Windows operating system and drivers

This section provides instructions on installing a Windows operating system and device drivers.

Install a Windows operating system

Microsoft constantly makes updates to the Windows operating system. Before installing a particular Windows version, check the compatibility list for the Windows version. For details, go to https:// support.lenovo.com/us/en/solutions/windows-support.

Attention:

- · It is recommended that you update your operating system through official channels. Any unofficial update might cause security risks.
- The process of installing a new operating system deletes all the data on your internal storage drive, including the data stored in a hidden folder.
- 1. If you are using the Windows BitLocker® Drive Encryption feature and your tablet has a Trusted Platform Module, ensure that you have disabled the feature.
- 2. Ensure that the security chip is set to **Enabled**.
 - a. Restart the tablet. When the logo screen is displayed, press F2 to enter the setup utility.
 - b. Select **Security** and ensure security chip is set to **Enabled**.
 - c. Press F10 to save the settings and exit.
- 3. Connect the drive that contains the operating system installation program to the tablet.
- 4. Restart the tablet. When the logo screen is displayed, press F2 to enter the setup utility.
- 5. Select Boot → Edit Boot Order to display the Boot Priority Order submenu.
- 6. Select the drive that contains the operating system installation program, for example, **USB HDD**. Press F6 to move the drive to the first order. Then, press F10 to save the setting and exit.

Attention: After you change the startup sequence, ensure that you select the correct device during a copy, a save, or a format operation. If you select the wrong device, the data on that device might be erased or overwritten.

- 7. The system restarts. Follow the on-screen instructions to install the device drivers and necessary programs.
- 8. After installing the device drivers, apply Windows Update to get the latest updates, for example the security patches.

Install device drivers

You should download the latest driver for a component when you notice poor performance from that component or when you added a component. This action might eliminate the driver as the potential cause of a problem. Download and install the latest driver by one of the following methods:

- Open the Vantage app to check the available update packages. Select the update packages you want, and then follow the on-screen instructions to download and install the packages.
- Go to https://pcsupport.lenovo.com and select the entry for your tablet. Then, follow the on-screen instructions to download and install necessary drivers and software.

Use firewalls programs

Your tablet might be preinstalled with a firewall program. The firewall protects against tablet Internet security threats, unauthorized access, intrusions, and Internet attacks. It also protects your privacy.

For more information, see the help system of the program.

Chapter 5. Help and support

Frequently asked que	stions		
How do I open the Control Panel?	? Type Control Panel in the Windows search box and then press Enter.		
How should I turn off my tablet?	Open the Start menu and select Power → Shut down .		
How do I partition my storage drive?	Refer to https://support.lenovo.com/solutions/ht503851.		
What should I do if my tablet stops responding?	Press and hold the power button until the tablet turns off. Then restart the tablet.		
What should I do if I spill liquid on the tablet?	 Carefully unplug the ac power adapter and turn off the tablet immediately. The more quickly you stop the current from passing through the tablet the more likely you will reduce damage from short circuits. Attention: Although you might lose some data or work by turning off the tablet immediately, leaving the tablet on might make your tablet unusable. Wait until you are certain that all the liquid is dry before turning on your tablet. CAUTION: Do not try to drain out the liquid by turning over the tablet. If your tablet has keyboard drainage holes on the bottom, the liquid will be drained out through the holes. 		
Where can I get the latest device drivers and UEFI BIOS?	 The Vantage app Lenovo Support Web site at https://support.lenovo.com 		
How do I disinfect my tablet?	 Squeeze out excess liquid from wipe or disinfecting cloth before using. Recommended wipes are hydrogen peroxide wipes and alcohol based wipes. Do not use wipes containing sodium hypochlorite (bleach). Gently wipe the tablet thoroughly, being careful to ensure no liquid drips into the tablet. Do not wipe on connector pins. After disinfecting, follow the cleaning procedure from the wipe supplier to minimize chemical buildup of disinfectant residue. 		

4. Always allow the tablet to completely dry prior to any use.

© Copyright Lenovo 2022 23

Self-help resources

Use the following self-help resources to learn more about the tablet and troubleshoot problems.

Resources	How to access?		
Troubleshooting and FAQ	https://www.lenovo.com/tips		
Ç	https://forums.lenovo.com		
Accessibility information	https://www.lenovo.com/accessibility		
	Use Lenovo recovery options.		
	Go to https://support.lenovo.com/ HowToCreateLenovoRecovery.		
	2. Follow the on-screen instructions.		
	Use Windows recovery options.		
Reset or restore Windows	1. Go to https://pcsupport.lenovo.com .		
	Detect your tablet or manually select your tablet model.		
	 Click Diagnostics → Operating System Diagnostics and then follow the on-screen instructions. 		
Use the Vantage app to:			
Configure device settings.			
• Download and install UEFI BIOS, drivers, and firmware updates.	Type Vantage in the Windows search box and then press		
Secure your tablet from outside threats.	Enter.		
Diagnose hardware problems.			
Check the tablet warranty status.			
Access User Guide and helpful articles.			
Product documentation:			
Safety and Warranty Guide			
Generic Safety and Compliance Notices	Go to https://pcsupport.lenovo.com . Then, follow the onscreen instructions to filter out the documentation you want.		
Setup Guide			
This User Guide			
Regulatory Notice			

Resources	How to access?		
Lenovo Support Web site with the latest support information of the following:			
Drivers and software			
Diagnostic solutions	https://pcsupport.lenovo.com		
Product and service warranty			
Product and parts details			
Knowledge base and frequently asked questions			
	Open the Start menu and click Get Help or Tips.		
Windows help information	 Use Windows Search or the Cortana® personal assistant. 		
	 Microsoft support Web site: https://support.microsoft.com 		

Windows label

Your tablet might have a Windows Genuine Microsoft label affixed to its cover depending on the following factors:

- Your geographic location
- Edition of Windows that is preinstalled

Go to https://www.microsoft.com/en-us/howtotell/Hardware.aspx for illustrations of the various types of Genuine Microsoft labels.

- In the People's Republic of China, the Genuine Microsoft label is required on all tablet models preinstalled with any edition of the Windows operating system.
- In other countries and regions, the Genuine Microsoft label is required only on tablet models licensed for Windows Pro editions.

The absence of a Genuine Microsoft label does not indicate that the preinstalled Windows version is not genuine. For details on how to tell whether your preinstalled Windows product is genuine, refer to the information provided by Microsoft at https://www.microsoft.com/en-us/howtotell/default.aspx.

There are no external, visual indicators of the Product ID or Windows version for which the tablet is licensed. Instead, the Product ID is recorded in the tablet firmware. Whenever a Windows product is installed, the installation program checks the tablet firmware for a valid, matching Product ID to complete the activation.

In some cases, an earlier Windows version might be preinstalled under the terms of the Windows Pro edition license downgrade rights.

What are CRUs

Customer Replaceable Units (CRUs) are parts that can be upgraded or replaced by the customer. The tablets contain the following types of CRUs:

- Self-service CRUs: Refer to parts that can be installed or replaced easily by customer themselves or by trained service technicians at an additional cost.
- Optional-service CRUs: Refer to parts that can be installed or replaced by customers with a greater skill level. Trained service technicians can also provide service to install or replace the parts under the type of warranty designated for the customer's machine.

If you intend on installing a CRU, Lenovo will ship the CRU to you. CRU information and replacement instructions are shipped with your product and are available from Lenovo at any time upon request. You might be required to return the defective part that is replaced by the CRU. When return is required: (1) return instructions, a prepaid shipping label, and a container will be included with the replacement CRU; and (2) you might be charged for the replacement CRU if Lenovo does not receive the defective CRU within thirty (30) days of your receipt of the replacement CRU. For full details, see the Lenovo Limited Warranty documentation at https://www.lenovo.com/warranty/llw_02.

Refer to the following CRU list for your tablet.

Self-service CRUs

- ac power adapter*
- Power cord*
- Lenovo 10w Detachable Keyboard*
- Lenovo Integrated Pen*
- Pen dummy*

Note: Replacement of any parts not listed above, including the built-in rechargeable battery, must be done by a Lenovo-authorized repair facility or technician. Go to https://support.lenovo.com/partnerlocation for more information.

Call Lenovo

If you have tried to correct the problem yourself and still need help, you can call Lenovo Customer Support Center.


Before you contact Lenovo

Prepare the following before you contact Lenovo:

- 1. Record the problem symptoms and details:
 - What is the problem? Is it continuous or intermittent?
 - Any error message or error code?
 - What operating system are you using? Which version?
 - Which software applications were running at the time of the problem?
 - Can the problem be reproduced? If so, how?
- 2. Record the system information:
 - Product name
 - Machine type and serial number

^{*} for selected models

The following illustration shows where to find the machine type and serial number of your tablet.



Lenovo Customer Support Center

During the warranty period, you can call Lenovo Customer Support Center for help.

Telephone numbers

For a list of the Lenovo Support phone numbers for your country or region, go to https:// pcsupport.lenovo.com/supportphonelist for the latest phone numbers.

Note: Phone numbers are subject to change without notice. If the number for your country or region is not provided, contact your Lenovo reseller or Lenovo marketing representative.

Services available during the warranty period

- Problem determination Trained personnel are available to assist you with determining if you have a hardware problem and deciding what action is necessary to fix the problem.
- Lenovo hardware repair If the problem is determined to be caused by Lenovo hardware under warranty, trained service personnel are available to provide the applicable level of service.
- Engineering change management Occasionally, there might be changes that are required after a product has been sold. Lenovo or your reseller, if authorized by Lenovo, will make selected Engineering Changes (ECs) that apply to your hardware available.

Services not covered

- Replacement or use of parts not manufactured for or by Lenovo or nonwarranted parts
- Identification of software problem sources
- Configuration of UEFI BIOS as part of an installation or upgrade
- Changes, modifications, or upgrades to device drivers
- Installation and maintenance of network operating systems (NOS)
- Installation and maintenance of programs

For the terms and conditions of the Lenovo Limited Warranty that apply to your Lenovo hardware product, go to:


- https://www.lenovo.com/warranty/llw 02
- https://pcsupport.lenovo.com/warrantylookup

Appendix A. Compliance information

For compliance information, refer to *Regulatory Notice* at https://pcsupport.lenovo.com and *Generic Safety and Compliance Notices* at https://pcsupport.lenovo.com/docs/generic_notices.

Locate the wireless antennas

Your tablet has a wireless antenna system. You can enable wireless communication wherever you are. The following illustrations show the antenna locations on your tablet.



Wireless-LAN antenna (auxiliary)

2 Wireless-LAN antenna (main)

Certification-related information

Product name	Compliance ID	Machine type	
Lenovo 10w LN0002W		82SU(Rx) and 82ST(Tx)	

Further compliance information related to your product is available at https://www.lenovo.com/compliance.

Operating environment

Maximum altitude (without pressurization)

3048 m (10 000 ft)

Temperature

Operating: 5°C to 35°C (41°F to 95°F)

• Storage: 5°C to 43°C (41°F to 109°F)

Note: When you charge the battery, its temperature must be no lower than 10°C (50°F).

Relative humidity

- Operating: 8% to 95% at wet-bulb temperature 23°C (73°F)
- Storage: 5% to 95% at wet-bulb temperature 27°C (81°F)

Appendix B. Notices and trademarks

Notices

Lenovo may not offer the products, services, or features discussed in this document in all countries. Consult your local Lenovo representative for information on the products and services currently available in your area. Any reference to a Lenovo product, program, or service is not intended to state or imply that only that Lenovo product, program, or service may be used. Any functionally equivalent product, program, or service that does not infringe any Lenovo intellectual property right may be used instead. However, it is the user's responsibility to evaluate and verify the operation of any other product, program, or service.

Lenovo may have patents or pending patent programs covering subject matter described in this document. The furnishing of this document does not give you any license to these patents. You can send license inquiries, in writing, to:

Lenovo (United States), Inc. 8001 Development Drive Morrisville, NC 27560 U.S.A.

Attention: Lenovo Director of Licensing

LENOVO PROVIDES THIS PUBLICATION "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Some jurisdictions do not allow disclaimer of express or implied warranties in certain transactions, therefore, this statement may not apply to you.

Changes are made periodically to the information herein; these changes will be incorporated in new editions of the publication. To provide better service, Lenovo reserves the right to improve and/or modify the products and software programs described in the manuals included with your tablet, and the content of the manual, at any time without additional notice.

The software interface and function and hardware configuration described in the manuals included with your tablet might not match exactly the actual configuration of the tablet that you purchase. For the configuration of the product, refer to the related contract (if any) or product packing list, or consult the distributor for the product sales. Lenovo may use or distribute any of the information you supply in any way it believes appropriate without incurring any obligation to you.

The products described in this document are not intended for use in implantation or other life support applications where malfunction may result in injury or death to persons. The information contained in this document does not affect or change Lenovo product specifications or warranties. Nothing in this document shall operate as an express or implied license or indemnity under the intellectual property rights of Lenovo or third parties. All information contained in this document was obtained in specific environments and is presented as an illustration. The result obtained in other operating environments may vary.

Lenovo may use or distribute any of the information you supply in any way it believes appropriate without incurring any obligation to you.

Any references in this publication to non-Lenovo Web sites are provided for convenience only and do not in any manner serve as an endorsement of those Web sites. The materials at those Web sites are not part of the materials for this Lenovo product, and use of those Web sites is at your own risk.

Any performance data contained herein was determined in a controlled environment. Therefore, the result obtained in other operating environments may vary significantly. Some measurements may have been made on development-level systems and there is no guarantee that these measurements will be the same on generally available systems. Furthermore, some measurements may have been estimated through extrapolation. Actual results may vary. Users of this document should verify the applicable data for their specific environment.

This document is copyrighted by Lenovo and is not covered by any open source license, including any Linux agreement(s) which may accompany software included with this product. Lenovo may update this document at any time without notice.

For the latest information or any questions or comments, contact or visit the Lenovo Web site:

https://pcsupport.lenovo.com

Trademarks

LENOVO and LENOVO logo are trademarks of Lenovo. ENERGY STAR and the ENERGY STAR mark are registered trademarks owned by the U.S. Environmental Protection Agency. Microsoft, Windows, BitLocker, and Cortana are trademarks of the Microsoft group of companies. The terms HDMI and HDMI High-Definition Multimedia Interface are trademarks or registered trademarks of HDMI Licensing LLC in the United States and other countries. Wi-Fi, Wi-Fi Alliance, and Miracast are registered trademarks of Wi-Fi Alliance. USB-C® is a registered trademark of USB Implementers Forum. All other trademarks are the property of their respective owners.

Lenovo