

Statement

Copyright © 2008 by AUTOBOSS TECH. INC. (short for "AUTOBOSS"). All rights reserved. No part of this publication can be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording or otherwise, without the prior written permission of AUTOBOSS. The information contained herein is designed only for the use of this unit. AUTOBOSS is not responsible for any use of this information as applied to other units.

Neither AUTOBOSS nor its affiliates shall be liable to the purchaser of this unit or third parties for damages, losses, costs, or expenses incurred by purchaser or third parties as a result of: accident, misuse, or abuse of this unit, or unauthorized modifications, repairs, or alterations to this unit, or failure to strictly comply with AUTOBOSS operating and maintenance instructions.

AUTOBOSS shall not be liable for any damages or problems arising from the use of any options or any consumable products other than those designated as Original AUTOBOSS Products or AUTOBOSS Approved Products by AUTOBOSS.

General Notice: Other product names used herein are for identification purposes only and may be trademarks of their respective owners. AUTOBOSS disclaims any and all rights in those marks.

The V-30 Diagnostic Computer can only be operated by qualified technicians.

Trade mark

AUTOBOSS is a registered trademark of AUTOBOSS TECH. INC. (short for AUTOBOSS) in China and other countries. All other AUTOBOSS trademarks, service marks, domain names, logos, and company names referred to in this manual are either trademarks, registered trademarks, service marks, domain names, logos, company names of or are otherwise the property of AUTOBOSS or its affiliates. In countries where any of the AUTOBOSS trademarks, service marks, domain names, logos and company names is not registered, AUTOBOSS claims other rights associated with unregistered trademarks, service marks, domain names, logos, and company names. Other products or company names referred in this manual may be trademarks of their respective owners. You may not use any trademark, service mark, domain name, logo, or company name of AUTOBOSS or any third party without permission from the owner of the applicable trademark, service mark, domain name, logo, or company name.

V30 ELITE User Manual instructions

- Please read this user manual carefully before using the scanner.
- The current user manual is based on the current features and functions available. Any new added features and functions of V30 ELITE Diagnostic Computer will be added to the user manual in the future. Updated versions of user manual will be available to download at AUTOBOSS website (<http://www.AUTOBOSS.net>).
- When reading the manual, please pay special attention to the words “Note”, “Caution” or “Warning”, read them carefully for appropriate operation.

V30 ELITE Diagnostic Computer main unit maintenance:

- Avoid shaking or dismantling as it may damage the internal components;
- Do not use hard or sharp objects to touch the LCD screen; do not use excessive force; do not expose the screen to strong sunlight for a long period;
- Caution: keep it away from water, moisture, high temperature or very low temperature;
- If necessary, calibrate the screen before testing to ensure the accuracy of LCD performance;
- Keep the main unit away from strong magnetic fields.

Operation Instructions

- For safe operation please follow the instructions below;
- Keep the scanner away from heat or fumes when using it;
- If the vehicle battery contains acid, please keep your hands and skin or fire sources away from the battery during testing;
- Exhaust gas of vehicle contains harmful chemicals, please ensure adequate ventilation;
- Do not touch the cooling system components or exhaust manifolds when engine is running due to the high temperatures reached;
- Make sure the car is securely parked and the selector is at P or N position to prevent the vehicle from moving when engine starts;
- Make sure the (DLC) diagnostic link connector is functioning properly before starting the test; otherwise the scanner may be damaged. AUTOBOSS suggests you test the Power/Earth with Multimeter first;
- Do not switch off the power or unplug the connectors during testing, otherwise you may damage the ECU or scanner.

CONTENTS

1. Introduction	1
1.1 FUNCTION AND FEATURE	1
1.2 LAYOUT OF V30 ELITE MAIN UNIT	2
1.3 TECHNICAL PARAMETERS	3
1.4 CONFIGURATION	3
1.5 PRINTER	8
2. Operation	9
2.1 POWER SUPPLY & CABLE CONNECTION	9
2.1.1 Power Supply	9
2.1.2 Cable Connection	9
2.2 INTERFACE INSTRUCTION	10
2.2.1 Starting Interface	10
2.2.2 Touch Screen Calibration	10
2.2.3 Diagnose Program	11
2.2.4 System Setting	12
2.2.5 Version Information	13
2.2.6 User Manual	13
2.2.7 Special tests Instructions	13
2.3 FLOW CHART OF V30 ELITE SOFTWARE UPGRADING	14
2.4 SOFTWARE UPGRADING	15
2.4.1 Download and Install "V30 ELITE Update Client"	15
2.4.2 Check V30 ELITE S/N and Password	16
2.4.3 Upgrading Instructions	17
2.5 USE YOUR PC TO PRINT SAVED FILES FROM SD CARD	21
2.6 LOGGING FUNCTION	22
3. Test Procedure	23
3.1 ENGINE ECU TESTING METHODS	23
3.1.1 Testing Description	23


1. Introduction

1.1 Function and Feature

- OE level coverage for European, Asian, American and Chinese cars
- Supports Multi-language
- CAN-BUS with high/low speed
- One OBDII connector for all CAN bus systems
- Frequent software update online
- High resolution VGA color TFT display
- Windows CE Operating System
- Quick Test function to test most vehicle systems
- Demo Mode for many OEM's
- Data graphing
- Self-check function

1.2 Layout of V30 ELITE main unit




- ① USB Port
- ② Printing test button
- ③ Paper released button
- ④ Diagnostic Port
- ⑤ Power Port
- ⑥ Touch pen/ Stylus slot
- ⑦ Power indicator
- ⑧ Paper released indicator
- ⑨ WIFI indicator
- ⑩ SD Card
- ⑪ Working state indicator
- ⑫ Power switch
- ⑬ Fuse















1.3 Technical Parameters







- **CPU:** SAMSUNG ARM9 2410A, 200MHz;
- **Memory:** 64M;
- **Flash card:** SD card, 8G
- **Display:** 7" Wide VGA (800×480) Ultra Bright TFT;
- **Power supply:** DC 8~15V
- **Port:** Diagnosis port, COM port, USB port, Power Port;
- **Operating system:** WINDOWS CE;
- **WIFI Model:**802.11 b/g/n
- **Storage temperature:** -30~85°C;
- **Working temperature:** -10~70°C;
- **Humidity:** <90%.







1.4 Configuration

Picture	Item	Description
	Name: V30 ELITE main unit Quantity: 1	Function: Display testing procedures and information
	Name: SD card Quantity: 1	Function: Storage of Diagnostic programs and saved files
	Name: Touch pen / Stylus Quantity: 1	Function: For touch screen operation

Picture	Item	Description
	Name: Main Cable Quantity: 1	Function: Connect the main unit & connectors for diagnosis
	Name: BENZ-38 connector Quantity: 1	Function: Used for testing Mercedes-Benz vehicles equipped with a circular 38-pin DLC
	Name: BMW-20 connector Quantity: 1	Function: Used for testing BMW vehicles equipped with a 20-pin DLC
	Name: Chery/Fiat -3 connector Quantity: 1	Function: Used for testing FIAT vehicles equipped with a 3-pin DLC
	Name: GM-12 connector Quantity: 1	Function: Used for testing GM/DAEWOO vehicles equipped with a 12-pin DLC
	Name: Kia-20 connector Quantity: 1	Function: Used for testing KIA vehicles equipped with a 20-pin DLC

Picture	Item	Description
	Name: Mazda-17 connector Quantity: 1	Function: Used for testing MAZDA vehicles equipped with a 17-pin DLC
	Name: TOYOTA-17 connector Quantity: 1	Function: Used for testing TOYOTA/LEXUS vehicles equipped with a semi-circular 17pin DLC
	Name: TOYOTA-22 connector Quantity: 1	Function: Used for testing Toyota and Lexus vehicles with a rectangular 22-pin DLC
	Name: MIT-12+16 connector Quantity: 1	Function: Used for testing Mitsubishi and Hyundai vehicles equipped with a 12-pin or 16-pin DLC
	Name: HONDA-3 connector Quantity: 1	Function: Used for testing HONDA and ACURA vehicles equipped with a 3-pin DLC
	Name: BENZ-4 connector Quantity: 1	Function: Used for testing Mercedes-Benz vehicles before 1997 with flash codes. Those vehicles are usually equipped with either a rectangular 8-pin or 16-pin

Picture	Item	Description
	Name: AUDI-4 connector Quantity: 1	Function: Used for testing VW/AUDI vehicles with a 4-pin (2x2) DLC
	Name: NISSAN-14 connector Quantity: 1	Function: Used for testing Nissan and Infiniti vehicles equipped with a 14-pin DLC
	Name: OBD-16 connector Quantity: 1	Function: Used for testing all vehicles compliant with OBDII, EOBD and J1962 with the 16-pin DLC
	Name: Citroen-16 connector Quantity: 1	Function: Used for testing Citroen with the 16-pin DLC according to software screen indicator
	Name: FIAT-16 connector Quantity: 1	Function: Used for testing Fiat with the 16-pin DLC according to software screen indicator
	Name: Jumper Quantity: 1	Function: Short circuit test for flash code reading

Picture	Item	Description
	Name: Battery power cable Quantity: 1	Function: Provide the power supply via battery
	Name: Cigarette lighter power cable Quantity: 1	Function: Provide the power supply via cigarette lighter on the car
-----	-----	-----
	Name: SD Card reader Quantity: 1	Function: Read SD card for software update or SD card reading and writing
	Fuse 5A 30*6	Spare parts
	Fuse 5A 20*5	Spare parts
	Name: Benz-14 pin connector Quantity: 1	Function: Used to test Mercedes-Benz Sprinter Note: Optional
	Name: Chrysler-16 connector Quantity: 1 Note: Optional	Function: Used to test Chrysler car with CCD protocol

NOTE: Configuration varies as per software package. For complete configuration, please refer to the relevant packing list.

1.5 Printer


There are two print modes in V30 ELITE.

1.5.1 Printing out on paper. You can print out diagnosis information on paper.


1.5.2 Save diagnosis information in World File and JPEG file. You can save diagnosis information in World file or in JPEG file.

1.5.3 Change printing paper


Step 1: Open printer back cover



Step 2: take out the stick



Step 3: Install the paper roll as shown in the following picture




2. Operation

2.1 Power Supply & Cable Connection

2.1.1 Power Supply

There are 4 ways to get power for V30 Elite Diagnostic Computer.
From:

- ① Vehicle DLC, no external power supply needed
- ② Cigarette lighter
- ③ Battery



2.1.2 Cable Connection

How to get power supply:

- ① Use Cigarette lighter or Battery cable to power main unit if DLC is not self-powered.
- ② No external power supply needed if DLC is self-powered.
- ③ **NOTE: ALL 16 PIN DLC connectors have 12v supply and earth for scan tools.**

How cables are connected:

- ① Select corresponding connectors for car make and DLC.
- ② Connect one end of main cable to the main unit and the other end to the connector.
- ③ Plug the connector in to the DLC on car.
- ④ Turn on the unit using the power button to start testing.


2.2 Interface Instruction

2.2.1 Starting Interface



The screen shown on the left picture will appear on the screen after the scanner is switched on.

2.2.2 Touch Screen Calibration



Several seconds after power is switched on, the screen will go into calibration mode. Click anywhere on the screen to start calibration if necessary.


Note: Just wait for several seconds until the diagnosis program runs if screen calibration is not required.



Click the center of cross with touch pen according to the instruction on the screen. Repeat the operation as the cross moves until the setting is finished.

After the scanner is started, you will come to the screen shown on the left picture which includes the functions of [Diagnose], [Setting], [User Data], [Version], [User Manual] and [Special tests Instructions],.

2.2.3 Diagnose Program



After entering [Diagnose], you will enter the diagnostic screen where you can select the region of vehicle manufacturer required: China, Europe, Asia, America, Others (OBD II /EOBD) and Favorite.

Europe: This section includes the diagnostic programs for European vehicles.


Asia: This section includes the diagnostic programs for Asian and Korean vehicles.

America: This section includes the diagnostic programs for US vehicles.

China: This section includes the diagnostic programs for Chinese vehicles.

Others: This diagnostic program can test all vehicles with OBD II /EOBD and CAN-OBD.


Favorite: This function enables you to save the vehicle frequently tested. For example, once you save Honda as your favorite, it will lead you directly to Honda interface when you click **【diagnose】** icon. You can save more than one vehicle as your favorites.






2.2.4 System Setting

Click the button **[Setting]** to enter settings for language, time, Self-Check and Print Mode.



2.2.4.1 Language Setting


V30 ELITE supports Multilanguage. Choose any language needed under **[working language]** and press **[OK]** to finish language setting.



2.2.4.2 Time Setting

Click **[Set time]** to enter the menu for time selection. By clicking on signs of “▼” or “▲”, numbers will increase or decrease correspondingly.

Click the button **[Set time]** to finish setting. The dialog box “**Set system time successfully!**” will popup.




Click **[OK]** to save the setting or **[Cancel]** to exit.

2.2.4.3 Display Data Stream in Imperial

Data stream will be displayed in Imperial after **[Imperial]** is chosen.


2.2.4.4 Self-Check



This is for hardware checking. Click the button **[Self check]** and any hardware faults will be displayed. Please contact technical support if a hardware problem is reported.

If there are no hardware errors, the checking result will be **“System Self test report: No error found.”**

2.2.5 Version Information



Click the button **[Version]** in main menu to get the information of Hardware version, Software Serial number, Release date, etc.

Click **[Back]** to exit.

2.2.6 User Manual




Click the Button **[User Manual]**, and you can read the user manual.

2.2.7 Special tests Instructions



Click the Button **[Special tests Instructions]**, and special tests, such as Injector code reading, Program new keys, air bleeding and others, will be shown step by step.

2.3 Flow Chart of V30 ELITE Software Upgrading






2.4 Software Upgrading


2.4.1 Download and Install "V30 ELITE Update Client"

Step1: Visit AUTOBOSS website at <http://www.AUTOBOSS.net>

Step2: Enter English website





Step3: Click button **[Download]** and select V30 ELITE as shown in left image.



Step4: Click the option **[V30 Elite Update Client]** to download the update client to your PC.


A file named V30 ELITEUpdateClien.exe will be saved in your PC.






Step 5: Double click this file to install “V30 ELITE update client” step by step until you see the image shown on the left.


Note: Just click the button [Next] in each step during the installation. We advise you to keep everything as default. Please remember to input your name and company name.



After finishing the installation, you will see the

icon shown below on your desktop 

Download of “V30 ELITE update client” is finished.



2.4.2 Check V30 ELITE S/N and Password

Check the S/N: Please refer to **2.2.7 Version information** in this manual;

How to get password:

Click the button **[Activate]** to get the original register password as shown in left image.




Fig 2-1 Login screen




Fig 2-2 Downloads progress

2.4.3 Upgrading Instructions

2.4.3.1 Run V30 ELITE update client program

Step1: Take out the SD card from main unit, plug it into the USB SD card reader and connect to PC. Step 2: Double click to run the **V30 ELITE update client** program on your PC and go to update screen as shown in Fig 2-1.

2.4.3.2 Login the Server

- (1) Input the serial number and password then click the **[OK]** button to connect to server. It takes some seconds before the download is finished like Fig 2-2.
- (2) The default server is 'www.AUTOBOSS.net'. Normally you do not have to change the server.

Note:

- ① Be sure that both S/N and password are correct. Please pay attention, the letters are case sensitive!
- ② If login takes a long time because of low internet speed, you can exit and retry;
- ③ Internet firewall might affect the login. If login fails, please make sure you have an internet connection, and ensure any installed firewall is not blocking the connection to the server. For detailed operation instructions, please contact technical support.




Fig 2-3 Program list screen

(4) After download is finished, all updates available will be displayed as shown in Fig 2-3.

(5) The update client will automatically identify new updates available for your V30 ELITE.

2.4.3.3 Modify Password

After initial login, users can change original registered password.




Fig 2-4 Modify password

Operation instruction:

(1) After inputting the serial number, click **[Modify password]** as shown in Fig 2-4 to go to the next step as Fig 2-5.



Fig 2-5 Modify password screen

(2) Input the current password and new password, then click **[OK]** for confirmation.

Note: Please keep the password in a secure location. If you forget the password, please contact AUTOBOSS or technical support.

User information			
First name	test	Last name	test
Company name	RD Center, SPX		
Tel	111	Fax	22005688
Mob	1	Email	1111111@spx.com
Distributor code	11	Country	11
State/Province	11	City	11
Street No.	11	Post code	11
<div>OK Cancel</div>			

Fig2-6 Input customer info screen

2.4.3.4 Input Customer Information

You must fill in your personal information when you first login to V30 ELITE update client; otherwise you will not be able to download updates.

Operation instruction:

Click the button **[Customer info]** after login succeeds. You can see the screen as shown in Fig. 2-6. Input your information to the relevant spaces and click **[OK]** to save the information.

V30 ELITE Vehicle Diagnostic System Update client

S/N: Language: English Driver:

Item	Vehicle	Version	Release	Status	Application	Repair info
1	PC/LINK-Dropcar	1.42	20120713	need update application		
2	ACURA	5.4	20120824	need update application		
3	ALFA	1.2	20120401	need update application		
4	AMFORD	2.9	20120823	need update application		
5	AUDI	6.6	20120826	need update application		
6	BBCC	1.9	20100123	need update application		
7	BEHC	9.0	20120802	need update application		
8	BMW	9.2	20120728	need update application		
9	BPD	2.3	20100123	need update application		
10	CHANA	2.7	20100123	need update application		
11	CHANGHE	3.2	20081105	need update application		
12	CHERY	3.7	20100123	need update application		
13	CHRYSLER	2.0	20111205	need update application		
14	CITROEN	5.6	20120826	need update application		
15	DANWOOD	2.81	20120831	need update application		
16	DAMATSI	1.21	20120831	need update application		
17	EURFORD	5.5	20120826	need update application		
18	FOUC	2.1	20100123	need update application		
19	FAT	3.0	20120802	need update application		
20	FUTIAN	2.4	20100123	need update application		
21	GEELY	2.6	20100123	need update application		
22	GM	2.9	20120723	need update application		

Downloaded diagnostic program list successful

Copyright © 2012 http://www.autoboss.net Version: 1.0

Fig.2-7 Download screen

2.4.3.5 Software Download

After user information is saved, you can download the programs needed.

Operation instruction:

- (1) Choose the language version on the top and tick the small box before the relevant program as Fig. 2-7;
- (2) Click **[Download]** in right column to enter download status.

Note: A maximum of 10 items can be chosen to download simultaneously.

- (3) The software will be downloaded to your PC hard drive automatically.

V30 ELITE Vehicle Diagnostic System Update client

S/N: Language: English Driver:

Item	Vehicle	Version	Release	Status	Application	Repair info
1	PC/LINK-Dropcar	1.42	20120713	need update application		
2	ACURA	5.4	20120824	need update application		
3	ALFA	1.2	20120401	need update application		
4	AMFORD	2.9	20120823	need update application		
5	AUDI	6.6	20120826	need update application		
6	BBCC	1.9	20100123	need update application		
7	BEHC	9.0	20120802	need update application		
8	BMW	9.2	20120728	need update application		
9	BPD	2.3	20100123	need update application		
10	CHANA	2.7	20100123	need update application		
11	CHANGHE	3.2	20081105	need update application		
12	CHERY	3.7	20100123	need update application		
13	CHRYSLER	2.0	20111205	need update application		
14	CITROEN	5.6	20120826	need update application		
15	DANWOOD	2.81	20120831	need update application		
16	DAMATSI	1.21	20120831	need update application		
17	EURFORD	5.5	20120826	need update application		
18	FOUC	2.1	20100123	need update application		
19	FAT	3.0	20120802	need update application		
20	FUTIAN	2.4	20100123	need update application		
21	GEELY	2.6	20100123	need update application		
22	GM	2.9	20120723	need update application		

Downloaded diagnostic program list successful

Copyright © 2012 http://www.autoboss.net Version: 1.0

Fig.2-8 Download screen 2




Fig.2-9 Software installation screen

2.4.3.6 Update

- (1) Take out the SD card from V30 ELITE main unit;
- (2) Put the SD card into SD Card reader;
- (3) Connect the Card-Reader to PC USB port;
- (4) Select the SD card driver on the top-right side of software installation screen as shown in Fig.2-9;
- (5) Click the button **[Update]**, the selected programs already downloaded to your PC hard drive will be installed on SD card automatically.

Note: Make sure the update destination is the SD card driver. To confirm this, please enter “My computer” on the PC to verify the content in SD card.



Fig.2-10 software installation screen

2.4.3.7 Software Management

You can delete old versions of software on the SD card by software management.

Operation instruction:

Click the button **[Management]** to enter the screen shown in Fig. 2-10. Select the software that is not needed and click **[Delete]**. The selected software will be uninstalled automatically.





2.4.3.8 Exit

After finishing all of the steps, click **[Exit]** to exit the update client.

2.5 USE YOUR PC TO PRINT SAVED FILES FROM SD CARD

- (1). Insert SD card in SD card reader
- (2). Plug SD card reader into USB port of PC
- (3). Window as shown will pop up, select “open folder to view files” press “OK”

NOTE: You can also obtain a printout by pressing “Print” with the optional mini printer installed on the V30 ELITE.



- (4). If the above window does not appear- go to “my computer”, double click the icon for “Removable disc (F:)” (NOTE: Drive letter may vary depending on assignment of letters by Windows.)

- (5). Double click “PRINT” folder and choose file required, double click to open file.


- (6). Depending on which program your PC has opened the file with, print using printer icon or select “File” then “Print” from top taskbar

2.6 Logging function

The data logger records communication data and ECU information when you are testing vehicles. So if you have any technical problems when you are testing vehicles, you can use LOGGING function to send feedbacks back to AUTOBOSS head office who will analyze the data and help you solve the problems quickly.

To use LOGGING function, please follow the following steps:


Step 1: Click Record, then Click OK to test vehicles



Step 2 : After testing the vehicles, exit testing program and power off V30 Elite.


Step 3: Take out SD Card from V30 Elite and put it into your laptop.

Step 4: Log in V30 Elite UPDATE CLIENT



Step 5: Click Upload Log

Step 6: After Uploading is finished, Click Exit.



3. Test Procedure

3.1 Engine ECU Testing Methods

3.1.1 Testing Description


- (1) Power up and turn on the scanner;
- (2) Click **[Diagnose]** → **[Europe]** to enter screen as shown on the left image;



- (3) Select diagnostic program


Click **[VW]**, for example, to enter software version selection screen shown in the left image.

Note: Program descriptions will be displayed under the version information.




- (4) Select a version such as V3.1 and click **[OK]** as shown in left image. Click **[Cancel]** to go back to the previous menu;

- (5) Select vehicle type: take Volkswagen/Audi for example, we have two vehicle types for selection: **[With Can bus]** and **[Without Can bus]**. Here we choose without Can bus car as an example to introduce the test.



NOTE: VEHICLES WITH CAN BUS WILL HAVE DLC PINS 6 AND 14 POPULATED



(6) Select system:

[Common system Auto-Scan]: Test the common-use ECU automatically;

[All system Auto-Scan]: Test all ECU automatically;

[Common]: by choosing this item, all common-use ECU will be displayed on the screen, users can then select ECU required accordingly;

Other systems: Enter the systems as per relevant ECU type.



(7) Click **[Common]** to enter the screen shown on the left.

Select **[01-Engine]** to enter the screen with the following functions.

[01-Interrogate control unit versions]

[02-Interrogate fault memory]

[03-Final control diagnosis]

[04-Introduction of basis setting]

[05-Erase fault memory]

[06-End output]

[07-Coding]


[08-Read measuring value block]

[09-Read individual measuring value]


[10-Adaptation]

[11-Login procedure]

[15-Write VIN]



Note: Functions 04,07,10,15 require knowledge of the systems operation, please use with care.



① [01-Interrogate control unit versions]


Click **[01-Interrogate control unit versions]** to see the information of control unit as shown on the left.

Note: Read out old ECU codes with this function when performing ECU coding.



② [02-Interrogate fault memory]

To display the DTC saved in the current control unit, click **[02-Interrogate fault memory]**. Please refer to the left image.




③ [03-Final control diagnosis]

Click the button **[03-Final control diagnosis]** to test relevant actuator automatically as shown on the left image. Click **[Active Test]** to begin actuator test.

④ [04-Introduction of basis setting]

Click the button **[04-Introduction of basis setting]** for basic setting. Input desired number using the number keys and click the button **[OK]** to start the basic setting.


- **[Del]**: Delete the input numbers;
- **[Left]**: Move cursor to left;
- **[Right]**: Move cursor to right;
- **[Home]**: Move cursor to Home;
- **[End]**: Move cursor to End;
- **[Enter]**: confirm enters.



The window of "Basic setting!" in left image will popup after Basic Setting is done.

- **[Input]**: continue to Input number;
- **[Back]**: Back to the Function Menu.


Note: Under basic setting mode, you can perform solenoid and engine control unit adaptation without starting the engine, or finish λ control process self-adaptation when engine starts. Also you can check faults or ignition timing by connecting or disconnecting λ control.



⑤ [05-Erase fault memory]

Click the button **[05-Erase fault memory]** to erase DTC as shown on the left image.

- **[OK]**: Return to the previous menu



⑥ [06-End output]

To exit from the diagnostic program, please click **[06-End output]**.


- **[Yes]**: Exit the diagnosis program

[No]: Return to the previous menu

⑦ [07-Code control unit]

Click **[07-Code control unit]** to go to screen as shown in the left image. Then input the code and click **[OK]**, the scanner will begin the coding. Click **[OK]** after coding succeeds.


Note: Please only code the ECU after the ECU has been changed or a function has been added (e.g. Cruise control). You can get the code of the old ECU by choosing **[01-Interrogate control unit versions]**, then recode the new ECU accordingly.



⑧ [08-Read measuring value block]


Click **[08-Read measuring value block]** to enter screen shown in left image. Please input the relevant channel number, and click **[OK]** to read data stream information.

Note: For channel definition, please refer to relevant technical manual.



The left image is the data stream of Group 01.


- **[Page Up]**: See previous group data stream;
- **[Page Down]**: See next group data stream;
- **[Waveform]**: Review data stream in graph;
- **[Replay]**: Review data stream;
- **[Back]**: Return to the Function Menu.
- **[Print]**: save the current screen to SD card.




⑨ [09-Read individual measuring value]

Click **[09-Read individual measuring value]** to enter the screen shown in the left image. Input the channel number and click **[OK]** to view the relative data.

Click **[Read Value]**, and current value will be displayed.



- **[Input]**: Back to the input screen;
- **[Increase]**: View the data of next channel number.
- **[Decrease]**: View the data of the previous channel number;
- **[Read value]**: Read current value;
- **[Back]**: Back to function list menu;
- **[Print]**: Save the current screen to SD card.




⑩ [10-Adaptation]

Click **[10-Adaptation]** to enter the screen for inputting channel number as shown in left image.


Note: Self-adaptation includes: self-study during idle, service reset, IMMO adaptation and so on. You should login first for some of the functions. For login methods, please refer to

⑪ [11-Login procedure] on page 26.




After inputting the relevant channel number, click **[OK]** to enter the screen as shown in left image.

- **[Input]**: Back to the “input number” screen;
- **[Read]**: Read the adaptation value of current channel;
- **[Back]**: Back to function list screen;
- **[Print]**: Save the current screen to SD card.



Click the button **[Read]** to read the adaptation value of current channel.

- **[Input]**: Input new adaptation value;
- **[Back]**: Back to function list menu.
- **[Print]**: Save the current screen to SD card.



Click **[Input]** in enter the “input adaptation value” screen shown on the left. Input the new value and then click the button **[Ok]** to go to the next step.

Name	Value	Unit
Group Number	1	
Current adaptation value	32000	
Input	23	
Lock		

After inputting the new value, new adaptation value will be displayed on the screen. If no error is found, please click the button **[Change]** to go to the next step.

Last step: Click the button **[Save]** to save the new adaptation value and go back to the self-adaptation screen.

⑪ [11-Login procedure]

To perform adaptation in some group, login will be needed first. Just click the button **[11-Login procedure]**, input the code number and then click **[OK]**.

Note: Login is required when performing functions such as ECU coding, change channel adaptation and IMMO, etc.

⑫ [15-Write VIN]

Volkswagen/Audi uses the 3rd generation anti-theft technology, if you change engine control unit and instrument cluster at the same time you must rewrite the VIN code. Please click **[15-Write VIN]** to input the new VIN.

- **[Del]**: Delete the input numbers;
- **[Left]**: Move cursor to left;
- **[Right]**: Move cursor to right;
- **[Home]**: Move cursor to Home;
- **[End]**: Move cursor to End;
- **[Enter]**: confirm the information.
- **[Shift]**: same with **[Caps Lock]** + **[shift]** function on key board

FCC STATEMENT

1. This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Radiation Exposure Statement:

The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition without RF striction.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If the equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.