

1 Get to Know Your AP

2 Install Your AP

3 Connect Your AP

4 Manage Your AP

Method 2: Managed by an AC (like AC2000 as an example)

Step 1: Select your management PC's IP to a static IP address within the following range: 192.168.0.X (2-253) and a subnet mask of 255.255.255.0

Step 2: Launch a web browser, input the AC's default login IP address 192.168.10.1 in the address bar and press Enter. Then you'll be prompted to enter the default login username and password (admin for admin). Click Login.

Step 3: Then you'll be directed to the web UI of the AC. For more settings, see the User Guide of the AC at our website: <http://www.ip-com.com.cn>

FAQs

CE Mark Warning

NOTE: (1) The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. (2) To avoid unnecessary radiation interference, it is recommended to use a shielded RJ45 cable.