

V62G/V62W Quick Installation Guide

Fanvil Link Technology Co., LTD
www.fanvil.com

V1.2

Packaging list

IP Phone	Handset	Handset Cord	Ethernet Cable	Quick Installation Guide
Stand			Power Adapter (Optional)	Wall Mount Bracket (Optional)

Screen icon

	In hands-free mode		Call forward activated		VM messages		Internet connected
	In headset mode		Disable do not disturb (Beige)		Voice quality level of call		Internet disconnected
	In handset mode		Do not disturb activated (Red)		Keypad locked		No IP address
	Mute activated		SIP hotspot activated		Forward call(s)		Wireless network connected
	Silent mode		VLAN activated		Missed call(s)		Wireless network disconnected
	Call is on hold		VPN activated		Received call(s)		Wireless network failure
	Auto-answering activated		SMS		Dialed call(s)		

Keys features


	DSS Keys, It can be set as line key/function key/speed dial key, etc.		Home key, go back to Homepage		Headset key, activate/deactivate headset
	Soft keys		Return key, go back to the previous directory		Phonebook key
	Message waiting indicator		Voice message key		Redial key, access to redial the last record
	Left and right navigation keys Up navigation key, Shortcut to call log Down navigation key, Shortcut to Status OK key		In idle mode or during ringing: increase or decrease ringer volume In communication: increase or decrease handset, headset or hands-free volume		Hand-free key, activate/deactivate hands free

- 2 -


Installation the device

Please follow the instructions in below picture to install the device.

• Desk Mount Method



• Wall Mount Method



Network connect

Using Ethernet

1. The power on the device and connect the WAN port of the phone to the RJ45 socket of a hub/switch or a router (LAN side of the router) using the Ethernet cable.
2. The default is DHCP mode.

Configuration

Configuration via LCD menu of phone

1. Press Menu > Advanced (default password 123),
2. Select Network: To configure the Network Settings (IPv4/IPv6/IPv4&IPv6, DHCP/Static IP/PPPoE),
3. Select Accounts: To configure enable the account, fill the SIP server address, port, Auth/User, Auth,Password etc.
4. Save the configuration.

Configuration via web


1. Get the IP address from the phone: Press down navigation key, or Menu > Status > ETH IP/WIFI IP.
2. Login: Input the IP address in the web browser. The PC and phone should be in the same IP address segment (The default username and password are both 'admin').
3. Configure: Select network/Line etc, and fill the relevant content.
4. Save the configuration.

Language setting

1. Press Menu key > Basic > Language,
2. Select the desired language and press OK soft key.

Making a call

1. **Pre-dialing:** enter the phone number and pick up the handset.
2. **Direct dialing:** lift the handset and enter the phone number.
3. **Handsfree:** enter phone number and press or viceversa.
4. **Headset:** enter phone number and press or viceversa.
5. **Designated line:** press line key, enter phone number and press dial key.



- 3 -



Fanvil Link Technology Co., LTD

Website: www.fanvil.com

EMail: sales@fanvil.com support@fanvil.com

Tel: +86-755-2640-2199 Fax: +86-755-2640-2618

Redial

1. Press key, redial a call number.

Call Mute

1. Press to Mute the microphone during the call.
2. Press again to unmute the conversation.

Putting a call on hold

1. Press Hold soft key, caller is put on hold.
2. To retrieve the call press Resume soft key.
Note: with more than one active call, select desired call with the navigation key and use the corresponding soft key to hold or resume.

Call transfer

Attended transfer:
1. Press Xfer soft key during the active conversation, the call is put on hold.
2. Dial the second telephone number.
3. When the call is answered, then press Xfer soft key to complete the operation.

Blind transfer:
1. Press Xfer soft key during the active conversation, the call will be on hold.
2. Then enter the 2nd telephone number and press Xfer soft key.

Call forward

1. Press Menu > Features > Call Forward.
2. Select the line, the type of forward, enter the destination number and status, and press OK soft key.

Call conference

1. Once in line with 1st caller, press Conf soft key, 1st call is put on hold.
2. Then call the 2nd number.
3. After, 2nd call is established, press Conf soft key to setup the conference.

Programmable key

1. You can configure shortcuts for the programmable keys.
2. Press Menu > Basic > Keyboard, select among the configurable items, and select your desired type and value, press OK key.

Do not disturb

1. Press DND soft key, and enable the device do not disturb mode.
2. Or press Menu > Features > DND, and select the Mode and effective time, and press OK key.

Voice mail

1. To access your voice mailbox, press or Menu > Message > Voice Message, number of messages will be indicated if provided by your server or pbx.
2. Select the line and press Play to call.

Wi-Fi (Only available for Wi-Fi models)

1. Press Menu > Basic > WLAN.
2. Press OK soft key to enter the WLAN open interface.
After opening, press Scan soft key to display the list of Wi-Fi scanned.
3. Press Enter soft key to enter the available Network, select the wireless network, press the Connect soft key and enter the password to connect.

Call list

1. Press up navigation key or Menu > Call Log > Local Call Logs.
2. Scroll through the list using navigation key.
3. To dial an entry, press Dial soft key or pick up handset or press or .

Phonebook

Access Phonebook:
1. Press or Contact soft key or Menu > Contact > Local Contacts.
2. Select All Contacts or other group.
3. To dial an entry, press Dial soft key or pick up handset or press or .

Add new entry:
1. Press Contact soft key. Press All Contacts or other group > Press Add.
2. Enter name and number and press OK soft key.

1. This equipment complies with Part 68 of the FCC rules and the requirements adopted by the ACTA. On the bottom of this equipment is a label that contains, among other information, a product identifier in the format US: FV1PNANV62W. If requested, this number must be provided to the telephone company.
2. A plug and jack used to connect this equipment to the premises wiring and telephone network must comply with the applicable FCC Part 68 rules and requirements adopted by the ACTA. A compliant telephone cord and modular plug is provided with this product. It is designed to be connected to a compatible modular jack that is also compliant. See installation instructions for details.
3. If this equipment [US: FV1PNANV62W] causes harm to the telephone network, the telephone company will notify you in advance that temporary discontinuance of service may be required. But if advance notice isn't practical, the telephone company will notify the customer as soon as possible. Also, you will be advised of your right to file a complaint with the FCC if you believe it is necessary.
4. The telephone company may make changes in its facilities, equipment, operations or procedures that could affect the operation of this equipment. If this happens the telephone company will provide advance notice in order for you to make necessary modifications to maintain uninterrupted service.
5. If trouble is experienced with this equipment [US: FV1PNANV62W], for repair or warranty information, Service can be facilitated through our office at:
U.S. Agent Company name: EMCTEK
Address: 11788 Big Canyon Ln, San Diego CA 92131 USA
Tel: +1 858 401 9073
Fax: N/A
If the equipment is causing harm to the telephone network, the telephone company may request that you disconnect the equipment until the problem is resolved.
6. Please follow instructions for repairing if any (e.g. battery replacement section); otherwise do not alter or repair any parts of device except specified. For repair procedures, follow the instructions outlined under the limited warranty.
7. Connection to party line service is subject to state tariffs. Contact the state public utility commission, public service commission or corporation commission for information.
8. If your home has specially wired alarm equipment connected to the telephone line, ensure the installation of this does not disable your alarm equipment. If you have questions about what will disable alarm equipment, consult your telephone company or a qualified installer.
9. If the telephone company requests information on what equipment is connected to their lines, inform them of:
a) The ringer equivalence number [NAN]
b) The USOC jack required [N/A]
c) Facility Interface Codes ("FIC") [N/A]
d) Service Order Codes ("SOC") [N/A]
e) The FCC Registration Number [US: FV1PNANV62W]
10. The REN is used to determine the number of devices that may be connected to a telephone line. Excessive RENs on a telephone line may result in the devices not ringing in response to an incoming call. In most but not all areas, the sum of RENs should not exceed five (5.0). To be certain of the number of devices that may be connected to a line, as determined by the total RENs, contact the local telephone company. The REN for this product is part of the product identifier that has the format US: FV1PNANV62W. The digits represented by # are the REN without a decimal point. For this product the FCC Registration number is [US: FV1PNANV62W] indicates the REN would be NAN.
11. We suggest the customers use a surge arrester to protect the device.

This device meets HAC and CS03 Part V.

"This device meets the applicable Innovation, Science and Economic Development Canada technical specifications. / Ce produit répond à la innovation, des sciences et de .Développement économique Canada spécifications techniques applicables."

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Innovation, Science, and Economic Development Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:
(1) this device may not cause interference, and
(2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d' Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- (1) l'appareil nedoit pas produire de brouillage, et*
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.*

5GHz band (W52): Indoor use only

Bande 5 GHz (W52): utilisation intérieure uniquement

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

This equipment complies with FCC/ISED radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator& your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

L'appareil est conforme aux limites d'exposition aux rayonnements spécifiées par la FCC/ISED pour les environnements non contrôlés. La distance entre le radiateur et le corps doit être d'au moins 20 cm lors de l'installation et du fonctionnement de l'appareil.

Cet émetteur ne doit pas coexister ou fonctionner conjointement avec toute autre antenne ou émetteur.