

M87P8 Module Evaluation Kit

User Manual V1.0


1. Initial setup

1.1 Powering the Reader

Plug the **power cable** in, with the **indicator light** on & reader is ready. As illustrated below:

DC IN: 9~24V

B TYPE USB




1.2 Connecting Antenna to Reader

Connect the antenna with the antenna MMCX port as illustrated below:



1.3 Connecting Data Line to Reader

You can connect the reader to your PC via B type USB, as illustrated below:




2. Connect DEMO SW


Double-click **EagleDemo.exe** to run the software.

2.1 Connect

2.1.1 Open the software and it will shows as below:



2.1.2. Please select **USB** as **Connection**, Choose the corresponding **Serial Port** and **Baud Rate** (default baud rate is 921600). As illustrated below:



2.1.3. Click **Connect**, if it is connected successfully, the **FW version** will display as below:

operation record :

```
2023-07-03 02:06:06.934 Connect COM39@921600
2023-07-03 02:06:06.939 GetFirmwareVersion
2023-07-03 02:06:06.971 00 01 40 00 02
```

File Log Activate Monitor

2.1.4. Text communication with the reader:

Click on **Get** in Firmware Version or in Reader Region, the following screen displays:

Firmware

01400002

Read

Region

FCC

Set

Get

3. Run Inventory function

After connecting the reader with PC, we can start go Inventory Run function. Please select **ISO 18000-6C tag test** as illustrated below:

Reader Setup ISO 18000-6C Tag Test Monitor UPGRADE

Inventory

Operation

Inventory

Abort

Inventory Type
 LoopAntenna
 Custom

Inventory Stop Condition
 Loop Times: 1 continuous
 Conti-Inventory Time: 1000 ms
 Warning Occur 2ndSetting

Antenna
 1
power 3000
inventory time 1000
inventory run 0

Select CFG
RF mode: ULTRA FAST MODE 103
 RF_Channel RSSI TimeStamp
 ANT ID Phase

Data

Inventory Quantity

Peak Speed(Tag/s) 0 Max Speed(Tag/s): 267 AVG Speed(Tag/s): 190

Command Duration(ms) 0 Total Inventory Duration 0 00:00:01.256

Result

Total Tag Count: 239

Min RSSI: -62.60dBm Max RSSI: -38.73dBm Refresh Save Tag

#	Coun	PC	EPC	Freq(khz)	Rssi(dBm)	ANT1	Timestamp
1	8	30 00	EE EE 00 00 00 00 00 00 00 00 00 02	925250	-5301	8	620874
2	9	30 00	EE EE 00 00 00 00 00 00 00 00 00 09	925750	-5395	9	428920
3	12	30 00	EE EE 00 00 00 00 00 00 00 00 00 0D	926750	-4831	12	211546
4	11	30 00	E2 00 00 1D 97 08 00 55 23 10 1C DF	926750	-5175	11	175870
5	12	30 00	00 00 00 00 00 00 00 00 00 00 00 00	926750	-5001	12	219103
6	10	30 00	E2 80 69 95 00 00 50 02 FD 98 DA 3C	926750	-5099	10	167488
7	9	1C 00	53 45 00 00 07 69	926750	-5457	9	169213
8	13	30 00	EE EE 00 00 00 00 00 00 00 00 00 04	926750	-5508	13	209209
9	10	30 00	EE EE 00 00 00 00 00 00 00 00 00 0A	926750	-4987	10	175040
10	6	30 00	E2 00 00 1D 97 08 01 94 23 10 AB C1	925750	-5724	6	426414

3.1 Step1: Enable ANT 1

Check mark the ANT1.

Antenna
<input checked="" type="checkbox"/> 1
power
3000
inventory time
1000
inventory run
0

3.2 Setp2: Setting RF Output Power

RF Output Power is the strength of RF output signal from antenna port whose unit is dBm.

Antenna
<input checked="" type="checkbox"/> 1
power
<input checked="" type="checkbox"/> 3000
inventory time
1000
inventory run
0

The output power range is 0 - 33dBm. Default RF output power is 30dBm .

3.3 Setp2: Setting Inventory time & Run

Setting Inventory time is mean the running time when start inventory command.

Setting Inventory Run is mean the running once when start inventory command.

Inventory stop if which time or run up to the setting value


Antenna
<input checked="" type="checkbox"/> 1
power
3000
inventory time
<input checked="" type="checkbox"/> 1000
inventory run
0

The default inventory time is 1000ms.

The default inventory run is 0, which mean “don’t care”.


3.4 Setp3: Setting RF-link mode

There is different read speed & sensitivity in different RF-link mode. To more detail, please check the **RF-link profile** of datasheet.



3.5 Setp4: Run/Stop Inventory


click **Inventory** button to Run Inventory function. click **Stop** button enforce to stop Inventory function.



3.6 Parameter of AUTO Stop Inventory

Loop time	Inventory stop when reach the setting of command count.
Conti-Inventory	Inventory stop when reach the setting of Inventory period.


* it will no stop if tick **continuous**



3.7 The parameter of Running Inventory

There are 13 parameters when run inventory as shown as following.

Inventoried Quantity	Total number of inventory tags since click Inventory .
Peak Speed	Read Speed of Tag for last one inventory command, unit: Tag/s
Max speed	MAX Read Speed of Tag for total inventory period, unit: Tag/s
AVG speed	AVG Read Speed of Tag for total inventory period, unit: Tag/s
Command Duration	Time between Inventory Command to command, unit: ms
Total Inventory Duration	Total inventory period when click Inventory , unit: ms.
Total Tag Count	Total tags when start Inventory period.
Count	Tag count
EPC	EPC data of tag.
PC	PC data
CRC	CRC data
RSSI	The Tag signal strength at the last inventory command.
Carrier Frequency	Carrier Frequency of tag at the last time.



4. Error Display

◆ ANT error:

operation record :	<input type="checkbox"/> File Log	<input type="checkbox"/> Activate Monitor	<input type="button" value="Clean"/>
2023-09-08 01:37:17.751 Interval Count1: RFMode:103 ANT1 Set			
2023-09-08 01:37:18.456 Stop			
2023-09-08 01:37:24.966 Interval Count1: RFMode:103 ANT1 Set			
2023-09-08 01:37:25.461 Stop			
2023-09-08 01:37:28.121 Interval Count1: RFMode:103 ANT1 Set			
2023-09-08 01:37:28.134 CMD 0xD Status Error:62 01 ERR_OP_STATUS			
2023-09-08 01:37:28.135 Stop			

Reason:

1. ANT is Disconnection to ANT port of module
2. VSWR is too large of ANT, it should be lower than 1.3
3. Reflection RF power too large, please check is there some Metal around ANT.

◆ Receiver data time out:

operation record :	<input type="checkbox"/> File Log	<input type="checkbox"/> Activate Monitor	
2023-07-03 02:39:54.639 Stop			
2023-07-03 02:40:03.688 Interval Count1: RFMode:103 ANT1 Set			
2023-07-03 02:40:08.885 Interval Count2: RFMode:103 ANT1 Set			
2023-07-03 02:40:14.066 Interval Count3: RFMode:103 ANT1 Set			
2023-07-03 02:40:19.265 Interval Count4: RFMode:103 ANT1 Set			
2023-07-03 02:40:24.451 Interval Count5: RFMode:103 ANT1 Set			
2023-07-03 02:40:32.463 MEX10.SerialReader, message is Receiver TimeOut 3s			

Reason:

1. Software CRASH
2. Interface CRASH

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

IMPORTANT NOTE: FCC Radiation

Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

LABEL OF THE END PRODUCT:

The final end product must be labeled in a visible area with the following " Contains TX FCC ID: 2BEYTM87P8 ". The FCC part 15.19 statement below has to also be available on the label: This device complies with Part 15 of FCC rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference and
- (2) this device must accept any interference received, including interference that may cause undesired operation.