

Preface

Thank you for buying "Xperia™ ●" (simply called the "product" from here on).

About Operating Instructions

■ Basic Manual (this manual)

Handles only basic operations for main features. For detailed descriptions on various functions, refer to the "Instruction Manual" (Japanese) application installed on the product or "取扱説明書詳細版 (Full Instruction Manual) (Japanese)" available on the au homepage.

■ "Instruction Manual" (Japanese) application


This product allows you to use the "Instruction Manual" (Japanese) application on the product to confirm detailed operational procedures. Certain functions can be directly activated from the application screens on which their operations are described.

4G LTE

Do you have everything?

Before your start using the product, make sure that you have all the following packaged with the product.

- Xperia™ ● (with battery cover)*1
Desktop Holder (SOL23PUA)*1



- *1 Including warranty
取扱説明書 (Instruction Manual) (Japanese)
Xperia™ ●のご利用にあたっての注意事項 (Cautions on using Xperia™ ●) (Japanese)
携帯電話機の比較吸収率などについて (Radio Frequency (RF) exposure and Specific Absorption Rate (SAR)) (Japanese)
設定ガイド (Setting Guide) (Japanese)


- Information
Purchase a specified charger (sold separately).
Illustrations used in this manual are just images for explanations. They may be different from actual ones.

7

Getting Ready

Names and functions of parts

- 1 Headset connection terminal
2 Proximity sensor: Switches touch panel on and off to prevent from erroneous operation during a call.
3 Earpiece
4 Notification LED: Notifies charging status, missed calls, mail reception.
5 Front camera
6 Display (Touch panel)
7 au Micro IC Card (LTE) slot
8 Power key/Screen lock key: [C]
9 Volume key/Zoom key: [V] [Z]
10 Camera key: [C] (Activates the camera, works as a shutter when shooting)
11 Camera
12 Infrared data port
13 Second microphone: Reduces noise to make easy to listen.
14 NFC (FeliCa™ compatible) antenna*1



8

- For Those Requiring an English Instruction Manual
You can download the English version of the Basic Manual from the au website (available from approximately one month after the product is released).
Download URL: http://www.au.kddi.com/support/mobile/guide/manual/

Safety Precautions

Before you start using the product, make sure to read the "Cautions on using Xperia™ ●" to ensure correct use. Before you assume that the product is malfunctioning, check for possible remedies in the following au Customer Support site of our homepage:

http://www.au.kddi.com/support/mobile/trouble/repair

When using the product

- Communication is not possible even inside the service area in places where the signal does not reach (e.g. tunnels and basements). Also, communication is sometimes not possible in poor reception areas.
Since this product uses radio waves, the possibility of communication intercepts by third parties cannot be eliminated.
This product is compatible with the international roaming service.

2

- Screen illustrations shown in this manual look different from the actual screens.
In this manual, "microSD™ memory card", "microSDHC™ memory card" and "microSDXC™ memory card" are abbreviated as "microSD memory card" or "microSD".
"MicroSD" as appears on the product refers to the following companies: Sold by: KDDI CORPORATION, OKINAWA CELLULAR TELEPHONE COMPANY

■ Use of the product is not allowed in the following places!

- Do not use a cell phone while driving a car or riding a motorbike or bicycle.
Use of a cell phone while driving a car or riding a bicycle may be punishable by some regulations.
Use of electric devices transmitting radio waves in airplane is prohibited by law.


Regarding notations used in this document

- In this manual, keys are represented by simplified illustrations such as [C], [V], [Z].
Operations of tapping menu items/icons/buttons on the screen etc. are indicated as [(name of the item etc.)].

3


CE mark and FCC ID

1 Open the au Micro IC Card (LTE) slot cover, and insert a fingernail into the hook at the edge of the label tray, then pull it out straight.



au Micro IC Card (LTE)

Your phone number etc. is recorded in the au Micro IC Card (LTE). The product is compatible only with au Micro IC Card (LTE). Do not use the product with an au IC-card or micro au IC card switched from an au cell phone or au smartphone.



10

- Using 緊急通報メール (Emergency Rapid Mail)
Emergency Rapid Mail is a service that distributes Earthquake Early Warning or Tsunami Warning delivered from the meteorological bureau or Disaster and Evacuation Information delivered from the government or local public organization to all au cell phones in specified areas simultaneously.

Using au 災害対策 (au Disaster Countermeasure)

You can use 災害用伝言板 (Disaster Message Board) service, 緊急通報メール (Emergency Rapid Mail) service that distributes 緊急地震速報 (Earthquake Early Warning), 災害・避難情報 (Disaster and Evacuation Information) and 津波警報 (Tsunami Warning), and 災害用音声お届けサービス (Disaster Voice Messaging Service).

1 From the Home screen, [Menu] [au 災害対策 (au Disaster Countermeasure)] au 災害対策 (au Disaster Countermeasure) menu appears.

■ Using 災害用伝言板 (Disaster Message Board)

Disaster Message Board service enables you to register information of well-being from an area of distress via LTE NET in case of large-scale disaster such as earthquake with a seismic intensity of over 6 lower.

1 au 災害対策 (au Disaster Countermeasure) menu [災害用伝言板 (Disaster Message Board)]

- Information
To register information of well-being, E-mail address (~ezweb.ne.jp) is required. Set up E-mail address beforehand.

4

Attaching/removing the au Micro IC Card (LTE)

Before attaching/removing the au Micro IC Card (LTE), make sure to turn off the product and remove the battery cover and battery pack. Do not attach the AC adapter.

- Information
Note the following points, otherwise handling the au Micro IC Card (LTE) may cause malfunction or damage.
Do not touch the IC (metal) part of the au Micro IC Card (LTE) or the IC card terminal inside the product.
Insert in the correct direction.
Do not use force to attach or remove.
Do not lose the au Micro IC Card (LTE) after it has been removed.

■ Attaching the au Micro IC Card (LTE)

1 Hook the projection (1) of the tray with your fingernail and slide the tray straight out, then insert the au Micro IC Card (LTE) with IC (metal) side facing down into the tray and press the tray with the card all the way. Insert au Micro IC Card (LTE) with the notch facing out.



11

2 Insert the USB plug of the microUSB cable into the USB port of a PC
Notification LED lights on the product.
When a confirmation screen for installation of PC Companion software appears on the product, tap "Skip".
When a screen for new hardware detection etc. appears on the PC, select "Cancel".
3 When charging is complete, remove the microUSB plug of the microUSB cable from the product and close the microUSB connection terminal cover firmly
4 Remove the USB plug of the microUSB cable from the USB port of the PC

- Information
Installation of MTP driver to a PC is required to charge the product with a Microsoft Windows XP PC, since "USB connection mode" is set to "Media transfer mode (MTP)" by default. Install Windows Media Player 10 or later to install MTP driver.

■ Charging with a PC

The followings describe charging procedure by connecting the product to chargeable USB port on a PC using the microUSB cable of Sony Mobile AC adapter 05 (sold separately).

1 Open the microUSB connection terminal cover and insert the microUSB plug of the microUSB cable, with the printed side (→) facing up, straight into the microUSB connection terminal of the product

17

- 1 au 災害対策 (au Disaster Countermeasure) menu [緊急通報メール (Emergency Rapid Mail)]
Information
Reception of Emergency Rapid Mail is notified by a special warning tone. It is not possible to change the warning tone.
Earthquake Early Warning may not arrive before strong tremors in areas near the epicenter.
Tsunami Warning is a major tidal wave/seismic sea wave notification delivered from the meteorological bureau to the area including target coast.

1 au 災害対策 (au Disaster Countermeasure) menu [緊急通報メール (Emergency Rapid Mail)]

- Information
Disaster and Evacuation Information is a service that distributes bulletins concerning residents' safety including evacuation advisories, evacuation orders and other warnings issued by the national and local governments.
The service is available only in Japan (it cannot be used overseas).
No information fee or communication charge is required for receiving Emergency Rapid Mail.
KDDI is not liable for damages suffered by customers resulting from the service's information, lack or delay in the information caused by transmission or system breakdowns, or other events that are outside the responsibility of KDDI.

5

- Refer to the Japan Meteorological Agency web page for details about distribution of Earthquake Early Warning. http://www.jma.go.jp/
You cannot receive Emergency Rapid Mail when your cell phone is turned off or during a call.
Emergency Rapid Mail may not be received when your cell phone is communicating such as while sending/receiving SMS/e-mail or using the browser, or if you are in a place where signal does not reach even in the service area (e.g. in a tunnel, basement) or in a place with a poor reception.
You cannot receive the Emergency Rapid Mail that the reception is failed.
This delivery system is different from Earthquake Early Warning provided through TV, radio, or other communication procedures, which means that the time the Earthquake Early Warning arrives may vary.
Information from someplace other than your current location may be received.

■ Using 災害用音声お届けサービス (Disaster Voice Messaging Service)

Disaster Voice Messaging Service is a service which allows you to record your voice and send someone you want to inform your well-being in case of a large-scale disaster.

1 au 災害対策 (au Disaster Countermeasure) menu [災害用音声お届けサービス (Disaster Voice Messaging Service)]

- Information
Sending/Receiving voice messages is available only via LTE/3G network. Turn off wireless LAN (Wi-Fi®) and then use it.
Voice message can be recorded for up to 30 seconds.
Voice messages cannot be saved or played if the product does not have available memory.

6

Attaching/Removing microSD memory card

Before attaching/removing the microSD memory card, make sure to turn off the product and remove the battery cover and the battery pack. Do not attach the AC adapter.

■ Attaching microSD memory card

1 Confirm the orientation of the microSD memory card and insert it in the direction of the arrow. Insert the SD memory card with contact side down.

2 Attach the battery pack and the battery cover, and press each tab to close firmly

■ Removing au Micro IC Card (LTE)

1 Hook the projection of the tray with your fingernail and slide the tray straight out, then while pressing the au Micro IC Card (LTE) with tip of your finger, slide it out
2 Press the tray all the way into the end, and attach the battery pack and the battery cover, and press each tab to close firmly

- 2 Attach the battery pack and the battery cover, and press each tab to close firmly
Information
Insert a microSD memory card in the appropriate direction. Inserting a microSD memory card forcefully into the slot could result in failure to remove the microSD memory card or damage.

12

service etc., from the Home screen, [Menu] [au Easy Setting].

Screen Lock

When the screen lock is set, the backlight turns off to avoid the keys and touch panel from false operations.
When the specified time elapses, the product's screen backlight turns off automatically and screen lock is activated.

1 While the screen is displayed, [C]

Turning on (Initial settings)

Turning the power on

- 1 [C] (over 1 sec)
The product vibrates and after a while the unlock screen appears.
2 Swipe the screen up or down

■ Turning the power off

- 1 [C] (over 1 sec)
2 [Power off] [OK]

- Information
Press [C] for over 1 second and long-touch "Power Off" → [OK] to restart product.

Initial settings

When you turn on the product for the first time, swipe (flick) the screen up or down to unlock screen lock and follow the onscreen instructions to set language, functions, service, etc. For details, refer to "Setting Guide".

- Information
Setup items can be set or changed later as required. To change the language later, from the Home screen, [Menu] [Settings] [言語と入力 (Language & input)] [地域/言語 (Language)]. To make settings, from the Home screen, [Menu] [Settings] [Setup guide]. To make settings for au

18

14

15

16

20

