



# CHCNAV i83Pro GNSS

## User Guide



Make your work more efficient

# Table of Content

<b>Table of Content</b> .....	<b>2</b>
<b>Preface</b> .....	<b>5</b>
Copyright 2024 .....	5
Trademarks .....	5
Safety Warnings .....	5
FCC Interference Statement .....	5
CE Interference Statement .....	5
<b>1. Introduction</b> .....	<b>6</b>
1.1 Safety Information .....	6
1.2 Regulations and Safety .....	6
1.3 Technical Support .....	6
1.4 Disclaimer .....	7
1.5 Your Comments .....	7
<b>2. Getting Started with i83Pro</b> .....	<b>8</b>
2.1 About the Receiver .....	8
2.2 Parts of the Receiver .....	8
2.2.1 Front Panel .....	8
2.2.2 Lower Housing .....	9
2.2.3 Receiver Ports .....	10
2.3 Batteries and Power .....	10
2.3.1 Batteries .....	10
2.3.2 The Internal Battery .....	10
2.3.3 Battery Safe .....	11
2.4 Inserting SIM Card .....	11
2.5 Product Basic Supply Accessories .....	12
2.5.1 Base Kit Basic Supply .....	12
2.5.2 Rover Kit Basic Supply .....	13
2.6 Connecting to an Office Computer .....	13
2.7 Connecting to a Controller .....	14
2.7.1 Connecting via Wi-Fi with Landstar Software .....	14
2.7.2 Connecting via Bluetooth with Landstar Software .....	15
2.8 Downloading Logged Data .....	16
2.8.1 FTP Download .....	16
2.8.2 Web Server Download .....	17
2.8.3 USB Download .....	18
<b>3. Equipment Setup and Operation</b> .....	<b>20</b>
3.1 Post-processing Base Station Setup .....	20
3.2 Real-Time Base Station Setup .....	21
3.2.1 Internal Cellular or UHF .....	21
3.2.2 External UHF .....	22
3.3 Real-Time Rover Station Setup .....	23

3.4 Working with the Tilt Compensation .....	24
3.4.1 Operation Steps for first IMU initialization .....	24
3.4.2 Notes of using tilt measurement .....	26
<b>4. Configuring Through a Web Browser .....</b>	<b>27</b>
4.1 Status Menu .....	28
4.1.1 Position Submenu .....	28
4.1.2 Activity Submenu .....	29
4.1.3 Google Map Submenu .....	29
4.2 Satellites Menu .....	30
4.2.1 Tracking Table Submenu .....	30
4.2.2 Tracking Info. Table Submenu .....	31
4.2.3 Tracking Skyplot Submenu .....	31
4.2.4 Satellite Activation Submenu .....	32
4.3 Receiver Configuration Menu .....	32
4.3.1 Description .....	33
4.3.2 Antenna Configuration Submenu .....	33
4.3.3 Reference Station Settings Submenu .....	33
4.3.4 Receiver Reset Submenu .....	35
4.3.5 Languages Submenu .....	35
4.3.6 User Management Submenu .....	35
4.3.7 HCPPP Settings .....	36
4.4 Data Recording Menu .....	36
4.4.1 Log Settings Submenu .....	36
4.4.2 FTP Push Settings Submenu .....	38
4.4.3 FTP Push Log Submenu .....	39
4.4.4 Data Download Submenu .....	39
4.5 IO Settings Menu .....	40
4.6 Network Setting Menu .....	45
4.6.1 Description Submenu .....	45
4.6.2 Mobile Network Setting Submenu .....	46
4.6.3 Email Alarm Submenu .....	46
4.6.4 HTTP Submenu .....	47
4.6.5 HTTPS Submenu .....	47
4.6.7 FTP Service Submenu .....	48
4.7 Module Setting Menu .....	48
4.7.1 Description Submenu .....	48
4.7.2 WiFi Submenu .....	49
4.7.3 Bluetooth Settings Submenu .....	49
4.7.4 Radio Settings Submenu .....	49
4.7.5 IMU Setting .....	49
4.8 Firmware Menu .....	50
4.8.1 Firmware Info Submenu .....	50

4.8.2 Hardware Version Submenu .....	50
4.8.3 Config File Submenu .....	51
4.8.4 System Log Download Submenu .....	51
4.8.5 User Log Submenu .....	51
4.8.6 Firmware Update Submenu .....	52
4.8.7 GNSS Board Upgrade Submenu .....	52
4.8.8 GNSS Registration Submenu .....	53

## Preface

### Copyright 2024

CHC | Shanghai Huace Navigation Technology Ltd. All rights reserved. The CHC are trademark of Shanghai Huace Navigation Technology Limited. All other trademarks are the property of their respective owners.

### Trademarks

All product and brand names mentioned in this publication are trademarks of their respective holders.

### Safety Warnings

The Global Positioning System (GPS) is operated by the U.S. Government, which is solely responsible for the accuracy and maintenance of the GPS network. Accuracy can also be affected by poor satellite geometry and obstructions, like buildings and heavy canopy.

### FCC Interference Statement

This equipment has been designed to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules in the Portable Mode. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

Operation is subject to the following two conditions: (1) this device may not cause harmful interference and (2) this device must accept any interference received, including interference that may cause undesired operation.

### CE Interference Statement

Declaration of Conformity: Hereby, Shanghai Huace Navigation Technology Ltd. declares that this i83Pro is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU. A copy of the Declaration of conformity can be found at Shanghai Huace Navigation Technology Ltd.



## 1. Introduction

The i83Pro GNSS Receiver User Guide describes how to set up and use the CHC i83Pro GNSS receiver. In this manual, “the receiver” refers to the i83Pro GNSS receiver unless otherwise stated. Even if you have used other Global Navigation Satellite Systems (GNSS) products before, CHC recommends that you spend some time reading this manual to learn about the special features of this product. If you are not familiar with GNSS, go to [www.chcnav.com](http://www.chcnav.com) for an interactive look at CHC and GNSS.

### 1.1 Safety Information

An absence of specific alerts does not mean that there are no safety risks involved.

A Warning or Caution information is intended to minimize the risk of personal injury and/or damage to the equipment.



**WARNING** - A Warning alerts you to a potential misused or wrong setting of the equipment.



**CAUTION** - A Caution alerts you to a possible risk of serious injury to your person and/or damage to the equipment.

### 1.2 Regulations and Safety

The receivers contain a built-in wireless modem for signal communication through Bluetooth® wireless technology or through external communication datalink. Regulations regarding the use of the wireless modem vary greatly from country to country. In some countries, the unit can be used without obtaining an end-user license. However, in some countries, the administrative permissions are required. For license information, consult your local dealer. Bluetooth® operates in license-free bands.

Before operating a i83Pro GNSS receiver, determine if authorization or a license to operate the unit is required in your country. It is the responsibility of the end-user to obtain an operator's permit or license for the receiver for the location or country of use.

This receiver is designed to withstand the rough environment that typically occurs in the field. However, the receiver is high-precision electronic equipment and should be treated with reasonable care.



**CAUTION** - Operating or storing the receiver outside the specified temperature range will cause irreversible damage.

### 1.3 Technical Support

If you have a problem and cannot find the information you need in this manual or CHC website ([www.chcnav.com](http://www.chcnav.com)), contact your local CHC dealer from which you purchased the receiver(s).

If you need to contact CHC technical support, please contact us by email ([support@chcnav.com](mailto:support@chcnav.com)) or Skype (chc\_support) or Knowledge Base (<https://support.chcnav.com/portal/en/kb>).

## 1.4 Disclaimer

Before using the receiver, please make sure that you have read and understood this User Guide, as well as the safety information. CHC holds no responsibility for the wrong operation by users and for the losses incurred by the wrong understanding about this User Guide. However, CHC reserves the rights to update and optimize the contents in this guide regularly. Please contact your local CHC dealer for new information.

## 1.5 Your Comments

Your feedback about this user guide will help us to improve it in future revision. Please email your comments to [support@chcnav.com](mailto:support@chcnav.com).

## 2. Getting Started with i83Pro

### 2.1 About the Receiver

The new CHCNAV i83Pro GNSS receiver offers integrated IMU-RTK technology to provide a robust and accurate GNSS positioning in any circumstances. Unlike the standard MEMS based GNSS receivers, the i83Pro GNSS IMU-RTK combines state-of-the-art GNSS RTK engine, calibration-free professional IMU sensor and advanced GNSS tracking capabilities. Survey projects are achieved with high productivity and reliability pushing the boundaries of conventional GNSS RTK survey.

The LCD panel enables user to check satellite-tracking status, internal battery status, Wi-Fi status, working mode, data logging status and basic receiver information. Bluetooth and Wi-Fi technology provides cable-free communication between the receiver and controller.

The receiver can be used as the part of an RTK GNSS system with CHC LansStar software. Moreover, user can download the GNSS data that recorded in the internal memory of receiver to a computer.

To configure the receiver for performing a wide variety of functions, you can use the web interface by connecting the receiver with PC or smartphone through Wi-Fi.

### 2.2 Parts of the Receiver

The operating controls are all located on the front panel. SIM card slot is on the backside. Serial ports and connectors are located on the bottom of the unit.

#### 2.2.1 Front Panel

The following figure shows a front view of the receiver.



The front panel contains two indicator LEDs and two buttons.



Name	Description
Correction LED (Yellow/Green)	<ul style="list-style-type: none"> <li>Indicates whether the receiver is transmitting/receiving differential data.</li> <li>As a Base station: successfully transmitting differential data, flash yellow light.</li> <li>As a Rover station: successfully receiving differential data from Base station will flash yellow light when it is single or float, flash green light when it is fixed.</li> </ul>
Satellite LED (Blue)	<ul style="list-style-type: none"> <li>Shows the number of satellites that the receiver has tracked.</li> <li>When the receiver is searching satellites, the blue LED flashes once every 5 seconds.</li> <li>When the receiver has tracked N satellites, the blue LED will flash N times every 5 seconds.</li> </ul>
Fn button (White)	<ul style="list-style-type: none"> <li>Move to next line of the menus or options.</li> <li>Move to next character of the value that you want to make change.</li> <li>Cancel the change you make on a function.</li> </ul>
Power button (White)	<ul style="list-style-type: none"> <li>Works as a Power button:</li> <li>Press and hold this button for 3 seconds to turn on or turn off the receiver.</li> <li>Works as a Confirm button</li> <li>Hold Fn button and press this button for 5 times continuously to reset the mainboard.</li> </ul>

## 2.2.2 Lower Housing

The lower housing contains one SIM card slot, one TNC radio antenna connector, one communication and power port and one USB type C communication and power port.



### 2.2.3 Receiver Ports

Port	Name	Description
	IO port	<ul style="list-style-type: none"> <li>This port is a 7-pin LEMO connector that supports RS-232 communications and external power input.</li> <li>Users can use a 7-pin cable to transmit differential data to an external radio.</li> </ul>
	USB port	<ul style="list-style-type: none"> <li>This port is a type-C USB connector that supports USB communications.</li> <li>Users can use USB Cable supplied with the system to download the logged data to a computer.</li> </ul>
	Radio antenna connector	<ul style="list-style-type: none"> <li>Connect a radio antenna to internal radio of the receiver. And this connector is not used if you are using an external radio.</li> </ul>

## 2.3 Batteries and Power

### 2.3.1 Batteries

The receiver has an built-in non-removable Lithium- ion battery.

### 2.3.2 The Internal Battery

The rechargeable Lithium-ion battery is supplied partially charged.



**WARNING** – Charge and use the rechargeable Lithium-ion battery only in strict accordance with the instructions. Charging or using the battery in unauthorized equipment can cause an explosion or fire and can result in personal injury and/or equipment damage.

To prevent injury or damage:

- Do not charge or use the battery if it appears to be damaged or leaking.

- Charge the Lithium-ion battery only in a CHC product that is specified to charge it. Be sure to follow all instructions that are provided with the battery charger.
- Discontinue charging a battery that gives off extreme heat or a burning odor.
- Use the battery only in CHC equipment that is specified to use it.
- Use the battery only for its intended use and according to the instructions in the product documentation.

### 2.3.3 Battery Safe



**WARNING** – Do not damage the rechargeable Lithium-ion battery. A damaged battery can cause an explosion or fire and can result in personal injury and/or property damage.

To prevent injury or damage:

- Do not use or charge the battery if it appears to be damaged. Signs of damage include, but are not limited to discoloration, warping, and leaking battery fluid.
- Do not expose the battery to fire, high temperature, or direct sunlight.
- Do not immerse the battery in water.
- Do not use or store the battery inside a vehicle under hot weather condition.
- Do not drop or puncture the battery.
- Do not open the battery or short-circuit its contacts.



**WARNING** – Avoid contact with the rechargeable Lithium-ion battery if it appears to be leaking. Battery fluid is corrosive and contact with it can result in personal injury and/or property damage.

To prevent injury or damage:

- If the battery leaks, avoid with the battery fluid.
- If battery fluid gets into your eyes, immediately rinses your eyes with clean water and seek medical attention. Please do not rub your eyes!
- If battery fluid gets onto your skin or clothing, immediately use clean water to wash off the battery fluid.

## 2.4 Inserting SIM Card

Open the SIM card slot cover.

Insert the SIM card with the contacts facing upward, as indicated by the SIM card icon next to the SIM card slot.

Close the cover to prevent water immersion.

To eject the SIM card, slightly push it in to trigger the spring-loaded release mechanism.

Insert the SIM card with the contacts facing upward, as indicated by the SIM card icon next to the SIM card slot.

To eject the SIM card, slightly push it in to trigger the spring-loaded release mechanism.

Tip – The SIM card is provided by your cellular network service provider.

## 2.5 Product Basic Supply Accessories

### 2.5.1 Base Kit Basic Supply

Item	Picture
i83Pro GNSS Receiver	
UHF Bar Antenna (410-470 MHz)	
Power Adapter	
USB Type-C Cable	
H.I. Tape	
Extension pole	
Tribrach with optical plummet	
Auxiliary H.I. Tool	
Transport Hard Case	


## 2.5.2 Rover Kit Basic Supply

Item	Picture
i83Pro GNSS Receiver	
UHF Bar Antenna (410-470 MHz)	
Power Adapter	
USB Type-C Cable	
2M Range Pole/bag	
Auxiliary H.I. Tool	
Transport Hard Case	

## 2.6 Connecting to an Office Computer

The receiver can be connected to an office computer for serial data transfer or settings via a USB Type-C Cable. Before you connect to the office computer, ensure that the receiver is powered on by internal battery or external power.

The following figure shows how to connect to the computer for serial data transfer or settings:




## 2.7 Connecting to a Controller

### 2.7.1 Connecting via Wi-Fi with Landstar Software

Turn on the controller → run Landstar → go to **Config** main menu → tap **Connect**.

In the Connect screen, select CHC for the Manufacture field, i83Pro for Device Type field, **WIFI** for Connection Type field.




Tap the Wireless Lan icon on the right side to select the hot spot → Switch on the WiFi module by the top switch → select the target device in the list.



Tap **Connect** to link to the hot spot.


Tap the **Connect** button to build the connection.



## 2.7.2 Connecting via Bluetooth with Landstar Software


Turn on the controller → run Landstar → go to **Config** main menu → tap **Connect**.

In the Connect screen, select **CHC** for the Manufacture field, **i83Pro** for Device Type field, **Bluetooth** for Connection Type field.



Tap the **Bluetooth Manager** and turn on the **Bluetooth** function to search Bluetooth device around → select the target device in the list → Tap back button → select the target device in the Bluetooth manager list.

Tap the **Connect** button to build the connection.



## 2.8 Downloading Logged Data

Data logging involves the collection of GNSS measurement data over a period at a static point or points, and subsequent post-processing of the information to accurately compute baseline information. Data logging using receivers requires access to suitable GNSS post-processing software such as the CHC Geomatics Office (CGO) Software.


### 2.8.1 FTP Download

The procedures of downloading logged data through FTP are as follows:


- (1) Switch on the receiver, search its Wi-Fi in the computer and connect.
- (2) After the successful connection, open the file manager in the computer and input "ftp:\\192.168.1.1" in the address box.



- (3) Input user name and password, the default user name and password are "ftp".




(4) Double click the folder “repo\_receiver SN” (take 3411955 as example), you will see 9 folders. The “push\_log” folder is used to save the log files, and the other 8 folders represent different logging sessions and are used for store static data.




(5) Double click the folder that you have configured to store the static data, you will see the folder(s) created by the i83Pro system automatically and named by the date which is decide by GPS time when you start to log data.



(6) Select the destination folder and double click it, two folders named as different data format (hcn and rinex) will be displayed.



(7) Select the data format that you configured to save the static data, you will find the static raw data.



Notes: For hcn files, the name of the file is represented as XX XXXXDD D NN, where XXXXX X is

the SN of the receiver, D DD is day of year, and NN is the recording session.



WARNING – The static data will be saved in the first logging session, the “record\_1” folder, by default. Old files will be deleted if the storage space is full. If you configure not to auto delete old files when the memory is low, the receiver will stop data logging.

## 2.8.2 Web Server Download

The procedures of downloading logged data through web server refer to 5.4.4 Data Download Submenu.


### 2.8.3 USB Download

The procedures of downloading logged data in the receiver are as follows:


(1) Switch on the receiver and connect it with a computer by Type-C Cable. After the successful connection, a removable disk named as the Serial Number (SN) of the receiver will appear on the computer.



(2) Double click the removable disk and you will see the folder named as "repo".



(3) Double click this folder, you will see 9 folders. The "push\_log" folder is used to save the log files, and the other 8 folders represent different logging session and are used for store static data.




(4) Double click the folder that you have configured to store the static data, you will see the folder(s) created by the i83Pro system automatically and named by the date which is decide by GPS time when you start to log data.



(5) Select the destination folder and double click it, and then two folders named as different data format (hcn and rinex) will be displayed.



(6)Select the data format that you have configured to save the static data, you will find the static raw data.



Tip – For hcn files, the name of the file is represented as XXX XXXD DD NN, where XXX XXX is the SN of the receiver, D DD is day of year, and NN is the recording session.




**WARNING** – The static data will be saved in the first logging session, the “record\_1” folder, by default. Old files will be deleted if the storage space is full. If you configure not to auto delete old files when the memory is low, the receiver will stop data logging.

### 3. Equipment Setup and Operation

#### 3.1 Post-processing Base Station Setup

For good performance, the following base station setup guidelines are recommended:

##### Components:



No.	Name
a	i83Pro GNSS receiver
b	Extension pole (30 cm)
c	Tribrach adaptor
d	Tribrach w/ Opti
e	Aluminum tripod

##### Steps:

- 1) Put tripod in the target position, center and level it roughly.
- 2) Place and lock the tribrach in the tripod.
- 3) Screw the receiver onto the tribrach.
- 4) Center and level the receiver more precisely.
- 5) Connect the receiver to external battery by using external power cable if necessary.
- 6) Connect the receiver to external storage disk by using USB cable if necessary.
- 7) Turn on the receiver by pressing the power button for 3 s.
- 8) Measure the antenna height by using H.I. tape and auxiliary H.I. tool.

9)Press the function button to select Data to start recording static raw.

**If work with a data controller:**

1)Switch on the data controller and connect it to the receiver.


2)Use software to configure the receiver as static mode.

## 3.2 Real-Time Base Station Setup

### 3.2.1 Internal Cellular or UHF

For good rover operation, the following base station setup guidelines are recommended:

**Components:**



No.	Name
a	i83Pro GNSS receiver
b	UHF whip antenna
c	Extension pole (30 cm)
d	Tribrach adaptor
e	Tribrach w/ Opti
f	Aluminum tripod
g	Micro SIM card (12 mm x 15 mm)

**Steps:**

1)Put tripod in the target position, center and level it roughly.

2)Place and lock the tribrach in the tripod.

**If work as a cellular base station, the SIM card need to be inserted**

1)Screw the receiver onto the tribrach.

2)Center and level the receiver more precisely.

If work as a **UHF base station**, the UHF whip antenna need to be connected to the receiver.

- 1) Connect the receiver to external battery by using external power cable if necessary.
- 2) Connect the receiver to external storage disk by using USB cable if necessary.
- 3) Turn on the receiver by pressing the power button for 3 s.
- 4) Measure the antenna height by using H.I. tape and auxiliary H.I. tool.
- 5) Switch on the data controller and connect it to the receiver.
- 6) Use software to configure the receiver as cellular base or UHF base mode.

### 3.2.2 External UHF

For good performance, the following base station setup guidelines are recommended:

#### Components:



No.	Name
a	i83Pro GNSS receiver
b	Extension pole (30 cm)
c	Tribrach adaptor
d	Tribrach w/ Opti
e	GPS to datalink cable (power cable)
f	Aluminum tripod
h	Whip antenna
i	3 m cable for datalink antenna 3m

j	Pole mounting
k	External 410-470 datalink

**Steps:**


- 1)Put tripod in the target position, center and level it roughly.
- 2)Place and lock the tribrach in the tripod.
- 3)Screw the receiver onto the tribrach.
- 4)Center and level the receiver more precisely.
- 5)Connect the receiver to external datalink by using GPS to datalink cable.
- 6)Hang the external datalink on the tripod leg.
- 7)Connect the receiver to external battery by using external power cable if necessary.
- 8)Connect the receiver to external storage disk by using USB cable if necessary.
- 9)Turn on the receiver by pressing the power button for 3 s.
- 10)Measure the antenna height by using H.I. tape and auxiliary H.I. tool.
- 11)Turn on the external datalink and configure it as need.

**If work with a data controller:**

- 1)Switch on the data controller and connect it to the receiver.
- 2)Use software to configure the receiver as cellular base or UHF base mode.

### 3.3 Real-Time Rover Station Setup

For good performance, the following rover station setup guidelines are recommended:

**Components:**

Name	
a	i83Pro GNSS receiver
b	whip antenna
c	2M range pole w/bag
d	Micro SIM card (12 mm x 15 mm)

### Steps:

Keep the receiver fully charged.

If work as a **cellular rover station**, the SIM card need to be inserted.

Screw the receiver onto the pole.

If work as a **UHF rover station**, the UHF whip antenna need to be connected to the receiver.

1) Turn on the receiver by pressing the power button for 3 s.

2) Switch on the data controller and connect it to the receiver.

3) Use software to configure the receiver as cellular rover or UHF rover mode.



4) Center and level the receiver more precisely.

5) Use software to start survey.


## 3.4 Working with the Tilt Compensation

### 3.4.1 Operation Steps for first IMU initialization



1. Open Landstar8-> Tap Survey-> Tap  to activate tilt measurement.



2. Hold the pole vertical for a while and shake according to the procedures in the interface to do initialization.



3. This icon  will appear when the initialization is successful.



4. Enter the Name and Antenna, then tap  , point will be collected and store to Points automatically.

5. When this icon  appears, the text will show "Tilt is not available, please measure in alignment" at the bottom of interface.



6.Tap  to close tilt compensation.

### 3.4.2 Notes of using tilt measurement

1. At the beginning of initialization, the pole height of the instrument should be the same as that antenna height in the software.

2. In the process of tilt measurement, if the controller shows that “Tilt is not available, please measure in alignment” (red), please shake RTK slightly from left to right or back to front until the reminder disappears.

3. The controller will prompt “Tilt is not available, please measure in alignment” when the receiver is stationary over 30 seconds or the pole hit the ground toughly.

4. The pole cannot be shaken when point is collected.

5. Initialization is required:

- when the RTK is turned on every time;
- when IMU module is turned on every time;
- when receiver drops at working;
- when the pole is tilted more than 65 degree;
- when the receiver is stationary more than 10 minutes;
- when the RTK rotates too fast on the matching pole (2 rounds per second);
- when the pole hit the ground toughly.

## 4. Configuring Through a Web Browser

Supported browsers:


➤ Google Chrome

➤ Microsoft Internet Explorer version 10, or higher To connect to the receiver through a web browser:

1. Turn on the Wi-Fi of the receiver.

2. Search the wireless network named as GNSS-XXXXXXX (the SN of your receiver) on your computer, and then establish the connection.

3. After the successful connection between your computer and the receiver, enter the IP address (192.168.1.1) of the receiver into the address bar of the web browser on your computer:



4. The web browser prompts you to enter a login account and password:




The default login account for the receiver is:

➤ Login Account: admin

➤ Password: password

Note – Tick remember me option, and then the browser will remember the Login Account and Password you entered.

5. Once you log in, the web page appears as follows:




This web page shows the configuration menus on the left of the browser window, and the setting on the right. Each configuration menu contains the related submenus to configure the receiver and monitor receiver performance.

This chapter describes each configuration menu.

To view the web page in another language, select the corresponding language name from the drop down list on the upper right corner of the web page.

Currently, seven languages are available:



## 4.1 Status Menu

This menu provides a quick link to review the receiver's position information, satellites tracked, runtime, current data log status, current outputs, available memory, and more.

### 4.1.1 Position Submenu

This page shows the relevant position information about the receiver's position solution which including the position, DOP values, satellites used and tracked, and the receiver clock information.

**Position**

Latitude: 31°9'57.36875055"(North)  
Longitude: 121°17'16.97717278"(East)  
Height: 35.999  
Type: Single

**DOP**

PDOP: 1.172767  
HDOP: 0.616858  
VDOP: 0.997431  
TDOP: 0.744274

**Satellite Used: 30Total**

GPS(7): 1,7,8,9,21,27,30  
GLONASS(5): 9,15,18,19,20  
BDS(10): 1,3,7,9,10,26,35,40,44,59  
GALILEO(6): 1,12,24,26,31,33  
SBAS(0):  
QZSS(2): 194,195

**Satellites Tracked: 45Total**

GPS(8): 1,7,8,9,16,21,27,30  
GLONASS(5): 9,15,18,19,20  
BDS(23): 1,2,3,4,5,6,7,8,9,10,12,16,24,26,29,35,38,39,40,44,45,59,60  
GALILEO(7): 1,9,12,24,26,31,33  
SBAS(0):  
QZSS(2): 194,195

**Receiver Clock**

GPS Week: 2194  
GPS Seconds: 379271

## 4.1.2 Activity Submenu

Lists several important items to help you understand how the receiver is being used and its current operating condition. Items include the identities of currently tracked satellites, internal and external storage usage rate, how long the receiver has been operational, state of the internal battery, power source state, files being logged, and data streams being output. With this information, it is easy to tell exactly what functions the receiver is performing.

**Status**

- ▶ Position
- Activity**
- ▶ Google Map

**Activity**

**Satellites Track: 46Total**

GPS(8): 1,7,8,9,16,21,27,30  
GLONASS(5): 9,15,18,19,20  
BDS(23): 1,2,3,4,5,6,7,8,9,10,12,16,24,26,29,35,38,39,40,44,45,59,60  
GALILEO(7): 1,9,12,24,26,31,33  
SBAS(0):  
QZSS(3): 193,194,195

**Activity Status**

Current Time: 2022-01-27 09:21:39 (UTC)  
Operation Duration: 00-00-00 01:20:50  
Internal Storage: 

4.85%

 368MB/7595MB  
External Storage: 

0%


 Disconnected  
External Power: Disconnected  
Battery: 

46%

Type	Description	Output
1	RTK Client	211.144.116.5.2102
2	TCP/UDP_Client1/NTRIP Server1	192.168.3.18.9900
3	TCP/UDP_Client2/NTRIP Server2	192.168.3.18.9901
4	TCP/UDP_Client3/NTRIP Server3	192.168.3.18.9902
5	TCP/UDP_Client4/NTRIP Server4	192.168.3.18.9903
6	TCP/UDP_Client5/NTRIP Server5	192.168.3.18.9904
7	TCP/UDP_Client6/NTRIP Server6	192.168.3.18.9905
8	TCP Server/NTRIP Caster1	9901
9	TCP Server/NTRIP Caster2	9902
10	TCP Server/NTRIP Caster3	9903
11	TCP Server/NTRIP Caster4	9904
12	Serial Port	9600
13	Bluetooth	GNSS-3200193
14	Radio	460.0500MHz

## 4.1.3 Google Map Submenu

Tap this submenu to show the location of the receiver on Google map.



## 4.2 Satellites Menu

Use the Satellites menu to view satellite tracking details and enable/disable GPS, GLONASS, BDS and Galileo constellations. These menus include tabular and graphical displays to provide all required information on satellite tracking status.



### 4.2.1 Tracking Table Submenu

Provides the status of satellites tracked in general, such as the satellite ID, satellite type, attitude angle, azimuth angle, L1 SNR, L2 SNR, L5 SNR and enable/disable status of each one.

Tracking Table										
All	<input checked="" type="radio"/> GPS	<input type="radio"/> GLONASS	<input type="radio"/> BDS	<input type="radio"/> GALILEO	<input type="radio"/> SBAS	<input type="radio"/> QZSS				
SV	Type	Elevation Angle	Azimuth Angle	L1 SNR	L2 SNR	L5 SNR	B1C SNR	B2A SNR	Enabled	
3	GPS	21	282	40.000	40.850	30.880	0.000	0.000	Yes	▲
4	GPS	15	318	40.030	36.800	27.800	0.000	0.000	Yes	
16	GPS	45	242	44.820	39.450	0.000	0.000	0.000	Yes	
26	GPS	74	318	48.720	43.430	36.160	0.000	0.000	Yes	
27	GPS	12	188	34.690	35.890	26.250	0.000	0.000	Yes	
29	GPS	23	50	41.370	36.580	0.000	0.000	0.000	Yes	
31	GPS	55	44	45.450	41.970	0.000	0.000	0.000	Yes	
32	GPS	35	149	42.840	38.490	30.140	0.000	0.000	Yes	
1	GLONASS	52	211	41.760	46.170	0.000	0.000	0.000	Yes	
2	GLONASS	40	313	47.100	46.320	0.000	0.000	0.000	Yes	
8	GLONASS	14	174	36.530	43.730	0.000	0.000	0.000	Yes	
12	GLONASS	41	300	45.760	49.200	0.000	0.000	0.000	Yes	
21	GLONASS	22	94	37.800	44.160	0.000	0.000	0.000	Yes	
1	BDS	45	140	39.830	42.710	44.970	0.000	0.000	No	
2	BDS	35	235	35.420	43.410	42.250	0.000	0.000	No	
3	BDS	50	199	40.270	44.410	43.470	0.000	0.000	Yes	


#### 4.2.2 Tracking Info. Table Submenu

The following figure is an example of satellite track diagram page. Users can determine the satellite types and the corresponding SNR of L-band carriers to be displayed in any combination.



#### 4.2.3 Tracking Skyplot Submenu

The following figure is an example of Skyplot page.




#### 4.2.4 Satellite Activation Submenu

Use this menu to enable or disable satellites.


Satellite Id	Enable	Satellite Id	Enable
1	<input checked="" type="checkbox"/>	2	<input checked="" type="checkbox"/>
3	<input checked="" type="checkbox"/>	4	<input checked="" type="checkbox"/>
5	<input checked="" type="checkbox"/>	6	<input checked="" type="checkbox"/>
7	<input checked="" type="checkbox"/>	8	<input checked="" type="checkbox"/>
9	<input checked="" type="checkbox"/>	10	<input checked="" type="checkbox"/>
11	<input checked="" type="checkbox"/>	12	<input checked="" type="checkbox"/>
13	<input checked="" type="checkbox"/>	14	<input checked="" type="checkbox"/>
15	<input checked="" type="checkbox"/>	16	<input checked="" type="checkbox"/>
17	<input checked="" type="checkbox"/>	18	<input checked="" type="checkbox"/>
19	<input checked="" type="checkbox"/>	20	<input checked="" type="checkbox"/>
21	<input checked="" type="checkbox"/>	22	<input checked="" type="checkbox"/>
23	<input checked="" type="checkbox"/>	24	<input checked="" type="checkbox"/>
25	<input checked="" type="checkbox"/>	26	<input checked="" type="checkbox"/>
27	<input checked="" type="checkbox"/>	28	<input checked="" type="checkbox"/>

### 4.3 Receiver Configuration Menu

Use this menu to configure settings such as the antenna type and height, elevation mask and PDOP setting, the reference station coordinates, receiver resetting and web interface language:




### 4.3.1 Description




This submenu shows the receiver information and reference station information, including antenna related information, elevation mask angle, reference station work mode and position, etc.

### 4.3.2 Antenna Configuration Submenu

Use this screen to configure all the items related to the GNSS antenna. You must enter the correct values for all antenna-related fields, because the choices you make affect the accuracy for logged data and broadcast correction data significantly:



### 4.3.3 Reference Station Settings Submenu




Use this screen to configure settings such as the station coordinates and the broadcast station identifiers. You must enter accurate information in these fields, as this data affects the accuracy of logged data files and broadcast correction data significantly:

For Reference Station Mode, there are three modes available:

**1. Auto Rover:** The receiver will serve as a rover after this mode is enabled, and then receive correction data through the working mode set last time.

**2. Auto Base:** The receiver will serve as a base after this mode is enabled, and then broadcast correction data based on coordinate inputted by user or obtained through autonomous positioning automatically.



**3. Manual Base:** The receiver will serve neither as a base nor a rover after this mode is enabled. Users need to configure the receiver manually.

For Reference Latitude and Reference Longitude:

Reference Station Mode:	Manual Base
Base Station Name:	9999690
Base Station ID:	9999690
Reference Latitude:	31 ° 9' 34.56836444" N
Reference Longitude:	121 ° 10' 42.49352449" E
Reference Height:	50.4336

Sample for Average	
Positioning Constraint:	<input checked="" type="radio"/> Single Solution Coordinates <input type="radio"/> Fixed Solution Coordinates
Sampling Amount:	300 0%
<input type="button" value="Start"/>	<input type="button" value="Stop"/>
<input type="button" value="Save"/>	

There are mainly three methods to enter the reference coordinates and shown as follows:

**1. Acquire Current Position:** Click this button to acquire current position obtained through autonomous positioning automatically.

**2. Manual Input:** Manually input the coordinate of a control point.

**3. From CORS:** After the receiver logging in CORS, the software can record the coordinate of current position based on fix solution.

For **Sample for Average:**

Users can determine the positioning limit and sampling amount. The positioning limit falls

into two types:

**1. Single Solution Coordinates:** Collect the coordinates of receiver obtained through autonomous positioning.


**2. Fixed Solution Coordinates:** Only collect coordinates of receiver with a fixed solution.

After the configuration of positioning limit and sampling amount, click  to carry out sampling and averaging → the progress bar will show the progress → the result will be served as the coordinate of current position.

If users need to save the changes, please tap  button.

#### 4.3.4 Receiver Reset Submenu

Use this screen to completely or partially reset the receiver:




#### 4.3.5 Languages Submenu

Use this screen to select the web interface language:



#### 4.3.6 User Management Submenu



The screenshot shows a 'User Management' interface with a table:

ID	User Name	Password
1	admin	*****
2	admin1	*****
3	admin2	*****

Action buttons at the top:

- Add
- Save
- Delete
- Modify Anti-theft password


### 4.3.7 HC PPP Settings



HC PPP Range: 5min


## 4.4 Data Recording Menu

Use the Data Logging menu to set up the receiver to log static GNSS data and to view the logging settings. You can configure settings such as observable rate, recording rate, continuous logging limit, and whether to auto delete old files when memory is low. This menu also provides the controls for the FTP push feature:



### 4.4.1 Log Settings Submenu

Here shows the data logging status, including internal and external storage usage and data logging status of each session. Also, users can configure the data logging settings for each session, including recording name, store location, storage limit, store formats, start time, etc.



**Store Info**


	Position	Total Storage	Storage Available
1	Internal Storage	28786MB	27904MB
2	External Storage	0MB	0MB

**Record Info**


Attention: Total assigned storage size of 8 threads should be less than 27GB. It will stop recording when the storage is full.

Recording Numbe	File Name	Activated	Log Status	Setting Parameter	Switch	Clear Data
1	record1	No	Not Recording	<input type="button" value="Modify"/> <input type="button" value="Detail"/>	<input type="button" value="ON"/> <input type="button" value="OFF"/>	<input type="button" value="Clear"/>
2	record2	No	Not Recording	<input type="button" value="Modify"/> <input type="button" value="Detail"/>	<input type="button" value="ON"/> <input type="button" value="OFF"/>	<input type="button" value="Clear"/>
3	record3	No	Not Recording	<input type="button" value="Modify"/> <input type="button" value="Detail"/>	<input type="button" value="ON"/> <input type="button" value="OFF"/>	<input type="button" value="Clear"/>
4	record4	No	Not Recording	<input type="button" value="Modify"/> <input type="button" value="Detail"/>	<input type="button" value="ON"/> <input type="button" value="OFF"/>	<input type="button" value="Clear"/>
5	record5	No	Not Recording	<input type="button" value="Modify"/> <input type="button" value="Detail"/>	<input type="button" value="ON"/> <input type="button" value="OFF"/>	<input type="button" value="Clear"/>
6	record6	No	Not Recording	<input type="button" value="Modify"/> <input type="button" value="Detail"/>	<input type="button" value="ON"/> <input type="button" value="OFF"/>	<input type="button" value="Clear"/>
7	record7	No	Not Recording	<input type="button" value="Modify"/> <input type="button" value="Detail"/>	<input type="button" value="ON"/> <input type="button" value="OFF"/>	<input type="button" value="Clear"/>
8	record8	No	Not Recording	<input type="button" value="Modify"/> <input type="button" value="Detail"/>	<input type="button" value="ON"/> <input type="button" value="OFF"/>	<input type="button" value="Clear"/>

To edit the settings of each session, click the **Modify** button to the right of the required session, and then the Recording Edit screen appears:



Click advanced to see more settings.



In this screen, you can configure all the data logging parameters, and determine whether the recording files will be affected by the FTP Push. The parameters are mainly as follows:

- **Auto Record:** on or off.
- **Sample Interval:** Select the observable rate from the dropdown list.
- **Elevation Mask:** Enter the elevation mask.
- **Duration Time:** Set the duration of data logging.
- **Site Name:** Enter the name of the site.
- **Antenna Height:** the measured height value.
- **Measure way:** Antenna Phase Center, Vertical Height, Slant Height
- **Storage Format:** Select the format of the data store.
- **RINEX Version:** OFF, 3.02, 2.11
- **Start Date:** Select **Yes** or **No** option to determine whether to auto record start date.
- **Apply Time:** Select **Yes** or **No** option to determine whether to auto record apply time.

- **Integral Point Store:** Select **Yes** or **No** option to determine whether to allow receiver to save data every hour.
- **Circulating Memory:** Select **Yes** or **No** option to determine whether to auto delete old files if the storage space is full.
- **Repeat Observations:** Select **Yes** or **No** option to determine whether to turn on to record a single observation.
- **Store Location:** Internal Storage, External Storage.
- **Assigned Storage:** The assigned memory size of current thread(for example, Record 1) is 10000MB
- **Observer:** Enter the name of observer.
- **Observer Agency:** Enter the name of observer agency.
- **FTP Push:** Decide whether to push the stored files to the FTP server of your choice.

Tap  **Save** button to save the settings and back to the Log Settings screen. Also, users can click  **Back** to abandon the changed settings and back to Log Settings screen.

**Note** – To modify data logging parameters, make sure the data logging session is switched off.

To switch **on** or **off** **ANY** data logging session, tap the **ON** or **OFF** button on the right of the required session.

To delete the recorded files of **ANY** data logging session, tap the Clear button on the right of the required session.


To delete the recorded files of **ALL** data logging sessions, tap the Clear **ALL Accounts** button.

#### 4.4.2 FTP Push Settings Submenu

Use this screen to configure the receiver to push stored files to the FTP server of your choice. Only files that are configured to use FTP push are transmitted.


FTP Push Settings				
Record Info				
Server ID	Server IP	Remote Directory	Server Description	Modify
1	192.168.3.72	/repo/first	ftp server 1	
2	192.168.3.72	/repo/second	ftp server 2	
3	192.168.3.72	/repo/third	ftp server 3	

Tap **Modify** button on the right of the required FTP server and the FTP Push Settings screen appears:



#### 4.4.3 FTP Push Log Submenu


Shows the related information about the recorded file that be pushed. And users can tap Clear **Ftp Send Log** button in the upper right corner to clear the log of FTP Push operations.



#### 4.4.4 Data Download Submenu

In this submenu, users can download the data files that recorded in the internal storage through the internal FTP site. Please note that Chrome, EDGE and Firefox version higher than year 2020 version remove the FTP support through the browser.

1. Click this submenu, and then the log on dialogue box will prompt you to enter a user name and password:



The default logon account for the internal FTP site is:

- User name: ftp
- Password: ftp

2. Click the directory named as "repo" to view and download the files currently stored on the

receiver:


Index of /		
	Name	Size
	Date Modified	
📁	System Volume Information/	8/9/19, 10:28:00 PM
📁	repo_3225804/	7/16/19, 1:17:00 PM

3. To find the file need to be downloaded, click the name of data logging session → the date of file that be recorded → the format of the file → the name of the target file.

Index of /repo_3225804/		
	Name	Size
	Date Modified	
📁	push_log/	7/16/19, 1:17:00 PM
📁	record_1/	8/15/19, 10:22:00 AM
📁	record_2/	7/16/19, 1:17:00 PM
📁	record_3/	7/16/19, 1:17:00 PM
📁	record_4/	7/16/19, 1:17:00 PM
📁	record_5/	7/16/19, 1:17:00 PM
📁	record_6/	7/16/19, 1:17:00 PM
📁	record_7/	7/16/19, 1:17:00 PM
📁	record_8/	7/16/19, 1:17:00 PM

4. To download a file, left click the name of the target file → download the file according to the prompts.

## 4.5 IO Settings Menu



Use the IO Settings menu to set up all receiver outputs and inputs. The receiver can output CMR, RTCM, Raw data, Ephemeris data, GPGGA, GPGSV, on TCP/IP, UDP, serial port, or Bluetooth ports.

The following figure shows an example of the screen that appears when you select this submenu.


I/O Settings					
	Type	Description	Output	Connection Status	Modify
1	RTK Client	211.144.118.5.2102	---	Unconnected	<input type="button" value="Connect"/> <input type="button" value="Disconnecting"/> <input type="button" value="Delete"/>
2	TCP/UDP_Client1/NTRIP Serv	192.168.3.18:9900	---	Unconnected	<input type="button" value="Connect"/> <input type="button" value="Disconnecting"/> <input type="button" value="Delete"/>
3	TCP/UDP_Client2/NTRIP Serv	192.168.3.18:9901	---	Unconnected	<input type="button" value="Connect"/> <input type="button" value="Disconnecting"/> <input type="button" value="Delete"/>
4	TCP/UDP_Client3/NTRIP Serv	192.168.3.18:9902	---	Unconnected	<input type="button" value="Connect"/> <input type="button" value="Disconnecting"/> <input type="button" value="Delete"/>
5	TCP/UDP_Client4/NTRIP Serv	192.168.3.18:9903	---	Unconnected	<input type="button" value="Connect"/> <input type="button" value="Disconnecting"/> <input type="button" value="Delete"/>
6	TCP/UDP_Client5/NTRIP Serv	192.168.3.18:9904	---	Unconnected	<input type="button" value="Connect"/> <input type="button" value="Disconnecting"/> <input type="button" value="Delete"/>
7	TCP/UDP_Client6/NTRIP Serv	192.168.3.18:9905	---	Unconnected	<input type="button" value="Connect"/> <input type="button" value="Disconnecting"/> <input type="button" value="Delete"/>
8	TCP Server/NTRIP Caster1	9901	---	Closed	<input type="button" value="Connect"/> <input type="button" value="Disconnecting"/> <input type="button" value="Delete"/>
9	TCP Server/NTRIP Caster2	9902	---	Closed	<input type="button" value="Connect"/> <input type="button" value="Disconnecting"/> <input type="button" value="Delete"/>
10	TCP Server/NTRIP Caster3	9903	---	Closed	<input type="button" value="Connect"/> <input type="button" value="Disconnecting"/> <input type="button" value="Delete"/>
11	TCP Server/NTRIP Caster4	9904	---	Closed	<input type="button" value="Connect"/> <input type="button" value="Disconnecting"/> <input type="button" value="Delete"/>
12	Serial Port	115200	---	---	<input type="button" value="Settings"/>
13	Bluetooth	GNSS-3411955	GPGLL,5s,	---	<input type="button" value="Settings"/>
14	Radio	462.5500MHz	---	---	<input type="button" value="Settings"/>

In this submenu, users can configure 6 types of input and output settings.


### 1.RTK Client

After configuring the settings of RTK client, users can log on CORS or APIS. Tap the Connect button to the right → the IO Settings screen will appear → choose one of the connection protocols among the NTRIP, APIS\_BASE and APIS\_ROVER → configure the related parameters → click  to log on CORS or APIS.


#### ➤ Connection Protocol: NTRIP



#### ➤ Connection Protocol: APIS\_BASE



#### ➤ Connection Protocol: APIS\_ROVER




- Connection Protocol: TCP




## 2.TCP/UDP\_Client/NTRIP Server

Tap the Connect button on the right of required TCP/UDP Client → the IO Settings screen will appear → select the connection protocol from TCP, UDP,NTRIP1.0 and NTRIP2.0 → enter the IP and Port of the target server → configure messages that you want to output to the target server → click **Confirm** to save and complete the connection.


- Connection Protocol: TCP




- Connection Protocol: UDP



- Connection Protocol: NTRIP1.0




➤ Connection Protocol: NTRIP2.0




### 3.TCP Server/NTRIP Caster

Tap the Connect button to the right of required TCP Server/NTRIP Caster → the IO Settings screen will appear → select one of the connection protocols between NTRIP and TCP → configure the other related parameters → click to save the settings and open the server.

➤ Connection Protocol: TCP




➤ Connection Protocol: NTRIP




#### 4.Serial Port

Tap the Settings button on the right of Serial Port → the Serial Port Setup screen will appear → select Baud Rate used to transmit data → configure the messages that you want to output through the serial port → click **Confirm** to save the settings and start to transmit.




#### 5.Bluetooth


Tap the Settings button to the right of Bluetooth → the Bluetooth Set screen will appear → configure the messages that you want to transmit through Bluetooth → click **Confirm** to save the settings and start to transmit.



#### 6.Radio


Tap the Settings button to the right of Radio → the Radio Settings screen will appear →

select the format of differential data that you want to transmit through radio from the dropdown list → click  to save the settings and start to transmit.



## 4.6 Network Setting Menu

Use this menu to view network information, configure the receiver's mobile network, set email alert for specific situation, configure HTTP or HTTPS port, and the username and password of internal FTP site:




### 4.6.1 Description Submenu

Use this submenu to check the information of network setting.



## 4.6.2 Mobile Network Setting Submenu

Use this submenu to configure GPRS model, network module and modify dialing status.



## 4.6.3 Email Alarm Submenu

Use this submenu to choose which situation of receiver will be alerted and input the email address.

**TO**

Email Address 1:   
Email Address 2:   
Email Address 3:

**From**

Account:   
Password:   
Server Address:

**Email Alert**

Receiver is powered on  
 External power is off  
 Battery level is low  
 Ftp push is failed  
 Reciever(license) will be expired in 7 days.

**Save**

#### 4.6.4 HTTP Submenu

Use this submenu to configure HTTP port.

**HTTP**

HTTP Port:

**Save**

#### 4.6.5 HTTPS Submenu

Use this submenu to configure HTTPS port.

**HTTPS**


Enable HTTPS:  Yes  No

HTTPS Port:

**Save**


### 4.6.7 FTP Service Submenu

Use this submenu to configure the user name and password of internal FTP site.



## 4.7 Module Setting Menu

Use this menu to check module information, configure WiFi, bluetooth, radio related settings, turn on/off static voice of buzzer, and setting IMU:



### 4.7.1 Description Submenu

Use this submenu to check the information of WiFi module, bluetooth module and radio module.



## 4.7.2 WiFi Submenu

Use this submenu to turn on/off WiFi function and modify password.

Power Status: **ON** **OFF**

SSID: **GNSS-9999690**

Encryption Type: **NONE**

Network frequency bands: **5\_8G**

**Start**

## 4.7.3 Bluetooth Settings Submenu

Use this submenu to turn on/off bluetooth function and modify PIN number.

Local Name: **GNSS-9999690**

MAC Address: **81:5B:10:07:EC:2B**

PIN: **1234**

**Save**

## 4.7.4 Radio Settings Submenu

Use this submenu to turn on/off radio function and configure radio parameters.

Radio Status: **OFF** **ON** **OFF**

Auto Start: **Yes** **No**

Radio Protocol: **Transparent**

Channel Bandwidth: **25** (kHz)


OTA Baud Rate: **9600**

Radio Frequency: **33** **443.000000** (410MHz---470MHz)

**Save**

## 4.7.5 IMU Setting

Use this submenu to turn on/off IMU function and set antenna height.




## 4.8 Firmware Menu

Use this menu to check the current firmware information, download the system log, update the receiver firmware, download or update the configuration file and register the receiver, and more:



### 4.8.1 Firmware Info Submenu


Use this submenu to check the current firmware information. The following figure shows an example of the firmware information.



### 4.8.2 Hardware Version Submenu

Use this submenu to check the hardware information, including main board version and core


board version:



Main Board:	1.1.0
Core Board:	1.1.0
PN:	A19305290907070002
Board Firmware Version Number:	5.53

#### 4.8.3 Config File Submenu


Use this submenu to update Configuration File.



Download Configuration File:	<input type="button" value="Download"/>
Update Configuration File:	<input type="button" value="Browse"/>
<input type="button" value="Confirm"/>	

#### 4.8.4 System Log Download Submenu


Use this submenu to download the system log of the receiver.



System Log Type:	<input type="button" value="Firmware Log"/>
<input type="button" value="Download"/>	


#### 4.8.5 User Log Submenu

Use this submenu to download the user log. Tap Download to download current user log; Tick items that you want to see on the user log and tap confirm button to confirm selected user log.



#### 4.8.6 Firmware Update Submenu

Use this submenu to load new firmware to the receiver across the network. Tap the Browse button to locate the upgrade file → tap Confirm button to confirm the selected upgrading file and start upgrading.




##### Notes

It may take about 3 or 4 minutes to complete the firmware upgrading. Do not touch the power button or unplug the power until the upgrading process finishes, or damage will be caused to the receiver.

The receiver will restart after the firmware upgrading is done, so users need to reconnect the receiver with your computer via Wi-Fi, and then log-in the receiver through a web browser to continue the configuration.

#### 4.8.7 GNSS Board Upgrade Submenu

Use this submenu to upgrade GNSS Board. Use this submenu to load new board to the receiver across the network. Tap the Browse button to locate the upgrade file → tap Confirm button to confirm the selected upgrading file and start upgrading.



#### 4.8.8 GNSS Registration Submenu

Use this submenu to register the receiver. Paste or enter the registration code to the Registration Code field → tap Registration button to complete the registration.

A screenshot of a web-based configuration interface titled 'GNSS Registration'. It contains fields for 'Serial Number' (9999690), 'Registration Limit' (2024-6-21), 'Registration Code' (TDnSRvavY6y), and 'Registration deadline for external account access' (Unregistered). A 'Registration' button is at the bottom.



## CHC Navigation


Shanghai Huace Navigation Technology Ltd.  
CHCNAV | Smart Navigation & Geo-Spatial Technology Park,  
577 Songying Road, 201703, Shanghai, China  
Email: [sales@chcnav.com](mailto:sales@chcnav.com) | [support@chcnav.com](mailto:support@chcnav.com)  
Skype: [chc\\_support](#)  
Website: [www.chcnav.com](http://www.chcnav.com)

*This document is intended for general information purposes only. It does not consider the reader's specific circumstances and environmental constraints of use of GNSS.*

Make your work more efficient

### Detailed external antenna info

Manufacturer	:	Shanghai Huace Navigation Technology Ltd.
Antenna type	:	Portable omnidirectional antenna
Model	:	QT450GSB-T
Antenna gain	:	UHF, max gain 2 dBi



## **FCC warning statements:**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**Caution:** Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance 30cm between the radiator & your body.