

## 7. iPod® Operation

You can scan through the track numbers, play or pause and adjust the volume with the remote. When you are in the iPod mode the screen will appear like Figure H; then it will change to the track duration screen for the track. Using the Navigational Quad Keypad you can:



iPod

Figure H

- Increase the volume by pressing the Up button.
- Decrease the volume by pressing the Down button.
- Go to the previous track by pressing the Left button. Go to the next track by pressing the Right button.
- Pause or play by pressing the Select button.
- Turn off the system by pressing and holding the Select button for longer than 3 seconds.
- Go to the Main Menu by pressing the Return button.



**WARNING:** Electrical Shock Hazard Exists! Never install or remove iPod while hands are wet or while sitting partially immersed or fully immersed in spa!

## 8. Error has occurred

If the remote senses an error that needs attention, it will display the words "Spa" - "Err", one word at a time, (see Figure I). The words will cycle for 1 second each. Please go to the main spa control panel for further instructions. If this error is not detected by the user within 20 seconds, the remote will go to sleep mode and the backlighting will begin to flash on and off until the user a key is pressed.



Figure I

### 18.12 J1000™ Wireless Remote Battery Replacement

1. Turn the remote unit over and locate the battery door (Figure A).




Figure A

2. Remove the four screws securing the door.




Figure B

3. Remove the battery door. You could use a small screwdriver to pry the door upward.

4. Replace or install 3 AAA batteries.




Figure C

5. Reinstall the battery door and screws.

**Note:** Remote unit is water resistant not waterproof, therefore the unit should be stored in a dry location within your home and never be left in the spa while the cover is on and spa is not in use.

**The following UL requirements must be observed for all spas with optional stereo components installed.**

- A. "Caution - Risk of Electric Shock. Do not leave compartment door open";
- B. "Caution - Risk of Electric Shock. Replace component only with identical components"; and
- C. Do not operate the audio/video controls while inside the spa."
- D. "Warning - Prevent Electrocutation. Do not connect any auxiliary components (for example: cable, additional speakers, headphones, additional audio/video components etc.) to the system."
- E. These units are not provided with an outdoor antennae; when provided, it should be installed in accordance with Article 810 of the National Electric Code, ANSI/NFPA 70.
- F. Do not service this product yourself as opening or removing covers may expose you to dangerous voltage or other risk of injury. Refer all servicing to qualified service personnel.
- G. When the power supply connections or power supply cord(s) are damage; if water is entering the audio/video compartment or any electrical equipment compartment area; if the protective shields or barriers are showing signs of deterioration; or if there are signs of other potential damage to the unit, turn off the unit and refer to a qualified service personnel.
- H. This unit should be subject to periodic routing maintenance (for example, once every 3 months) to make sure that the unit is operating properly.

P/N: 6530-509, Rev. A

