

1 2 3 4 5 6 7 8

Illustrations:
Print Black

Logo:
K/O to White

Background:
Prints Process

Text:
K/O to White

At a glance

Let's get started. Here is some essential information about your tablet and its great features.

- 1 Power/lock key
- 2 Volume keys
- 3 Microphone
- 4 Proximity/light sensor
- 5 Front Camera
- 6 SIM and microSD™ tray
- 7 Speaker
- 8 USB Type-C charger port
- 9 Audio connector
- 10 Rear Camera

Set up your SIM card

The SIM card identifies your device to the wireless network.

Power on your device and follow the prompts to connect to the T-Mobile network with an eSIM (embedded SIM).

Note: Your device supports eSIM and nano SIM cards. To avoid damage to your device, do not attempt to insert any other SIM types.

- Locate the SIM Ejector tool found inside the tablet package and insert the tool into the small opening next to the SIM / microSD card holder, pull out the SIM tray.
- Position the SIM card and/or microSD card in the tray correctly, aligning the cutout tab and gently snap into place. Be sure the edges are aligned.

Note: SIM pin is included in the box. MicroSD™ cards are sold separately.

Charge your tablet

To optimize battery performance, charge your tablet fully. Insert the small end of the charging cable into the tablet and the other end into the wall charger, then plug it into a wall outlet.

Note: Please use the USB type-C cable included in the box. Wall charger sold separately.

WARNING: Only use compatible wall chargers that meet all applicable standards for safety. Using incompatible chargers or tampering with the charging port could damage your tablet and void the warranty.

Using your tablet

Turning your tablet on/off

To turn on your tablet, press and hold the power/lock key and follow instructions to set up your device.

To turn off your tablet, press and hold the power/lock key and volume up key at the same time, and tap Power Off on the screen when it appears.

Locking/unlocking the screen

To turn on your screen, press the power/lock key. Swipe up on the screen, then use the password, pin or pattern code used during setup wizard to unlock the tablet.

To create a new screen unlock password or PIN code, touch **Settings > Security & privacy > Set screen lock**.

To turn off your screen and prevent accidental key presses, press the power/lock key.

Approved firmware versions

This device will only operate with firmware versions that have been approved for use by your wireless carrier and the device manufacturer. If unauthorized firmware is placed on the device, it will not function.

Information about safeguarding devices

We encourage customers to take appropriate measures to secure their devices and invite them to take advantage of the features available on this device to help secure it from theft and/or other unauthorized access and use.

This device has a locking function (e.g., user-defined codes or patterns) that can serve as a first line of defense against unauthorized use or access to stored information. Preloaded security applications that allow customers to track or locate misplaced devices can be found on several devices. Lost or stolen devices should be immediately reported to your wireless carrier so that proper measures can be taken to protect accounts. For additional information, visit your wireless carrier's Privacy Policy.

Additional information

Not all features, apps or services may be available with your plan, device operating system and/or software version. Please review your service plan details for more information.

5G: Not all devices, signals, or uses are compatible; check device specs. See [T-Mobile.com](#), [MetrobyT-Mobile.com](#) or [AssuranceWireless.com](#) for 5G coverage, access and network management details.

eSIM: For more information regarding eSIM visit [T-Mobile.com/support/devices/sim-esim](#) or [MetrobyT-Mobile.com/resources/esim](#).

Devices and screen images are simulated. **Coverage** not available in some areas. See **Terms and Conditions (including arbitration provision)** at [T-Mobile.com](#), [MetrobyT-Mobile.com](#) or [AssuranceWireless.com](#) for additional information, restrictions and details. T-Mobile, the T logo, Magenta and the magenta color, Revvl and the stylized Revvl mark are registered trademarks of Deutsche Telekom AG. ©2025 T-Mobile USA, Inc.

Text:
Prints Black

Logo:
Prints T-Mobile Magenta

Text:
Prints T-Mobile Magenta

PID4959

Back of 8 Back of 7 Back of 6 Back of 5 Back of 4 Back of 3 Back of 2 Back of 1

Logo:
K/O to White

Background:
Prints Process

Text:
K/O to White

Descripción breve

Comencemos. Aquí tienes la información básica sobre tu tablet y sus increíbles funciones.

- 1 Botón de encendido/bloqueo
- 2 Botones de volumen
- 3 Micrófono
- 4 Sensor de luz/proximidad
- 5 Cámara frontal
- 6 Bandeja para SIM y microSD™
- 7 Bocina
- 8 Puerto de carga USB tipo C
- 9 Entrada para audio
- 10 Cámara trasera

Cómo instalar la tarjeta SIM

La tarjeta SIM identifica tu dispositivo dentro de la red de servicio móvil.

Enciende tu dispositivo y sigue las instrucciones para conectarte a la red de T-Mobile con una eSIM (tarjeta SIM integrada).

Nota: tu dispositivo admite tarjetas eSIM y nano-SIM. Para evitar que el dispositivo se dañe, no intentes insertar otro tipo de tarjeta SIM.

- Encuentra la herramienta de extracción de SIM que viene en la caja de la tablet, insértala en la pequeña abertura junto al portatarjetas SIM/microSD y saca la bandeja de la SIM.
- Coloca la tarjeta SIM o la tarjeta microSD correctamente en la muesca, y presiona suavemente hasta que encaje en su lugar. Asegúrate de que los bordes estén alineados.

Nota: el pin para la tarjeta SIM viene en la caja. Las tarjetas microSD™ se venden por separado.

Carga tu tablet

Para optimizar el rendimiento de la batería, carga tu tablet por completo. Introduce el extremo pequeño del cable de carga en la tablet y el otro extremo en el cargador de pared, y luego conéctalo a un enchufe.

Nota: usa el cable USB tipo C que viene incluido en la caja. El cargador de pared se vende por separado.

ADVERTENCIA: usa solamente cargadores de pared compatibles que cumplan con todos los estándares de seguridad correspondientes. Usar cargadores incompatibles o manipular el puerto de carga podrían dañar tu tablet y anular la garantía.

Cómo usar tu tablet

Encender y apagar tu tablet

Para encender tu tablet, mantén presionado el botón de encendido/ bloqueo y sigue las instrucciones para configurar tu dispositivo.

Para apagarla, mantén presionado el botón de encendido/bloqueo y el botón para subir el volumen a la vez, y toca Apagar cuando aparezca en la pantalla.

Bloquear/desbloquear la pantalla

Para encender la pantalla, presiona el botón de encendido/bloqueo. Desliza hacia arriba en la pantalla y luego usa la contraseña, código de patrón o PIN creado durante la configuración para desbloquear la tablet.

Para crear una nueva contraseña o código PIN de desbloqueo de pantalla, ve a **Ajustes > Seguridad y privacidad > Configurar bloqueo de pantalla**.

Para apagar la pantalla y evitar presionar botones por accidente, presiona el botón de encendido/bloqueo.

Versiones de firmware aprobadas

Este dispositivo solo funcionará con versiones de firmware cuyo uso haya sido aprobado por tu compañía de servicio móvil y por el fabricante del dispositivo. Si se instala firmware no autorizado, el dispositivo no funcionará.

Información sobre la protección de dispositivos

Recomendamos que los clientes tomen las medidas necesarias para proteger sus dispositivos y los invitamos a aprovechar las funciones disponibles en este dispositivo para protegerlo contra robo u otro tipo de acceso o uso no autorizados. Este dispositivo tiene una función de bloqueo (p. ej., códigos o patrones definidos por el usuario) que puede actuar como una primera línea de defensa contra el acceso o uso no autorizados de la información almacenada. Muchos dispositivos tienen aplicaciones de seguridad preinstaladas que permiten a los clientes rastrear o localizar un dispositivo extraviado. Deberás informar de inmediato a tu compañía de servicio móvil si pierdes o te roban un dispositivo para que puedan adoptarse las medidas apropiadas para proteger las cuentas. Para más información, consulta la Política de privacidad de tu compañía de servicio móvil.

Información adicional

Es posible que no todas las funciones, apps o servicios estén disponibles con tu plan, sistema operativo del dispositivo y/o versión de software. Revisa los detalles de tu plan de servicio para más información.

5G: no todos los dispositivos, señales y tipos de uso son compatibles; consulta las especificaciones del dispositivo. Para detalles sobre cobertura 5G, acceso y gestión de red, visita es. [T-Mobile.com](#), [hola.MetrobyT-Mobile.com](#) o [AssuranceWireless.com/es_us](#).

eSIM: para más información sobre la eSIM, visita [es.T-Mobile.com/support/devices/sim-esim](#) o [hola.MetrobyT-Mobile.com/resources/esim](#)

Las imágenes de los dispositivos y en las pantallas son simuladas. **Cobertura** no disponible en ciertas áreas. **Ve los Términos y condiciones (incluida la cláusula de arbitraje)** en [es.T-Mobile.com](#), [hola.MetrobyT-Mobile.com](#) o [AssuranceWireless.com/es_us](#) para información, restricciones y detalles adicionales. T-Mobile, el logotipo de la T, Magenta y el color magenta, Revvl y el diseño de la marca Revvl son marcas comerciales registradas de Deutsche Telekom AG. © 2025 T-Mobile USA, Inc.

Text:
Prints Black

Logo:
Prints T-Mobile Magenta

Text:
Prints T-Mobile Magenta

PID4959

Fold in / Doblar hacia adentro

Front Cover / Cubierta frontal

Front Cover / Cubierta frontal

Pearlfisher.		Filename: 250306_T-Mobile_REVVL-Tab-2_Quick-Start-Guide_EN-SPA		Artwork	
Pearlfisher Inc. 455 Broadway New York NY 10013 USA www.pearlfisher.com		Client: T-Mobile	Project: Revvl 8	Job N°: TMO10306	
	Date Created: 03-06-25	Modified: 03-06-25	Version: 08		
	Artwork Scale: 100%	Die/File Reference: REVVL_TAB_9185W_OSG_EN-V0.1.pdf			
Substrate: [TBC] Print Method: [TBC] Inks & Finishes: Number of Inks & Finishes [TBC]					
Font:	Tabl Neo Var
Foundry:	T-Mobile
Source:	T-Mobile
<p><small>IMPORTANT NOTES: Please check this artwork proof thoroughly, including all crop, colors, bleed and legal/mandatory information, prior to approval. Once the artwork has been approved by you and released by Pearlfisher, we can no longer take responsibility for any errors or omissions, as outlined in our terms and conditions. If you have any questions relating to this or if you require any guidance on checking artwork proofs, then please let us know and we will happily advise. Second screen is for positional only and should be set by printer according to client's specifications.</small></p>					