



1-BUTTON REMOTE CONTROL

MODEL: CH361

Product Manual



Overview

Your remote control is compatible with all Chamberlain®, LiftMaster®, and Craftsman® garage door openers manufactured after 1997 with the exception of Craftsman Series 100. Your remote control can be programmed to operate compatible devices, such as garage door openers and gate operators. The images throughout this manual are for reference only and your product may look different.

 **WARNING**

To prevent possible **SERIOUS INJURY** or **DEATH** from a moving gate or garage door:

- ALWAYS keep remote controls out of reach of children. NEVER permit children to operate, or play with the remote control transmitters.
- Activate gate or door **ONLY** when it can be seen clearly, is properly adjusted and there are no obstructions to door travel.
- ALWAYS keep gate or garage door in sight until completely closed. NEVER permit anyone to cross path of moving gate or door.

 **WARNING:** This product can expose you to chemicals including lead, which are known to the State of California to cause cancer or birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov.

Contents


Overview	2
Program Your Remote to Your Wi-Fi Garage Door Opener Using the myQ App	3
Programming Using the Learn Button	4
Before You Begin	4
Method A: Program to a Security+ 3.0 Protocol Garage Door Opener (White Learn Button) Using the Learn Button on Door Control Panel	5
Method B: Program to a Security+ 3.0 Protocol Garage Door Opener (White Learn Button) Using the Opener’s Learn Button	6
Method C: Program to All Compatible Garage Door Openers (White, Yellow, Purple, Red, & Orange Learn Buttons).	7
Replacing the Battery.....	9
Replacement Parts	11
Additional Resources	11

Program Your Remote to Your Wi-Fi Garage Door Opener Using the myQ App

HIGHLY RECOMMENDED: Connect your Wi-Fi Garage Door Opener to the myQ app and program your Remote to the Garage Door Opener to unlock exciting features such as remote naming, notifications and access history.


Garage Door Opener Already Connected to the myQ App

Scan the QR code on the reverse side of your remote and follow the programming instructions in the myQ app.



If Your Garage Opener is Not Connected to the myQ App


01 Look for a “Wi-Fi®” or a “Powered by myQ” logo to determine if your garage door opener is myQ compatible.




02 Scan the QR Code below to download the myQ app. Follow the instructions in the myQ app to connect your garage door opener.



03 Once your garage door opener is connected, scan the QR code on the reverse side of your remote, and follow the programming instructions in the myQ app.




04 Once your remote is programmed in the myQ app, you can name your remote, view access history and receive notifications when your remote activates the garage door opener.



Programming Using the Learn Button

Before You Begin

Be sure the garage door is clear of ALL obstructions. Make sure the garage door opener has a working light because it is a programming indicator.



1-Button Remote Control
Model: CH361

RECOMMENDATION: Read through all programming steps before you start.

Program Using the Learn Button (continued)


Method A: Program to a Security+ 3.0 Protocol Garage Door Opener (White Learn Button) Using the Learn Button on Door Control Panel

RECOMMENDATION: Have your door control panel product manual available, as models vary in how they set the garage door opener into programming mode.

01 Follow the instructions below for your door control panel model to set your garage door opener into programming mode.


Door Control Panel

Lift the door activation panel. Press the **LEARN** button **twice** (after the second press, the LED on the door control panel will pulse repeatedly).




Door Control Push Button

Press and hold the light button, then press and release the door activation button. The button LED will begin to flash.




Smart Door Control Panel

Select **MENU**, then select **PROGRAM** and follow on screen instructions.



02 Within 30 seconds, press and hold the button on the remote control. Release the button when the garage door opener lights flash **and/or** two clicks are heard.





TEST FOR SUCCESS: Press the remote button. The garage door opener will activate. If the garage door does not activate, repeat the programming steps.

Program Using the Learn Button (continued)



Method B: Program to a Security+ 3.0 Protocol Garage Door Opener (White Learn Button) Using the Opener's Learn Button

- 01** Locate the LEARN button on your garage door opener (a ladder may be required). Press and **immediately** release the LEARN button.



NOTE: The LEARN LED will glow steadily for 30 seconds.

- 02** Within 30 seconds, press and hold the button on the remote control. Release the button when the garage door opener lights flash **and/or** two clicks are heard.




TEST FOR SUCCESS: Press the remote button. The garage door opener will activate. If the garage door does not activate, repeat the programming steps.

Program Using the Learn Button (continued)


Method C: Program to All Compatible Garage Door Openers (White, Yellow, Purple, Red, & Orange Learn Buttons)

01 Start with your garage door closed.

IMPORTANT: The remote will activate your garage door during programming. Be sure the door is clear of ALL obstructions.



02 Press and release the remote button **6 times within 4 seconds**. The red LED on the remote remains solid to confirm programming mode is active.




03 Option 1: Follow the instructions below for your door control panel model to set your garage door opener into programming mode.

RECOMMENDATION: Have your door control panel product manual available, as models vary in how to set the garage door opener into programming mode.


Door Control Panel

Lift the door activation panel. Press the **LEARN** button **twice** (after the second press, the LED on the door control panel will pulse repeatedly).




Door Control Push Button

Press and hold the light button, then press and release the door activation button. The button LED will begin to flash.



Smart Door Control Panel


1. Select **MENU**.
 2. Scroll down and select **PROGRAM**.
 3. Scroll down and select **REMOTE**.
- Do not follow on screen instructions. MOVE DIRECTLY TO STEP 04.**




Program Using the Learn Button (continued)

Method C: Program to All Compatible Garage Door Openers (White, Yellow, Purple, Red, & Orange Learn Buttons) (continued)


Option 2: Locate the LEARN button on your garage door opener (a ladder may be required).
Press and **immediately** release the LEARN button.



04 Press and release the button **twice** (second press must be within 20 seconds of the first press). The red LED will flash intermittently as the remote sends the preprogrammed codes to the garage door opener.



05 Wait for the garage door opener to move the door. This can take up to 25 seconds. During this time, your garage door opener light might flash. When the garage door opener moves, **within 3 seconds**, press and release the button on the remote to confirm the code and exit programming.




TEST FOR SUCCESS: Press the remote button. The garage door opener will activate. If the garage door does not activate, repeat the programming steps.

Replacing the Battery


The LED on your remote control will stop flashing when the battery is low and needs to be replaced. Replace the battery with only 3V CR2032 coin cell battery. Dispose of old battery properly.

To replace battery, follow the instructions as shown below.


- 01** On the back side of the remote, using a **Phillips #1 screwdriver**, unscrew the captive screw until it rotates freely.




- 02** With the remote button side up, pry open the remote top housing from the bottom housing (if the housing will not separate, check that the captive screw is rotating freely).




- 03** With a cotton swab, push the old battery out of its holder in the direction of the nearest edge.



- 04** Insert the replacement battery positive side up.



- 05** Align the remote top and bottom housing so they clip together. Tighten the captive screw until the top and bottom housing no longer shift (**do not overtighten the screw to avoid cracking the plastic housing**).



Replacing the Battery (continued)

⚠ WARNING

- **INGESTION HAZARD:** This product contains a button cell or coin battery.
- **DEATH** or serious injury can occur if ingested.
- A swallowed button cell or coin battery can cause **Internal Chemical Burns** in as little as **2 hours**.
- **KEEP** new and used batteries OUT OF REACH of CHILDREN.
- **Seek immediate medical attention** if a battery is suspected to be swallowed or inserted inside any part of the body.



⚠ WARNING

- Remove and immediately recycle or dispose of used batteries according to local regulations and keep away from children. Do NOT dispose of batteries in household trash or incinerate.
- Even used batteries may cause severe injury or death.
- Call a local poison control center for treatment information.
- Battery Type: CR2032
- Battery Voltage: 3 V
- Non-rechargeable batteries are not to be recharged.
- Do not force discharge, recharge, disassemble, heat above (manufacturer's specified temperature rating) or incinerate. Doing so may result in injury due to venting, leakage or explosion resulting in chemical burns.
- Ensure the batteries are installed correctly according to polarity (+ and -).
- Do not mix old and new batteries, different brands or types of batteries, such as alkaline, carbon-zinc, or rechargeable batteries.
- Remove and immediately recycle or dispose of batteries from equipment not used for an extended period of time according to local regulations.
- Always completely secure the battery compartment. If the battery compartment does not close securely, stop using the product, remove the batteries, and keep them away from children.

Replacement Parts

Description	Part Number
Visor Clip	041-0494-000

Additional Resources

One Year Limited Warranty

The Chamberlain Group LLC ("Seller") warrants to the first consumer purchaser of this product that it is free from defect in materials and/or workmanship for a period of 1 year from the date of purchase.

For more information, visit www.myq.com/warranty

Contact Us

For additional information or assistance, please visit: support.chamberlaingroup.com

NOTICE: This device complies with part 15 of the FCC rules and Innovation, Science and Economic Development Canada license-exempt RSSs. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modification not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



TÉLÉCOMMANDE À 1 BOUTON

MODÈLE : CH361

Manuel du produit



Aperçu

La télécommande est compatible avec tous les ouvre-portes de garage Chamberlain®, LiftMaster® et Craftsman® fabriquées après 1997 à l'exception des commandes série 100 de Craftsman. Votre télécommande peut être programmée pour commander des appareils compatibles, tels que des ouvre-portes de garage et des opérateurs de portail. Les images de ce manuel sont fournies à titre indicatif uniquement et il est possible que votre produit soit différent.

AVERTISSEMENT

Pour éviter d'éventuelles BLESSURES GRAVES voire MORTELLES causées par le déplacement d'un portail ou d'une porte de garage :

- Gardez TOUJOURS les télécommandes hors de portée des enfants. N'autorisez JAMAIS les enfants à utiliser les télécommandes ou à jouer avec elles.
- Activez le portail ou la porte UNIQUEMENT lorsqu'il ou elle est clairement visible et correctement réglé(e), et qu'il n'y a pas d'obstacles au déplacement de la porte.
- Gardez TOUJOURS le portail ou la porte de garage en vue jusqu'à ce qu'il ou elle soit complètement fermé(e). Ne permettez JAMAIS à quiconque de passer la ligne du portail ou de la porte de garage en cours de déplacement.



AVERTISSEMENT : Ce produit peut vous exposer à des produits chimiques, dont le plomb, qui sont reconnus par l'État de Californie comme provoquant le cancer, des malformations congénitales ou d'autres problèmes de reproduction. Pour plus d'information, visitez www.P65Warnings.ca.gov.

Table des matières


Aperçu	2
Programmez votre télécommande sur votre ouvre-porte de garage Wi-Fi à l'aide de l'application myQ	3
Programmation à l'aide du bouton d'apprentissage	4
Avant de commencer	4
Méthode A : Programmer un ouvre-porte de garage à protocole Security+ 3.0 (bouton d'apprentissage blanc) à l'aide du bouton d'apprentissage du panneau de commande de la porte.	5
Méthode B : Programmer un ouvre-porte de garage à protocole Security+ 3.0 (bouton d'apprentissage blanc) à l'aide du bouton d'apprentissage de l'ouvre-porte.	6
Méthode C : Programmation sur tous les ouvre-portes de garage compatibles (boutons d'apprentissage blanc, jaune, violet, rouge et orange)	7
Remplacement de la pile	9
Pièces de rechange	11
Ressources complémentaires.	11

Programmez votre télécommande sur votre ouvre-porte de garage Wi-Fi à l'aide de l'application myQ

FORTEMENT RECOMMANDÉ : Connectez votre ouvre-porte de garage Wi-Fi à l'application myQ et programmez votre télécommande sur l'ouvre-porte de garage pour débloquer des fonctionnalités intéressantes telles que la désignation à distance, les notifications et l'historique des accès.


Ouvre-porte de garage déjà connecté à l'application myQ

Scannez le code QR au dos de votre télécommande et suivez les instructions de programmation dans l'application myQ.



Si votre ouvre-porte de garage n'est pas connecté à l'application myQ

01 Recherchez un logo « Wi-Fi® » ou « Powered by myQ » pour déterminer si l'ouvre-porte de garage est compatible à myQ.




Wi-Fi®
ou
ALIMENTÉ PAR myQ®

02 Numérisez le code QR ci-dessous pour télécharger l'application myQ. Suivez les instructions d l'application myQ pour connecter l'ouvre-porte de garage.




03 Une fois votre ouvre-porte de garage connecté, scannez le code QR au dos de votre télécommande et suivez les instructions de programmation dans l'application myQ.



04 Une fois votre télécommande programmée dans l'appli myQ, vous pouvez donner un nom à votre télécommande, consulter l'historique des accès et recevoir des notifications lorsque votre télécommande active l'ouvre-porte de garage.


myQ John a ouvert la porte du garage à 16 h 32.



Programmation à l'aide du bouton d'apprentissage

Avant de commencer

Assurez-vous que la porte est dégagée de TOUTES obstructions. Assurez-vous que l'ouvre-porte de garage a une lumière qui fonctionne, car elle sera un indicateur de programmation.



RECOMMANDATION : Lire toutes les étapes de programmation avant de commencer.

Programmer la télécommande à l'aide du bouton d'apprentissage (suite)


Méthode A : Programmer un ouvre-porte de garage à protocole Security+ 3.0 (bouton d'apprentissage blanc) à l'aide du bouton d'apprentissage du panneau de contrôle de la porte

RECOMMANDATION : Munissez-vous du manuel d'utilisation du panneau de commande de la porte, car les modèles varient dans la manière de mettre l'ouvre-porte de garage en mode de programmation.

01 Suivez les instructions ci-dessous correspondant au modèle de panneau de commande que vous possédez pour mettre l'ouvre-porte de garage en mode programmation.


Panneau de commande de la porte

Soulevez la porte du panneau d'activation. Appuyez **deux fois** sur le bouton d'**APPRENTISSAGE** (après la deuxième pression, la DEL du panneau de contrôle de la porte émet des impulsions répétées).




Bouton poussoir du panneau de commande de la porte

Appuyez sur le bouton Light (éclairage) et maintenez-le enfoncé, puis appuyez sur le bouton d'activation de la porte. Le voyant à DEL clignotera.




Panneau de commande de la porte intelligent

Sélectionnez **MENU**, puis **PROGRAM** et suivez les instructions à l'écran.



02 Dans les 30 secondes, appuyez sur le bouton de la télécommande et maintenez-le enfoncé. Relâchez le bouton lorsque les lumières de l'ouvre-porte de garage clignotent **ou** que deux clics se font entendre.




TESTER POUR RÉUSSIR : Appuyez sur le bouton de la télécommande. L'ouvre-porte de garage est activé. Si la porte de garage ne s'est pas activée, répétez les étapes de programmation.


Programmer la télécommande à l'aide du bouton d'apprentissage (suite)

Méthode B : Programmer un ouvre-porte de garage à protocole Security+ 3.0 (bouton d'apprentissage blanc) à l'aide du bouton d'apprentissage de l'ouvre-porte

- 01** Localisez le bouton d'apprentissage sur l'ouvre-porte de garage (un escabeau sera peut-être nécessaire). Appuyez et relâchez **immédiatement** le bouton LEARN (Apprentissage).



- 02** Dans les 30 secondes, appuyez sur le bouton de la télécommande et maintenez-le enfoncé. Relâchez le bouton lorsque les lumières de l'ouvre-porte de garage clignotent **ou** que deux clics se font entendre.




TESTER LA PROGRAMMATION : Appuyez sur le bouton de la télécommande. L'ouvre-porte de garage est activé. Si la porte de garage ne s'est pas activée, répétez les étapes de programmation.

Programmer la télécommande à l'aide du bouton d'apprentissage (suite)


Méthode C : Programmation sur tous les ouvre-portes de garage compatibles (boutons d'apprentissage blanc, jaune, violet, rouge et orange)

01 Débutez avec la porte de garage fermée.

IMPORTANT : La télécommande active la porte du garage pendant la programmation. Assurez-vous que la porte est dégagée de TOUTES les obstructions.



02 Appuyez et relâchez le bouton de la télécommande **6 fois en l'espace de 4 secondes**. Le voyant rouge de la télécommande reste allumé pour confirmer que le mode de programmation est actif.




03 Option 1 : Suivez les instructions ci-dessous correspondant au modèle de panneau de commande que vous possédez pour mettre l'ouvre-porte de garage en mode programmation.

RECOMMANDATION : Avoir le guide d'utilisation du panneau de commande à la portée de main, car la façon d'accéder au mode de programmation varie selon le modèle d'ouvre-porte de garage.


Panneau de commande de la porte

Soulevez la porte du panneau d'activation. Appuyez **deux fois** sur le bouton d'**APPRENTISSAGE** (après la deuxième pression, la DEL sur le panneau de contrôle de la porte émet des impulsions répétées).




Bouton poussoir du panneau de commande de la porte

Appuyez sur le bouton Light (éclairage) et maintenez-le enfoncé, puis appuyez sur le bouton d'activation de la porte. Le voyant à DEL clignotera.



Panneau de commande de la porte intelligente


1. Sélectionnez **MENU**.
 2. Faites défiler vers le bas et sélectionnez **PROGRAM** (Programme).
 3. Faites défiler vers le bas et sélectionnez **REMOTE** (À distance).
- Ne suivez pas les instructions à l'écran. ALLEZ DIRECTEMENT À L'ÉTAPE 4.**



Programmer la télécommande à l'aide du bouton d'apprentissage (suite)



Méthode C : Programmation pour tous les ouvre-portes de garage compatibles (boutons d'apprentissage blanc, jaune, violet, rouge et orange) (suite)

Option 2 : Localisez le bouton d'apprentissage sur l'ouvre-porte de garage (un escabeau sera peut-être nécessaire). Appuyez et relâchez **immédiatement** le bouton d'apprentissage.



04 Appuyez et relâchez le bouton **deux fois** (la deuxième pression doit être effectuée dans les 20 secondes qui suivent la première pression). Le voyant rouge clignote par intermittence lorsque la télécommande envoie les codes préprogrammés à l'ouvre-porte de garage.

05 Attendez que l'ouvre-porte de garage déplace la porte. Cette opération peut durer jusqu'à 25 secondes. Pendant ce temps, le voyant de l'ouvre-porte de garage peut clignoter. Lorsque l'ouvre-porte de garage se déplace, appuyez sur l'un des boutons de la télécommande **dans les 3 secondes**, puis relâchez-le immédiatement pour confirmer le code et quitter la programmation.



TESTER LA PROGRAMMATION : Appuyez sur le bouton de la télécommande. L'ouvre-porte de garage est activé. Si la porte de garage ne s'est pas activée, répétez les étapes de programmation.