# How to Use XFILE-DRIVE

Note : This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications, However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION : Changes or modifications not expressly approved by the manufacturer responsible for compliance could void the user's authority to operate the equipment.

## <GUARANTEE>



- This product is manufactured through tight quality control and inspection.
- If any troubles regarding XFILE-DRIVE, please contact the store where you bought product or Customer Service Center.
- This product is guaranteed for one year commencing on the date of purchase.
  Within guarantee period we will eliminate, free of charge, any defects due to faulty workmanship or materials by repairing or exchanging parts.
- The guarantee is void if the defect arises from accidental damage, misuse or neglect by users and natural disasters.
  Service will be charged even within the period of guarantee against of following defects due to:

  1. Physical impacts such as drop of the product
  2. Insert of alien substance into the drive
  3. Alteration or repair carried out by unauthorized persons
  4. Fire or natural disasters
  5. Malfunction of USB power supply
  6. Normal or natural wear of parts
  7. Improper use or neglect by users

## <CAUTION>
- Installation is needed only under Windows 98/SE.
  Under the other operating systems, the driver will be installed automatically.
- Removal of XFILE-DRIVE with LED on may cause data loss.
- Password loss and consequent reformatting may lead to permanent data loss in the locked system with XFILE-DIRVE.
- Write-protection switch works by the preset-mode.
  If you want to change the mode, then XFILE-DRIVE should re-plug into the system.
- For further information or request, please contact Customer Service Centers or E-mail us.
  Homepage   : www.KPF-junglip.or.kr
  E-mail     : elcas@disability.or.kr
  Customer Service Center :  +82-2-2-447-7328

# How to Use XFILE-DRIVE

## <COMPONENTS>



- XFILE-DRIVE
- Installation CD
- Neck strap
- USB extension cable
- User's guide

## <CAUTION>
- This product is consist of precise electronic components.
  Therefore, please do not use the drive in the following places where may cause malfunction or breakdown of the device ;
  1. Places under the direct sun light
  2. Places like summer beach
  3. Places with high temperature and humidity
  4. Places with flammable devices
  5. Places near air conditioners, heaters or humidifiers
  6. Watery or wet places
  7. Place with vibration

## <SPECFICATIONS>

| MODEL | XFILE-DRIVE |
|---|---|
| OS | Windows 98/SE, Windows ME, Windows 2000, Windows XP, Windows CE 3.0, Mac OS 9.0 or higher, Linux2.4.x or higher |
| CAPACITY | 128MB/256MB |
| INTERFACE | USB Spec 2.0(High Speed) UHCI, OHCI |
| DATA ACCESS TIME | 7MB/sec(Write), 8MB/sec(Read) |
| OTHER FUNCTIONS | Write protection switch Password protection Boot-up function(WIN98/SE ) |
| DIMENSIONS | 78.5mm× 19mm× 9.7mm |
| POWER SUPPLY | USB Port(4.5V 5.5V) |
| OPERATION TEMP. | 0 45 |
| TEMP. | -20 80 |
| DATE DETENTION | 10years or more |

# How to Use XFILE-DRIVE


## <HOW TO INSTALL A XFILE-DRIVE>

- Connect the XFILE-DRIVE (with or without the given cable) to USB port of you desktop or notebook PC.
- After the connection, XFILE-DRIVE is recognized as 'Removable drive'.
- XFILE-DRIVE is recognized as 'Untitled' on the Mac.
- Use XFILE-DRIVE after mounting the connected device.