User Manual

PASSAU S28CS

SOUNDBAR

Specifications

Model Name	S28CS
Driver Size	2.25" × 2 + 5" × 1
Power Output	80W
Bluetooth Version	5.3
BT Range	Up to 10m
Total Harmonic Distortion	<1%
SNR(dB)	>=80dB
Dimensions of soundbar(mm)	W570 × H79 × D68
Dimensions of subwoofer(mm)	W150 × H241 × D170
Impedence(ohm)	4Ω
Connectivity	USB/BT/AUX/HDMI(ARC)

Packaging Content

- 1 × Soundbar
- 1 × Subwoofer
- 2 × Cable
- 1 × Remote Control
- 1 × User Manual
- 1 × Mount Bracket

DESCRIPTION OF THE SOUNDBAR BACK COVER



1. AUX-IN
2. HDMI(ARC)Input
3. Power Input:110-240V~50/60HZ
4. SUB OUTPUT

DESCRIPTION OF THE SOUNDBAR CONTROL PANEL

1. Power/Input Button:Press and hold to power the unit on off. Short press to switch between Bluetooth/HDMI(ARC)/USB and AUX modes.
2. (-) button: Short press to play previous audio, press and hold to decrease the volume.
3. Play/Pause button: In Bluetooth mode, press to play/pause audio. Press and hold to disconnect/re-connect Bluetooth.In USB mode, press to play/pause. In AUX mode,press to mute/unmute.
4. (+) Button: Press to skip to next track, press and hold toincrease the volume.
5. USB Port

* USB supports upto 64 GB & supports audio codecs: Mp3, WMV and WMA

SAFETY PRECAUTION

Caution:
To reduce the risk of electric shock, do not dismantle the S28CS and do not expose the apparatus to rain or moisture.

This symbol alerts you about the presence of uninsulated dangerous voltage within the product's enclosure that may be of sufficient magnitude to constitute an electric shock to a person or persons.

Important! This symbol alerts you to read and observe important warnings and instructions on the unit or in this manual.

IMPORTANT SAFETY INSTRUCTIONS

This soundbar is specially developed for LED/LCD/Plasma & Smart TVs. It should not be used in combination with CRT TVs(Cathode Ray Tube TVs) in order to avoid image interferences.

Do not place this unit close to a strong magnetic field or the unit on an amplifier or receiver.

Do not place the S28CS on any unstable surfaces.

Don not take the soundbar near water, such as bath tubs, bathrooms e.t.c, and any areas that contain a high amount of moisture.

Switch off the device whenever you are not using it, even if this is only for a short while.

Please ensure that there is a 20 cm of space free above the soundbar and 5 cm on either side.

The soundbar should be situated away from heat sources such as radiators, stoves, or other devices, including amplifiers that produce heat.

This soundbar should be operated only from the type of power source indicated by the marking adjacent to the power cord entry.

Clean the soundbar with only a soft damp cloth and make sure to unplug the unit from the wall socket before starting.

If any servicing of the unit is required please do not disassemble the soundbar yourself. All maintenance must be done only by a service provider or from a manufacturer. Doing so on your own will automatically make the warranty null and void.

Do not replace any of the part on your own and don't use parts that are not factory authorised. It can result in fires, electrical shocks or other hazards.

Remote Control - Control/Functions



1. POWER : Turns on standby mode.
2. INPUT: Navigates between BT/HDMI/USB/AUX mode.
3. VOLUME (-,+) : Increase/decrease the volume.
4. ⏮ : Skip to the previous track(works under USB & BT modes).
5. ⏭ : Skip to the next track(works under USB & BT modes).
6. ⏯ : Play/Pause the USB mode.
7. TRE (-,+) : Increase/decrease treble.
8. BASS (-,+) : Increase/decrease bass.
9. EQ : Choose audio output sound field effect.
10. 🔇 : Mute the sound.

BATTERY INSTALLATION

1) Open the battery case.

2) Insert 2pcs AAA battery without the polarity reversed.

3) Close the battery case.

4) Keep within 5 meter range, 30 degree angle while aiming at the unit.

Precautionary note:

Remove the battery when the unit is not being used for a long period of time

WALL MOUNTING

- The soundbar has two keyhole slots on the rear panel to enable wall mounting, use the clamps and fix it on the soundbar with the help of screws
- Mark two 4.41 inches (920mm) and ø8.2 parallel holes (1/4 inch each) in the wall
- Firmly apply a dowel into each hole in the wall (dowel only required for solid wall).
- Attach the soundbar to the screws on the wall and press and push the soundbar to the right 1/8 inch each to lock.

Fig: Wiring

Fig: Clamps fixed on soundbar

** Pictures are for reference only.*

How to Use

1.Power On: Use the Adaptor to connect the sound bar, plug the adaptor into a wall outlet, it will automatically enter into the standby mode and led indicator with white light will be shown on display.

2.Short press the Power key on S28CS: the sound level automatically goes upto Level 15, press the standby button again to select input option: AUX/BT/HDMI(ARC)/USB

3.Power off: To turn off, press and hold the Power key for 2 seconds or unplug from the wall mount.

Pairing

1) Make sure the S28CS and your device are next to each other (within 1 meter /3 feet).

2) When using the S28CS for the first time, turn on the unit, the Indicator will flash white light regularly. Select "BT" as input source. Now the speaker is in pairing mode.

3) Activate the Bluetooth function on your phone, tablet and search for nearby Bluetooth connections. Find " S28CS " in the search results. Tap on the name to connect.

Using the Soundbar :Paring Modes

HDMI(ARC): Connect an HDMI (ARC) compatible device to the HDMI(ARC) port on the soundbar using an HDMI cable. Select HDMI(ARC) mode either by repeatedly pressing the standby button to select input option: AUX/BT/HDMI(ARC)/USB or repeatedly pressing the input key from the remote control by repeatedly pressing the input key.

Press the stand by key on the soundbar's control panel until "ARC" is displayed on the LED display. Ensure HDMI ARC is selected as audio output, then adjust the volume of the soundbar using the Volume up and Volume down buttons on the remote control or soundbar's control

AUX-in: Connect a compatible device using the 3.5mm jack cable. Select AUX mode either by repeatedly pressing the Input button on the remote control or repeatedly pressing the standby button on the soundbar control panel until nsu is displayed on the LED display . Ensure the connected device is turned on and set to max volume, then adjust the volume of the soundbar the Volume up and Volume down buttons on the remote control or soundbar control panel. buttons on the remote control or soundbar control panel.

Bluetooth: Repeatedly pressing the input button on the remote control or repeatedly pressing the standby button on the soundbar control panel until BT is displayed on the LED display. The LED display will flash to indicate that the soundbar is in Bluetooth pairing mode. Ensure that the device you wish to connect is also in pairing mode and search for S28CS in its device list. When the two devices are paired, the LED display on the soundbar will stop flashing and turn solid. (The soundbar will now automatically re-pair with this device whenever it is within range and has Bluetooth turned on.)

USB Media Mode: The Soundbar is compatible with USB Flash Drive upto 64 gb & can play Mp3,WMV, WAV audio files directly. Simply insert a compatible drive into the USB port on the rear end of the soundbar and the unit will automatically switch to USB mode and play the first compatible track.

If USB Mode is not detected automatically please select the USB option by repeatedly pressing the Standby key on the soundbar and USB mode (also accessed via the remote control via input button).

Equalizer modes: The soundbar has 5 equalizer presets, tailored to complement various styles of music. Press the EQ button on the remote to choose between different sound effects .

We'd Love to Hear From You!

Warranty 12-month limited warranty(The actual warranty period shall be implemented according to the requirements of local laws and regulations). We want to personally reach out and thank you
for purchasing from our Amazon store. Selling an Amazon is what we do to support the family, and positive reviews are the lifeblood of our business.
Thank you again for taking one of our amazing customers!

Customer Cervice:
cici@miless.com

AC POWER

IMPORTANT NOTES

- Make sure the power supply is correct and never handle the power cord or its plug with wet hands when plugging into, or unplugging from an outlet.
- Ensure that the main power switch is in the "OFF" position beforeconnecting to AC power cord to the power supply to avoid damage to the unit.
- A damaged power cord can easily cause an electric shock or fire hazard, never use a power cord after it has been damaged.

Trouble Shooting

Caution	
No power	1. Make sure the S28CS is plugged in and "Power" "Mute"
No sound	1. Make sure you have selected Proper Source 2. Make sure the volume is not plegarly on the unit and the correct input source is selected(Bluetooth,USB,AUX,HDMI(ARC)) 3. Check that soundbar output is not set to quietly 4. Check to see that Bluetooth devices are turned on and have Bluetooth Device to connect to 5. Turn "OFF" or "MUTE" both the device 6. Make sure you have selected the Proper output Mode 7. Make sure the Mute function is "OFF" 8. Move both the device away from other working Bluetooth devices 9. Make sure you are connected to a previously paired device
No search when receiving TV signal	1. Make sure the cable is connected properly 2. Make sure the cabinet is not plegarly on the unit and/or the detection sensor is not blocked by other objects
BT Remote control inoperative	1.The Battery might be dead,replace the battery

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.
If this equipment does cause harmful interference to radio or television reception,
which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different
from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.
FCC ID: 2A8PR-2888

EM-S28CS-083S说明书
Date: 2023.08.02
P/N:

成品尺寸：L87.44*W93.68mm；展开尺寸：L611.83*W93.68mm
材质：80g羽纸
工艺：风琴折，黑白印刷，