Label placement(5056N)

CAUTION
NON-REMOVABLE BATTERY.
ATTEMPTING TO REMOVE THE BATTERY OR THIS STICKER COULD RESULT IN INJURY AND WILL VOID YOUR WARRANTY.
DO NOT ATTEMPT TO DISASSEMBLE, DAMAGE, ALTER OR REMOVE BATTERY FROM DEVICE.
PRESS AND HOLD THE POWER KEY FOR MORE THAN 10 SECONDS TO RESTART.
ESTE ES UN DISPOSITIVO DE UNA SOLA PIEZA, LA BATERÍA NO ES EXTRAÍBLE.
EXTRAER LA BATERÍA O DESARMAR LA CUBIERTA PODRÍA CAUSARLE DAÑOS Y PERDERÍA LA GARANTÍA.
NO INTENTE DESARMAR, ROMPER, DAÑAR O EXTRAER LA BATERÍA DEL DISPOSITIVO.
MANTENGA PULSADO EL BOTÓN DE ENCENDIDO DURANTE MÁS DE 10 SEGUNDOS PARA REINICIAR EL DISPOSITIVO.
ALCATEL
onetouch
>45°C
>113°F
USE ONLY POWER SUPPLIES LISTED IN USER GUIDE
UTILICE SOLAMENTE LAS FUENTES DE ALIMENTACIÓN QUE FIGURAN EN INSTRUCTIVO DE USO
WWW.ALCATELONETOUCH.COM
Model:5056N
HW 02 HAC:M4/T4
Made in China
Date: 07/2016
FCC ID:2ACCJB062
IMEI:014650000000014

Label(5056N)

CAUTION
NON-REMOVABLE BATTERY.
ATTEMPTING TO REMOVE THE BATTERY OR THIS STICKER COULD RESULT IN INJURY AND WILL VOID YOUR WARRANTY.
DO NOT ATTEMPT TO DISASSEMBLE, DAMAGE, ALTER OR REMOVE BATTERY FROM DEVICE.
PRESS AND HOLD THE POWER KEY FOR MORE THAN 10 SECONDS TO RESTART.
ESTE ES UN DISPOSITIVO DE UNA SOLA PIEZA, LA BATERÍA NO ES EXTRAÍBLE.
EXTRAER LA BATERÍA O DESARMAR LA CUBIERTA PODRÍA CAUSARLE DAÑOS Y PERDERÍA LA GARANTÍA.
NO INTENTE DESARMAR, ROMPER, DAÑAR O EXTRAER LA BATERÍA DEL DISPOSITIVO.
MANTENGA PULSADO EL BOTÓN DE ENCENDIDO DURANTE MÁS DE 10 SEGUNDOS PARA REINICIAR EL DISPOSITIVO.
ALCATEL
onetouch
>45°C
>113°F
USE ONLY POWER SUPPLIES LISTED IN USER GUIDE
UTILICE SOLAMENTE LAS FUENTES DE ALIMENTACIÓN QUE FIGURAN EN INSTRUCTIVO DE USO
WWW.ALCATELONETOUCH.COM
Model:5056W
HW 02 HAC:M4/T4
Made in China
Date: 07/2016
FCC ID:2ACCJB062
IMEI:014665000000012

Label(5056W)