75mmX95mm

JM19

使用说明书

请细阅说明书并妥善保管，方便日后使用

产品参数

产品名称	JM19
蓝牙版本	5.4
传输距离	≥10M
喇叭直径	Φ10mm
充电口	Type-C
灵敏度	112dB±1.5dB
耳机电池	5.7V 300mAh
充电舱电池	5.7V 500mAh
耳机续航	1.5-2H
充电时间（充电盒）	1H
充电时间（耳机）	6H
播放时间（耳机）	5.0H（无滤波）
待机时间（耳机）	50H（无滤波）

包装清单

真无线蓝牙耳机	*2
耳机充电仓	*1
Type-C充电线	*1
说明书	*1

操作说明

1.基础说明



1 耳机　2 触摸按键　3 充电接触口
4 手触屏　5 Type-C口　6 开机键

2.模式选择

电话模式
按接来电长按2s
来电:单击接听，再单击挂断

对耳模式
左耳三触:音量降低
右耳三触:音量增加

音乐模式
左耳双触:播放上一曲
右耳双触:播放下一曲
单触:播放/暂停

3.屏幕说明

对耳模式
开机:长按5S
关机:长按5S
唤醒Siri:长按右耳2s

切换功能界面
左右滑动即可切换界面
向左数：上一个界面
向右数：下一个界面

音乐界面
点击图标即可播放/暂停
上下滑动切换

语音设置
上下滑动选择合适的语言
点击即可完成切换

关机界面
选择√关机，选择×退出关机

重启界面
选择√，屏幕会重新启动

出厂设置
清除以往的缓存数据

环境音
ANC主动降噪（25dB）
通透模式

均衡器
提供7种风格选择

定位功能
点击即可搜寻耳机位置

语音助手
点击即可呼唤语音助手

亮度调节
通过点击+、-，可调节屏幕亮度

音效选择
提供5种选择方式，电影/音乐/游戏

低电量提醒
当电量低至剩余5-20%时，耳机会发出提示音，电量低于5%时自动关机

手电筒
提供4种灯效，分别是白、红、黄、绿

拍照
当耳机连接手机蓝牙时，通过点击智能耳机，可控制手机远程拍照

注意事项

提示

1. 使用产品前请仔细阅读本使用说明书并妥善保管
2. 首次使用，请先将本产品充满电
3. 如果产品长期（超过1个月）不用，请对其充电；
4. 若手机无法搜索蓝牙耳机，请确认是否耳机是否处于"配对状态"若长时间未进行配对或连接，蓝牙耳机配对功能将关闭，请重新开启蓝牙耳机至"配对状态"若手机解除出厂，请重启蓝牙耳机，若蓝牙耳机程序出错，请重启蓝牙耳机。

警告

1. 请勿以任何理由拆除或擅修改蓝牙耳机，否则可能会导致起火、电子元件击穿甚至难度拆坏本产品
2. 请勿将设备置于温度过低或过高（0℃以下或 45℃以上）的环境下
3. 请避免激烈、重或剧烈的振动使用设备指示灯
4. 请勿在雷暴天气下使用设备，雷暴可导致设备工作不正常并增加触电的危险
5. 请勿将设备及其他高发射装置放置过本产品
6. 请勿将设备接触腐蚀性溶液

保修说明

尊敬的客户，你好!
亲爱激顾本公司的产品，为了保证你的利益，请您在购买本产品后，仔细阅读说明书以以下内容:（下列情况不属于保修范围，本公司可提供有偿服务，敬请见谅）
1、未按使用说明书操作，使用、保管、维修本产品故障和损坏。
2、擅自涂鸦、刷图产品包装以及外观。
3、擅自改动厂家配件和线缆。
4、部分因素或者人为导致产品损坏，如输入不合格的电压，高温，湿水，敲坏，产品严重氧化或者生锈等。
5、因不可抗拒，如地震，火灾，水灾，雷击等导致的故障和损坏。

JM19

OPERATING INSTRUCTIONS

Please read the instruction manual in advance to facilitate subsequent use

Product Parameter

Product Name	JM19
Bluetooth Version	5.4
Transmission Distance	≥10M
Speaker Diameter	Φ10mm
Charging Port	Type-C
Sensitivity	112dB±1.5dB
Charging Case Battery	5.7V 300mAh
Headphone Battery	5.7V 40mAh
Charge Time (Charging Case)	1.5-2H
Charge Time (Headphones)	1H
Playback time (headphones)	6H
Standby time (headphones)	50H(connector-less)

Packing List

True Wireless Bluetooth Headset	*2
Headphone Charging Compartment	*1
Type-C charging cable	*1
Instruction manual	*1

Operating Instructions

1. Basic description



1 Earcap　2 Touch Key　3 Charging Contacts
4 Touchscreen　5 Type-C　6 Boot Key

2. Mode selection

telephone mode:
Reject call:Long press 2s
Incoming call:click to answer, then click to hang up

In-ear mode
Three touches on the left ear: Volume down
Three touches on the left ear: Volume down

Music Mode
Double-touch in the left ear:Play the previous song
Right ear double touch:Play next song
Single touch:Play/Pause

In-ear mode
Switch on:Long press 5S
Switch off:Long press 5S
Wake up Siri:Long press right ear 2s

3. Screen Descriptions

Toggle Function Interface
Swipe left or right to switch screens
Swipe left: previous screen
Swipe right: next screen

music interface
Click on the icon to play/pause
Switch between up and down songs

Language Settings
Swipe up and down to select the appropriate language
Tap to finish switching

Shutdown screen
Select √ to switch off and x to exit Switch off

Reboot Screen
Select √ and the screen will restart

Setup
Clearing previous cached data

Ambient Sound
ANC active noise cancellation (25dB)

Equaliser
Offers a choice of 7 styles

Positioning Function
Click to search for headset location

Voice Assistant
Tap to call the voice assistant

Brightness Adjustment
The screen brightness can be adjusted by clicking +-

Sound Selection
Offers 3 ways to choose, film /Music/Games

Low battery alert
When the headset is connected to the charging case and the battery level is below 5%, the headset will automatically shut down to conserve power by keeping the charge in reserve.

Electric Hand Torch
Provides 4 light effects, which are white,Red, Yellow and Green

Take A Picture
When the headset is connected to the charging case and the battery level is below 5%, the headset will automatically shut down to conserve power by keeping the charge in reserve.

Caveat

Draw Attention To Sth.

1. Please read the instruction manual carefully before using the product and keep it in a safe place.
2. Please fully charge the product for the first time use.
3. If the product is not used for a long time (more than 1 month), please charge it.
4. If your mobile phone can not search for the Bluetooth headset, please make sure the Bluetooth headset is in the "pairing state" If there is no pairing for a long time, it will enter the "disconnection and pairing function" to turn off Bluetooth or the Bluetooth headset goes into the "pairing state" If the mobile phone program exits,please restart the mobile phone. If the Bluetooth headset is not connected,please restart the mobile phone. If there is an error in the mobile phone programme, please restart the mobile phone. If there is an error in the Bluetooth headset programme, please restart the Bluetooth headset.

Warnings

1. Do not dismantle or modify the headset for any reason, as this may result in fire, breakdown of electronic components or even complete damage to the product.
2. Do not expose the device to temperatures that are too low or too high (below 0℃ or above 45℃).
3. Avoid using the light near the eyes of children or animals.
4. do not use the device in thunderstorms, which may cause the device to operate improperly and increase the risk of electric shock.
5. Do not wipe the product with oil or other volatile liquids.
6. Do not wet the device with liquids.

Warranty Description

Dear customer, hello!
I am grateful for your patronage of our products, in order to ensure that your interests, please read the instructions and the following content carefully after you buy this product: 1 The following circumstances do not belong to the scope of the warranty, the company can provide paid services, please note)
1, not in accordance with the instructions for operation, use, storage, resulting in this product failure and damage.
2, unauthorized graffiti, tearing the product packaging and barcode.
3, unauthorized changes to the factory settings and dismantle the machine for repair.
4, accidental fracture or human-induced damage to the product, such as the input of unsuitable voltage, high temperature, water, damage, serious oxidation or rust of the circuit.
5, due to inevitable, such as earthquakes, fires, floods, lightning strikes and other causes of failure and damage.

FCC Requirement

changes or modifications not expressly approved by the party responsible for compliance could void the user’ s authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

– Reorient or relocate the receiving antenna.

– Increase the separation between the equipment and receiver.

– Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

– Consult the dealer or an experienced radio/TV technician for help.