

4. When you click on the **New** button, the new profile dialog box will show out to allow you to key in some profile data. You may key in a profile name, Network Name to associate to wireless network, Network Type for Infrastructure or Ad-hoc; If you click “ Ad-hoc”, you can click the task bar, then choose the Chanel.



( Profile 1 )



( Profile 2 )



( Profile 3 )

5. When you click the **Advance** button, the Advance dialog box will display. Users can insert and select the data. **WEP** for 64bits or 128bits; In order to enable WEP encryption, hexadecimal values must be inserted in **WEP Key** item. The value must match the Key on all other devices on the wireless network or else this device will be unable to transmit or receive data.



( Advance 1 )