

acer OHR514 TWS Wireless headset

**Customer Services: (978)230-8895(US)
Mon-Fri: 9am-6pm(EST)
User Manual**

Please read this user manual carefully when using this product.

Preface
Thank you for purchasing Acer products. For optimum operation, please read this manual carefully before using.

Model
OHR514

Item Name
TWS Wireless Earphones

Product List
Headphones x2pcs
Charging case x1pcs
Type-C charging cable x1pcs
Instruction manual x1pcs

Product Description
This TWS earphone is a wireless connectivity-enabled audio product, which is compatible with Android and iOS smartphones, tablets, and other portable electronic devices. By eliminating the constraints of wired connections, it offers users enhanced convenience and unrestricted mobility, catering to a wide range of application scenarios.

Product Specifications
Material: ABS
Product Weight: 65.2g
Charging port: type-c
Earphones Size: 45.8*37.8*12.5mm
Charging case size: 73.7*64.2*29.7mm

Product structure diagram

Introduction to product operation

function	operate	Light	Tone
Pair name	OHR514	/	/
Boot	While on the phone, double-click the touch button on any headset	/	/
Shutdown	Put the earphone into the charging bin and shut down automatically. Press the touch button for 5 seconds to shut down the earphone	The white light flashes three times	Power off/关机
Pair the left and right earphones	After the left and right earphones are successfully paired, the blue and red light of the main earphone flashes, and the secondary earphone light is off	After the left and right earphones will automatically enter pairing mode after powering on	Connected/pairing successfully
Toggle the Chinese and English prompt tones	Without connecting the smart device, double-click the left/right ear touch key 4 times, language switch	/	English/中文
Smart device connectivity	When the ears are successfully paired, it will automatically turn off and start charging when they are put back into the charging compartment, the white light of the earbuds will always be on, and the light will turn off when they are fully charged	The lights in the left and right ears are turned off	Connected/连接成功
Charge the headphones	The headphones will immediately charge the smart device, and the left/right ear touch key 4 times, language switch	The lights in the left and right ears are turned off	Connected/连接成功
The charging bin charges the headphones	The headphones will immediately charge the smart device, and the left/right ear touch key 4 times, language switch	The lights in the left and right ears are turned off	Connected/连接成功
Charging bin charging	When the battery is too low, charge the battery with a power adapter with a standard output of 5V. The battery screen lights up and flashes to show the current battery	/	Music/GAME MODE
Toggle Music/ Game mode	Connect the device to the state of the left and right ear touch keys 4 times, mode switching, the factory default music mode	/	Music/GAME MODE
Play/Pause	After the music player starts, double-click the left/right headphones touch button	/	/
Previous song	After the music player starts, click the left earphone touch button three times	/	/
Next song	After the music player starts, double-click the right earphone touch button three times	/	/
Increase the volume	After the music player starts, click the touch button on the right headset	/	Maximum volume indicator (knock)
Reduce the volume	After the music player starts, click the touch button on the left headset	/	/
Voice assistant	Connect the state, long press the left earphone touch button 2 seconds to release; you can wake the voice assistant	/	Ding Dong
Answer an incoming call	When the call is incoming, double-click any left or right earphone function key	/	Ringtone of your phone

Introduction to product operation

function	operate	Light	Tone
Hang up	While on the phone, double-click the touch button on any headset	/	/
Clear the pairing history	Take out the headphones from the charging bin, press the touch buttons on the left and right earphones three to five times to clear the paired devices and automatically shut down. This feature is designed to provide reasonable protection against interference in residential installations. This equipment generates, uses and can radiate radio frequency energy, and if not installed in accordance with the instructions, it may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does not contain any maintenance components.	The white breathing light flashes	Power on/开机
Low battery alarm	Put the earphone into the charging bin and shut down automatically. Press the touch button for 5 seconds to shut down the earphone	The white light flashes every 5 seconds	Ding Dong
Automatic power off	Automatic low battery	Charge the headphones	/
The headphones have an echo	The volume is too loud or the environment is too noisy	Adjust the volume or change the environment	/
There is a murmur from the headphones	Serious external interference or too far away from the phone	Change the location or close to the phone	/
The other party's voice is quiet	The headphones are worn incorrectly or the volume is too low	Adjust the headset wear volume	/
The signal is intermittent	Serious external interference or too far away from the phone	Choose a distraction-free environment or be close to your phone	/

Introduction to product operation

function	operate	Light	Tone
Reject an incoming call	When the call is incoming, press and hold the function button of any left or right earphone for 2 seconds	/	/
Clear the pairing history	Take out the headphones from the charging bin, press the touch buttons on the left and right earphones three to five times to clear the paired devices and automatically shut down. This feature is designed to provide reasonable protection against interference in residential installations. This equipment generates, uses and can radiate radio frequency energy, and if not installed in accordance with the instructions, it may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does not contain any maintenance components.	Charge the headphones	Power off/ shutdown
Low battery alarm	Put the earphone into the charging bin and shut down automatically. Press the touch button for 5 seconds to shut down the earphone	The white light flashes	Power on/开机
Automatic power off	Automatic low battery	Charge the headphones	/
The headphones have an echo	The volume is too loud or the environment is too noisy	Adjust the volume or change the environment	/
There is a murmur from the headphones	Serious external interference or too far away from the phone	Change the location or close to the phone	/
The other party's voice is quiet	The headphones are worn incorrectly or the volume is too low	Adjust the headset wear volume	/
The signal is intermittent	Serious external interference or too far away from the phone	Choose a distraction-free environment or be close to your phone	/

Introduction to product operation

function	operate	Light	Tone
Hang up	While on the phone, double-click the touch button on any headset	/	/
Clear the pairing history	Take out the headphones from the charging bin, press the touch buttons on the left and right earphones three to five times to clear the paired devices and automatically shut down. This feature is designed to provide reasonable protection against interference in residential installations. This equipment generates, uses and can radiate radio frequency energy, and if not installed in accordance with the instructions, it may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does not contain any maintenance components.	Charge the headphones	Power off/ shutdown
Low battery alarm	Put the earphone into the charging bin and shut down automatically. Press the touch button for 5 seconds to shut down the earphone	The white light flashes	Power on/开机
Automatic power off	Automatic low battery	Charge the headphones	/
The headphones have an echo	The volume is too loud or the environment is too noisy	Adjust the volume or change the environment	/
There is a murmur from the headphones	Serious external interference or too far away from the phone	Change the location or close to the phone	/
The other party's voice is quiet	The headphones are worn incorrectly or the volume is too low	Adjust the headset wear volume	/
The signal is intermittent	Serious external interference or too far away from the phone	Choose a distraction-free environment or be close to your phone	/

Introduction to product operation

function	operate	Light	Tone
Hang up	While on the phone, double-click the touch button on any headset	/	/
Clear the pairing history	Take out the headphones from the charging bin, press the touch buttons on the left and right earphones three to five times to clear the paired devices and automatically shut down. This feature is designed to provide reasonable protection against interference in residential installations. This equipment generates, uses and can radiate radio frequency energy, and if not installed in accordance with the instructions, it may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does not contain any maintenance components.	Charge the headphones	Power off/ shutdown
Low battery alarm	Put the earphone into the charging bin and shut down automatically. Press the touch button for 5 seconds to shut down the earphone	The white light flashes	Power on/开机
Automatic power off	Automatic low battery	Charge the headphones	/
The headphones have an echo	The volume is too loud or the environment is too noisy	Adjust the volume or change the environment	/
There is a murmur from the headphones	Serious external interference or too far away from the phone	Change the location or close to the phone	/
The other party's voice is quiet	The headphones are worn incorrectly or the volume is too low	Adjust the headset wear volume	/
The signal is intermittent	Serious external interference or too far away from the phone	Choose a distraction-free environment or be close to your phone	/

Introduction to product operation

function	operate	Light	Tone
Hang up	While on the phone, double-click the touch button on any headset	/	/
Clear the pairing history	Take out the headphones from the charging bin, press the touch buttons on the left and right earphones three to five times to clear the paired devices and automatically shut down. This feature is designed to provide reasonable protection against interference in residential installations. This equipment generates, uses and can radiate radio frequency energy, and if not installed in accordance with the instructions, it may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does not contain any maintenance components.	Charge the headphones	Power off/ shutdown
Low battery alarm	Put the earphone into the charging bin and shut down automatically. Press the touch button for 5 seconds to shut down the earphone	The white light flashes	Power on/开机
Automatic power off	Automatic low battery	Charge the headphones	/
The headphones have an echo	The volume is too loud or the environment is too noisy	Adjust the volume or change the environment	/
There is a murmur from the headphones	Serious external interference or too far away from the phone	Change the location or close to the phone	/
The other party's voice is quiet	The headphones are worn incorrectly or the volume is too low	Adjust the headset wear volume	/
The signal is intermittent	Serious external interference or too far away from the phone	Choose a distraction-free environment or be close to your phone	/

Introduction to product operation

function	operate	Light	Tone
Hang up	While on the phone, double-click the touch button on any headset	/	/
Clear the pairing history	Take out the headphones from the charging bin, press the touch buttons on the left and right earphones three to five times to clear the paired devices and automatically shut down. This feature is designed to provide reasonable protection against interference in residential installations. This equipment generates, uses and can radiate radio frequency energy, and if not installed in accordance with the instructions, it may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does not contain any maintenance components.	Charge the headphones	Power off/ shutdown
Low battery alarm	Put the earphone into the charging bin and shut down automatically. Press the touch button for 5 seconds to shut down the earphone	The white light flashes	Power on/开机
Automatic power off	Automatic low battery	Charge the headphones	/
The headphones have an echo	The volume is too loud or the environment is too noisy	Adjust the volume or change the environment	/
There is a murmur from the headphones	Serious external interference or too far away from the phone	Change the location or close to the phone	/
The other party's voice is quiet	The headphones are worn incorrectly or the volume is too low	Adjust the headset wear volume	/
The signal is intermittent	Serious external interference or too far away from the phone	Choose a distraction-free environment or be close to your phone	/

Introduction to product operation

function	operate	Light	Tone
Hang up	While on the phone, double-click the touch button on any headset	/	/
Clear the pairing history	Take out the headphones from the charging bin, press the touch buttons on the left and right earphones three to five times to clear the paired devices and automatically shut down. This feature is designed to provide reasonable protection against interference in residential installations. This equipment generates, uses and can radiate radio frequency energy, and if not installed in accordance with the instructions, it may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does not contain any maintenance components.	Charge the headphones	Power off/ shutdown
Low battery alarm	Put the earphone into the charging bin and shut down automatically. Press the touch button for 5 seconds to shut down the earphone	The white light flashes	Power on/开机
Automatic power off	Automatic low battery	Charge the headphones	/
The headphones have an echo	The volume is too loud or the environment is too noisy	Adjust the volume or change the environment	/
There is a murmur from the headphones	Serious external interference or too far away from the phone	Change the location or close to the phone	/
The other party's voice is quiet	The headphones are worn incorrectly or the volume is too low	Adjust the headset wear volume	/
The signal is intermittent	Serious external interference or too far away from the phone	Choose a distraction-free environment or be close to your phone	/

Introduction to product operation

function	operate	Light	Tone
Hang up	While on the phone, double-click the touch button		