



HMN: SENSE.TEMP and SENSE PRES

SENSAiO MainBoard – Top view




HMN: SENSE.TEMP and SENSE.PRES

SENSEiO MainBoard – Top view




HMN: SENSE.TEMP and SENSE PRES

SENSEiO MainBoard – 3D Top view



HMN: SENSА.TEMP and SENSА.PRES

SENSAiO MainBoard – Bottom view



HMN: SENSE.TEMP and SENSE PRES

SENSAiO MainBoard – 3D Bottom view




HMN: SENSEA.TEMP and SENSEA.PRES

SENSEaIO Antenna – Top view




HMN: SENSА.TEMP and SENSА.PRES


SENSAiO Antenna – Bottom view




HMN: SENSA.TEMP
SensorBoard Temperature – Top view




HMN: SENA.TEMP
SensorBoard Temperature – Bottom view



HMN: SENSА.PRES
SensorBoard Pressure – Top view




HMN: SENA.PRES
SensorBoard Pressure – Bottom view



HMN: SENA.TEMP and SENA PRES

SENSAiO Cartridge – Assembly view



HMN: SENA.TEMP and SENA PRES

SENSAiO – Cartridge to SensorBoard connection



HMN: SENSА.TEMP and SENSА.PRES

SENSAiO – Assembly view

