

[illegible]

WOODCESSORIES®

THANKS FOR CHOOSING WOODCESSORIES!

CHARGE SMART. CHARGE SUSTAINABLE!

www.woodcessories.com

WOODCESSORIES®

NATURE MEETS TECH!

BE FLEXIBLE. CHARGE ALL YOUR Q! DEVICES!

*Fast USB charging option, use USB-C to USB-A or higher power adapter.
Speed, tested: 1.5x faster. Available December 1st.

CHARGING GUIDE




Need help?
hello@woodcessories.com

Please read the instructions carefully before using the Wireless Charger!

INSTRUCTION

- 1.Connect your charger to power. Use the USB-C cable with connect with a power outlet or laptop. **Highly recommended:** Connect the USB-C cable to 20W (or higher) power adapter. Once the charger is connected to power the LED light will flash for 3 seconds.
- 2.Place the Single Charging Pad on a flat surface like your desk.
- 3.Place your wireless charging enabled phone in the centre of the charger. Especially for iPhone MagSafe models or cases with built in magnets.
- 4>Your smartphone should start charging a second after you place it on your charger. This LED light will stay on to showstart the charging process.
- 5.As an additional, free adapter gives you the ability to switch from USB-C to USB-A ports

RECOMMENDATION



NOTE: Connect the USB-C cable to 20W (or higher) power adapter to reach 1500mAh charging

THINGS TO WATCH

if your phone vibrates your phone might with position. if this happens often, consider turning vibration mode on.

if your phone doesn't get any power while it's charging. This is caused by several things. You might consider moving the charger to a cooler place.

important: Your phone or phone case cannot carry any metal materials, which will stop the charging process, such as rings, bags, metal plates. If the LED starts to blink the FOD (foreign object detection) noticed a problem. Please re-connect your charger with power if this happens.

ENJOY FAST & SUSTAINABLE CHARGING!