

User Manual

Dear customer:

First of all, thank you for your trust in our products. In this world, we met and reached an agreement. Your trust is our most precious gift, and we are very honored and cherished!

If you are satisfied with our products, please share with your family and friends. At the same time, please pay attention to whether there are related praise gift activities on the homepage of the purchased sales platform product. We sincerely look forward to your participation and hope that you can click on all the stars in the evaluation as an encouragement to our customer service.

Your evaluation is the life of our company's sustainable development! If you have any questions or help about our products, please contact us as soon as possible through the Amazon website, so that we have the opportunity to provide you with timely and effective help and give us praise. Thank you very much for your tolerance and support! I wish you and your family health and happiness forever. All the staff of SGIN look forward to seeing you again!

-----SGIN Brand Division

Contents

- 1. Precautions before Use, Intended Use
- 2. Introduction to Desktop
- 3. Basic Operations
 - 1.Sleep, restart and shut down
 - 2.WIFI、Bluetooth、Flight mode
 - 3.Cortana
 - 4.System and BIOS ---- system reset
 - ---- BIOS-setting&Bootmanager
 - 5.Battery charging
- 4. Troubleshooting



Charge the battery for at least 12 hours before initial start-up.

Parameter configuration

- 1. This product is suitable for use in non-tropic areas below 2,000 meters
- 2. Prevent this product from falling to the ground it could be strongly damaged.
- 3. Keep the device away from rain, moisture, direct sunlight and heat source.
- 4. Avoid using it in the strong magnetic and strong static environment as much as possible.
- 5. Once any water or other liquid splashes onto this product, close it immediately and do not use it until it dries out.
- 6. Do not clean this product with any detergent containing chemical elements or other liquid to avoid causing damage due to corrosion and becoming damp. If cleaning is really necessary, clean it with dry soft cloth tissue paper.
- 7. Handle the screen gently. To clear fingerprints or dust on the screen, use soft cloth dedicated for camera lens instead of gauze.
- 8. Please back up your important files at any time to avoid loss.
- 9. Please do not disassemble this product by yourself; otherwise you will lose the right to warranty.
- 10.Do not disconnect the device from power suddenly when formatting or up lo ad in g and downloading, which can lead to program errors.
- 11.Please use the original AC adapter for charging. Nonconforming chargers may cause harms.
- 12. Protect the power cord. When connect the power cord, do not step onto it or place any object on it, which may cause extrusion. Protect the connector of the power cord connected devices specially.
- 13 Batteries

The batteries in this product can not be easily replaced by users themselves. Replacement with incorrect type batteries may cause explosion.


- 14. While using the earphone, if the volume is excessively high it may cause hearing damage. So please adjust the volume of the player to a moderate level and balance the time of using.
- 15. Pictures in this manual are for demonstration purpose only and may differ from the real product.

16. Caution!

This unit contains battery. If the battery is defective, it should not be disposed of with household Waste Batteries can possibly

contain harmful substances that can harm the environment and peoples health. Please dispose of the battery commercially or at a municipal recycling plants. Return is free of charge and is prescribed by law. Please only dispose of empty batteries in the containers provided and tape the terminals.


Accessories





Power Adapter


Quick installation of Sgin.



Plug in the adapter to power SGIN and charge the battery at the same time.

Use of SGIN laptop.

Boot steps.





Quickly press the power button to turn on the SGIN Laptop.

When the SGIN logo appears on the screen, please wait patiently for some time and follow the system prompts to enter the system.

Sleep, restart and shut down.



Same experience as you use Desktop PC. Click the on the bottom taskbar, and then click the (). Finally, in the pop-up menu options, you can choose hibernation, shutdown or restart.