

LTE Measurement - V3.5.50 - Base V 3.5.120 - TX Measurement

Multi Evaluation PRACH SRS

FDD Freq: 2502.5 MHz Ref. Level: 40.10 dBm BW: 5.0 MHz CP: Normal Meas Subfr/Slot: 2 / All

IO Constellation

PS: Connection Established RRC State: Connected

Go To Local Show Remote Screen

LTE

Multi Evaluation RDY

RF Settings


Trigger

Display

Signaling Parameter

LTE Signaling ON

**Band7-5MHz-QPSK-21100-25RB#0**



LTE Measurement - V3.5.50 - Base V 3.5.120 - TX Measurement

Multi Evaluation PRACH SRS

FDD Freq: 2535.0 MHz Ref. Level: 40.70 dBm BW: 5.0 MHz CP: Normal Meas Subfr/Slot: 2 / All

IO Constellation

PS: Connection Established RRC State: Connected

Go To Local Show Remote Screen

LTE

Multi Evaluation RDY

RF Settings


Trigger

Display

Signaling Parameter

LTE Signaling ON

**Band7-5MHz-QPSK-21425-25RB#0**



LTE Measurement - V3.5.50 - Base V 3.5.120 - TX Measurement

Multi Evaluation PRACH SRS

FDD Freq: 2567.5 MHz Ref. Level: 41.00 dBm BW: 5.0 MHz CP: Normal Meas Subfr/Slot: 2 / All

IO Constellation

PS: Connection Established RRC State: Connected

Go To Local Show Remote Screen

LTE

Multi Evaluation RDY

RF Settings


Trigger


Display

Signaling Parameter

LTE Signaling ON

**Band7-5MHz-16QAM-20775-25RB#0**






**Band7-10MHz-QPSK-21100-50RB#0**

LTE


- Multi Evaluation **RDY**
- RF Settings
- Trigger
- Display
- Signaling Parameter
- LTE Signaling **ON**



**Band7-10MHz-QPSK-21400-50RB#0**

LTE

- Multi Evaluation **RDY**
- RF Settings
- Trigger
- Display
- Signaling Parameter
- LTE Signaling **ON**



**Band7-10MHz-16QAM-20800-50RB#0**

LTE

- Multi Evaluation **RDY**
- RF Settings
- Trigger
- Display
- Signaling Parameter
- LTE Signaling **ON**

