





2, Hardware description:

- 1. HDMI: HD output
- 2. Mic power support: 5V / 2a, 5V / 1a, 5V / 0.5A 3. Handle interface: wired handle, wireless handle,

one second-hand handle; USB2.0 Interface

4. Indicator light: blue indicator light is on when

connecting to the power supply

5. Support maximum 128g expansion TF Card

3. Function description

- 1. Supporting languages: Simplified Chinese, traditional Chinese, English and other 23 languages
- Support simulator: CPS; GB; GBC; GBA; MD; SFC;

4. Main menu function

1. List: all the Games in the folder will be displayed on this page, with up and down selection and left and right page turning $\,$ (in what simulator the game is in, there will be prompts on




2. Classification: identify all simulators contained in the



3. History: after playing, the game record will be in this



4. Collection: your favorite games can be added to the collection list



5. Search: filter the game according to the game name uppercase letters (Note: case insensitive)



- 1. Press the direction key to select the game menu and press the start $\!\!\!/$ a key to enter the game
- 2. Press B in the game list to return to the home page 3. Holding down the SELECT/START key at the same time in the game brings up a game menu that allows the user to Pause/save/load/exit the game

b. Settings



key tone, search local file, restore default setting and exit, system information, exit setting

5. Hardware function definition

o. IDetai	led parameters
game	Support: CPS, FC, GB, GBA, GBC, MD, SFC, PS1; Atari arcade game
Power supply	5V/1A, 5V/2A, 5V/0. 5A
extend	Support TF card expansion, maximum 128GB
Video output	HDMI HD output

- 1. The picture of the machine is for reference. The shell of the machine is subject to the material object. The instructions are only for reference. The software upgrade of the machine is subject to the material object.
- 2. If there is any change in the product content or parameters, please refer to the current product without notice.
- 3. The machine is stored in zero files at the factory. All external files (audio, video, games, pictures, etc.) must be deleted immediately after the demonstration. The company will not take any responsibility for this.
- 4. Charging method: please use the output 5v-la charger, connect the data cable to the USB port of the machine for power $\,$
- 5. Executive standard: gb17625.1-2012, gb8898-2011, GB /t13837-2012
- 6. Children between 6.0 and 14 years old need to be accompanied by an adult to use this product.
- 7. Download instructions: please download the game according to the format supported by the machine, and put it in the
- corresponding folder of the machine Warranty

1. Within seven days from the date of sale, in case of

- performance failure, the body and package of the goods must be intact, and the same type of goods can be replaced (subject to inspection), but not including artificial damage
- 2. The goods are guaranteed for one year from the date of sale, with lifelong maintenance, and the accessories are not covered by the warranty

- 3. The warranty service is only valid under normal use. and all artificial damages (including self disassembly and improper use) are not covered by the warranty.
- 4. This card shall be provided during warranty. If this card is not provided or altered without permission, the company has the right to scrap it

		F	ackaging	g accesso	ries		
olor box	machine		instru ctions		wireless handle	receiver	HDMI extension cable
*1	*1	*1	*1	*1	*2	*1	*1
		Pr	oduct w	arranty	card		

	iloddol wailaity	- Can G		
User name	Gender		Age	
mailing address				
contact number			Zip code	
Place of purchase				

Date of purchase	Sales Order No	
Product name and specification	Serial No	
Dealer signature	User signature	



When the ambient temperature is less than or equal to 0 °C, the hours before use





3. 手柄接口: 有线手柄, 无线手柄, 一托二手柄; USB2. 0接口

- 4. 指示灯:接入电源有蓝色指示灯亮 5. 支持最大 128G 扩展 TF 卡

3、 功能描述

- 1. 支持语言:中文简体,中文繁体,英文等 23 国语言
- 2. 支持功能: 收藏, 历史, 搜索
- 3. 支 持 模 拟 器 CPS;GB;GBC;GBA;MD;SFC;FC;;PS1;ATARI.
- 4、 主菜单功能
- 1. 列表: 文件夹所有游戏会在此页面显示,上下选择,左右翻页 (游戏在什么模拟器中, 屏幕中上会有提示)




2. 分类: 识别机器包含的所有模拟器

- - 3. 历史: 玩过以后的游戏记录会在此界面



4. 收藏: 自己喜欢的游戏即可添加到收藏列表



5. 搜索:按照游戏名称大写字母来对游戏进行筛选(注:不区分大



1. 方向键选中游戏菜单,按 START/A 键进入游戏

2. 游戏列表中按 B 键返回主页 3. 在游戏中同时按住 SELECT/START 键会出现游戏菜单,用户可 对游戏进行暂停/保存/载入/退出等操作



- 1. 手柄按 SELECT 键进入设置列表,语言,按键音,查找本机文 件,恢复默认设定并退出,系统信息,退出设置。
- 5、硬件功能定义 5.1 详细参数

游戏	支持: CPS, FC, GB, GBA, GBC, MD, SFC, ; PS1; ATARI 街机游戏
电源供电	5V/1A, 5V/2A, 5V/0. 5A
扩展	支持 TF 卡扩充,最大 128GB
视频输出	HDMI 高清输出
各注 :	1

- 1. 此机器图片供参考机器外壳以实物为准,使用说明只提供参考,

机器软件升级 按实物为准。

- 2. 如产品内容或参数有变更时,请以当前产品为准,恕不另行通知。 3. 本机出厂为零文件储存,所有演示时外来所有文件(音频,视频, 游戏,图片等)必须在演示后立即删除,本公司对此不承担任何责任。
- 4. 充电方法: 请使用输出 5V-1A 充电器,连接数据线连接机器 USB 口进行通电
- 5. **执行标准:** GB17625.1-2012,GB8898-2011,GB/T13837-2012
- 6. 0 到 14 岁以下儿童需成人陪同下使用本产品。
- 7. 下载说明: 请按机器所支持的格式下载游戏, 在放到机器对应文 件夹当中即可

保修条款

- 1. 商品自售出之日起七日内,如发生性能故障,商品机身 及包装必须保持完整,可换同种型号商品(须经检查),但不包括 人为损坏。
- 2. 商品自售出之日起保修一年,终身维护,配件不在保修范
- 3. 保修服务只在正常使用下有效,一切人为损坏(包括自行 拆机,使用不当)不在保修范围内。
- 4. 保修时需提供本卡,未能提供本卡或私自涂改本卡,本公 司有权作报废处理。

	产品保	修卡				
用户姓名		性别			年龄	
通信地址						
联系电话				邮练	iii	
购买地点						
购买日期	4	销售单号	클			

包装配件

彩盒 机器 USB线 说明书 合格证 无线手柄 接收器 HDMI 延长线

警告 窒息危险-所有包装物料(如胶带、 塑料袋、塑胶片、捆绑线、标签)以及 机内细小配件,勿让3岁以下儿童接触, 以免发生窒息危险,并在成人监护下使用

机身编号

用户签名

品名及规格

FCC Warnning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection againstharmful interference in a residential installation. This equipment generates, uses and can radiateradio frequency energy and, if not installed and used in accordance with the instructions, maycause harmful interference to radio communications. However, there is no guarantee thatinterference will not occur in a particular installation. If this equipment does cause harmfulinterference to radio or television reception, which can be determined by turning the equipmentoff and on, the user is encouraged to try to correct the interference by one or more of thefollowing measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1)This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.