

# IP67 Waterproof Bluetooth Speaker

## User Manual



## Speaker Operation

- ① Power On: Hold the power button for 3 seconds to switch speaker on and 5 seconds turn off.
- ② Previous/V-: Short press to play the previous music. Press and hold to turn down the volume.
- ③ Next/V+: Short press to skip song. Press and hold to turn up the volume.
- ④ PLAY/PAUSE :Play or pause the music.
- ⑤ PHONE button: Pick up or hang up the phone, Double click to redial the last number.

## Detail as following

- Short Press to answer the phone calls when incoming calls are indicating.
- Short press to hang up after finish talking on the phone.
- Long press (hold around 3 seconds) to reject the phone calls when incoming calls are indicating
- Press twice quickly to redial the last phone number

- Long press (hold around 3 seconds) to cut off the bluetooth pairing that connecting to your mobile phone
- Short press to control the Apple Siri

**Notice: Once the speaker paired and connected to your mobile phone successfully, next time when you switch on this speaker, it will connect to your mobile phone automatically as long as the Bluetooth is on in your mobile.**

## Key Feature

- Waterproof IP grade : IP67
- Bluetooth 3.0 wireless
- Hand free talk support
- Dedicated Suction Cup
- Charging by USB
- Siri Control

## Specification

- Frequency Range: 100Hz-20KHz
- Operating Distance: 10 Meters
- Built in Microphone
- Power Rating: 3W
- SNR:  $\geq 85dB \pm 2dB$

- Battery Capacity: 650mAh
- Charging Voltage: DC 5V
- Charge Time: approx. 3 hours
- Playing Time: approx. 6 hours
- Housing Material: ABS

## Packing Content

1. Waterproof Bluetooth Speaker
2. USB Charging Cable
3. Dedicated Suction Cup
4. User Manual

## Bluetooth Pairing

Please make sure your cellphone (or media player device) is Bluetooth enabled. Specific pairing steps may vary with different devices. Please refer to the user manual of your device for further information.

5. To enter to pairing mode, first be sure that F012 speaker is in power off mode. Press and hold power button until the LED light blinks in blue rapidly
6. Activate the bluetooth device search function

from the media players such as smartphone, tablets or music players

7. Choose device name "My speaker F012" from the list of bluetooth devices discovered and pair with the media player. Enter password "0000" if applicable

8. The blue LED light will flash regularly when the pairing is successful and connected to Bluetooth

## Charging the Speaker

The Bluetooth speaker is powered by a built-in rechargeable lithium battery that can be operated by the following steps:

1. Release the DC 5V charging port cover.
2. Connect the standard USB plug end of the cable to a power USB port on a computer or other USB charging device. For first time use, a fully charge is recommended.
3. A red LED is on while the unit is charging and off when the speaker is fully charged.

## Application

Compatible with Smartphones, iPhone, Tablet, iPad, iPod, Android & Bluetooth Devices with Built-in Mic for wireless Speakerphone and music playing. Dedicated Suction Cup and IPX7 Waterproof for Showers, Bathroom, Pool, Boat, Car, Beach, Boat, Office, Indoor & Outdoor Use.

1. In the shower room :stick the suction cup on the smooth wall or mirror.
2. In the pool: place speaker upside down with its floating.
3. In the car: stick suction cup to the windshield of the car  
If need to remote control your phone (such as phone call or play music), please short press the phone button, then you can remote control via Siri .( Currently support Apple device of the version more than iPhone4s/iPad2)

**Notice: Please make sure the plug covered tight before drop in the water, otherwise it will broken easily.**

## Troubleshooting

Symptoms	F012 speaker can't be powered on	Not able to pair with the speaker	Volume too low
Causes	Low battery level	F012 speaker already on or not to the pairing mode	Battery is not charged up or volume is not set to the maximum on F012 speaker & media player
Solutions	Recharge the battery	Refer to "Bluetooth Pairing" section	Increase the volume via press & hold the volume up button on F012 speaker. Increase the volume on the media players

## Safety Instructions

- Read this manual carefully before operating
- Do not use this device near any heat sources such as radiators, heaters, stoves, or other heat-producing machinery.
  - Do not leave it in direct sunlight.
  - Keep the speaker out of children's reach to

- avoid a choking hazard.
- Clean with soft cloth. Do not use harsh chemicals to clean.
  - Do not clean this device when it is charging. Always unplug from the power source before cleaning the device.
  - Do not insert any metal object into the device. Risk of short circuit.
  - Do not try to repair or open this device yourself.



This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.