Operation Manual of Product

key finder

Model: WD01



Please read this user manual completely and keep it with proper care

Product introduction

This remote mutual finder can help you to find the lost keys, remotes, purse, eyeglass, cane, and other easily lost items quickly.

With just one press on the button, the beep sound and flashes will lead you to find the lost items.

This product integrates the functions of transmitting and receiving, which is more convenient to use.

This product comes with flashlight function, which is more convenient to use.

Product diagrams



2×Mutual finder



Change the battery

This product battery has been installed, Pull out the insulating sheet and use it.

If the battery needs to be replaced, please prepare CR2032 battery.

- 1. Remove the battery door of the product, remove the old battery.
- 2. Put new battery into the battery compartment, make sure the "+" side of the battery is facing up.
- 3. Push the battery door back into place.



Protect the environment and respect the law. Please handle the old battery properly .

Never discard it by throwing into a garbage bin.

Function use

- 1. Attach the product to your frequently lost items.
- 2. Press the launch button of another product.
- 3. If the receiver is in rang(30 meters), it will beep and meanwhile the LED indicator will flash.
- 4. If no beep is heard, change your location or use new batteries and press the button again.
- 5. When you need lighting, please press the flashlight button of the product.
- 6. On/off: Press the switch three times continuously and quickly to turn it off, and then press it again to turn it on.

Specification parameters

Battery: CR2032 (Has been installed)

Battery life: 12 months

Working rang: 30-50 meters (Open space)

Sound: 70-85db

Frequency: 433.92MHz

Fault self inspection

If the LED of the product is dim or has no function, please replace the battery and try again.

If the buzzer of the product doesn't sound or the volume decreases, Please replace the battery and try again.

If the flashlight is dim or does not light. Please replace the battery and try again.

Important notice

Do not use this product in humid environment.

This product is not a toy, please keep it away from children to avoid eating by mistake.

Do not use liquid, spray cleaner or wet cloth to clean this product.

Keep away from water sources and heat sources when using, so as not to damage products and pose potential safety hazards.

FCC Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.