

<p><b>EN AD</b></p> <p><b>N06-A</b> User Manual</p> <p>Thanks for using our wireless electronic products. For a good user experience, please read the manual carefully before using the products. Notice: To avoid unnecessary troubles, please do not disassemble these products by yourself, and please use the standard charger to charge.</p>	<p>Make sure that the ear caps face down and put the earbuds into the ear in the angle shown as the picture on the right.</p> <p>After putting on the earbuds, gently rotating the earbuds to a comfortable and secure position shown as picture 3 on the right. Now the earbuds are put on correctly.</p> <p><b>Error demonstration</b> Do not wear the earbuds like the way shown as the picture on the right.</p>	<p>3. Open the cover of the charging case and take out the two earbuds. They will turn on and pair automatically and will be prepared for pairing to the phone.</p> <p><b>Warm notice:</b> If the earbuds are not turned on or there is no sound come out, please put them back in the charging case again to make sure that they are in the charging case before taking them out for use (red/white light flash alternately).</p> <p>4. The indicator of one earbud will go off and another will flash red and white light alternately (in pairing mode).</p>	<p><b>Button control</b></p> <p>The earbuds will automatically turn on after opening the top lid of the charging case.</p> <p>OR</p> <p>Press and hold the touch button for 5 seconds, then leave hold, the earbuds will turn on (Not in the charging case and is in the off state).</p> <p>ON</p> <p>Put the earbuds into the charging case and close the lid, they will automatically shut down.</p> <p>OR</p> <p>While in the non-working state, press and hold the touch button for 6s, the two earbuds will be turned off at the same time.</p> <p>OFF</p> <p>Automatically shut down after not connected for more than 5 minutes.</p>	<p><b>Siri and other Voice Assistant</b></p> <p>iOS and part of the Android users can triple touch the left or right haptic button to turn on the voice assistant.</p> <p>The voice assistant will be automatically activated depends in different OS in mobile system.</p>	<p><b>Earbuds indicator</b></p> <p><b>Steps of charging for earbuds:</b></p> <p>The earbuds will be charged when put into the charging case, and they will automatically turn off and disconnect when the charging case lid is closed.</p> <p>Turn on: White light flashes for one second Turn off: Red light flashes for one second Connect with mobile phone successfully: No light Music play: No light Talk time: The white light of the main earphone flashes. The light of the voice earphone goes out. Re-connection state: The red white light of the main earphone flashes. The light of the voice earphone goes out. Low battery: Red light of earbud flashes once every 6s Charging: Red light on Full battery: Red light off</p>	<p><b>Specifications</b></p> <p>Version: V5.2+EDR Support: HFP/HSP/A2DP/AVRCP Transmission distance: 10m Frequency range: 2,402GHz-2,480GHz Audio frequency range: SBC/AAC Speaker: Ø10mm*2 Impedance: 32Ω Standby time: 100 hours Talking time: 6 hours Playing time: 7 hours Earbud battery capacity: 45mAh Earbud delay: 196.2ms Charging case battery capacity: 380mAh Charging time of charging case: About 1 hour Weight (single earbud): 4.8 g</p>	<p><b>Charging the charging case</b></p> <p>When the battery level is less than 10%, the orange light flashes frequently. Please use a charger with an output voltage of DC5V/1A to charge the charging compartment, and you can use a computer USB or other USB interface charger (Must choose a charger certified by a regular manufacturer).</p> <p><b>Notice:</b> 1. If the charging case is out of power, it may cause the earbuds to fall to shut down and remain connected to the phone even when they are placed in the charging case. So please remember to charge the charging case in time.</p> <p>2. If moisture remains at the audio output hole, the sound may become fuzzy or completely inaudible. This is completely normal. In this case, please remove the earbuds and shake the audio output hole down several times to allow water to flow out or let it dry for 1-2 hours, then the sound quality will become normal.</p>	<p><b>Charging case:</b> The charging case is not waterproof. Do not use hot water to disinfect the product.</p> <p><b>Tip:</b> 1. If the product is dirty, please do not rub it directly with water or use boiling water to soak and disinfect it. It is recommended to wipe the earbuds with an alcohol cloth or a wet paper towel. 2. If the product falls into the water accidentally, please pick it up in time and dry it with natural wind or dry it in the sun for two hours before using it. (Otherwise it will affect the sound quality, thus fail to give you a better using experience)</p>
<p><b>Product overview</b></p> <p>MFB Touch Button Earbud Cap Microphone Charging case indicator light Magnetic Contacts Type-C Charging Port</p> <p>1. Choose the ear cap that suits you.</p> <p>2. Put the earbuds into the charging case and close the lid to charge (the earbuds are in charging state).</p>	<p><b>First time using</b></p> <p>1. Take out the two earbuds from the charging case and peel off the insulating film.</p> <p>2. Put the earbuds into the charging case and close the lid to charge (the earbuds are in charging state).</p>	<p>5. Turn on the Bluetooth function on your phone and search for <b>N06-A</b> and connect it.</p> <p><b>Warm notice:</b> 1. If you want to switch the Bluetooth connection to another device, please disable the Bluetooth function in the previously connected device OR delete the pairing name of "N06-A" from the original device. Then the pairing name of "N06-A" can be searched in new device and connected successfully.</p>	<p>1. Accept / 2. Decline / 3. Play / Pause / 4. Previous track / 5. Next track / 6. Volume+ / 7. Volume- / 8. Voice assistant</p> <p><b>Warm notice:</b> For any single earbud, when it is in standalone mode, you can't use it to play the previous song or decrease the volume.</p>	<p><b>Restore factory setting</b></p> <p>1. Please turn off the Bluetooth of the mobile phone. When the red and white lights of the two earbuds are blinking, press the earbud 4 times quickly. The earbud will shut down after the reset is successful.</p> <p>2. Delete the old pairing name on the Bluetooth terminal of the mobile phone and connect the earbud after it is turned on.</p>	<p><b>Charging case indicator</b></p> <p>Status: Indicator Low Battery: Orange light flashes Charging to case: Orange light on Full battery: White light on Charging case lid opening/closing: White light on for 3s (Orange light on opening/closing) Two earbuds in charging state: White light flashes 4 times, then the white light stay on for 10s One earbud in charging state: White light flashes twice, then the white light stay on for 10s</p>	<p><b>Voice prompt</b></p> <p>Power on: Power on Power off: Power off Call reminder: Incoming Call Call ringing: Incoming Call Pairing mode: Pairing Volume maximum: Volume maximum Volume minimum: "Too" Previous/Next track: "Volume" Connection failed/Distance disconnect: Disconnected Connection succeeded: Connected Low power alarm: Please charge Accept/Decline: "Too" Earbud TWS Paired successfully: Connected</p>	<p>3. If there is noise, broken sound, or low sound, please take off the silicone ear cap and wipe it with a cotton swab.</p> <p>4. If the earbud is not charged properly, wipe the charging column with a cotton swab, and then charge it again.</p>	<p><b>Attentions</b></p> <ol style="list-style-type: none"> <li>Do not use corrosive liquid to clean this product.</li> <li>If it comes into contact with chemicals, please rub it with a damp cloth wet with clean water.</li> <li>Do not use this product under extreme circumstances for temperature below +10 degree Celsius or above 60 degree Celsius.</li> <li>To avoid explosion, please do not touch this product into fire.</li> <li>To avoid scratches, please do not touch the earbuds with sharp objects.</li> <li>Do not insert objects into the earbuds, otherwise it would cause damage to the internal components.</li> <li>Do not disassemble the earbud.</li> <li>Please keep regular charge to earbuds, don't leave them become empty battery status to keep their lifetime.</li> <li>Please do not charge products with power adapter over 2A current. Excessive current may cause the damage to battery.</li> </ol> <p><b>Battery Warning!</b> There is a built-in lithium battery in this product. To avoid explosion, do NOT expose the product to strong sunlight or throw it into fire.</p>
<p><b>JP AD</b></p> <p><b>N06-A</b> 取扱説明書</p> <p>本社のワイヤレス製品をご購入いただき、誠にありがとうございます。より良い使用感を得るため、ご使用前にマニュアルをお読みください。取扱説明書はご運送ください。付属充電器で充電することをお勧めします。</p>	<p>耳のキャップが眼を下にし、右の図例として表示される角度で耳にイヤホンをお付けください。</p> <p>イヤホンの上に置くことの後、緩やかに、Avatar 3表示している状態で安全な位置に、イヤホンをお付けしてください。今すぐイヤホンが正しく繋がります！</p> <p><b>エラー</b> イヤホンは右と左の耳が反対です。図に示すように右の耳を</p>	<p>3. 充電ケースのカバーを開いてイヤホンを取り出すと、イヤホンの電源が自動的にオンになり、相互接続され、ペアリングの待機モードになります。</p> <p><b>重要提示:</b> イヤホンが起動しない場合や音が出ない場合は、充電ケースに入れて充電状態を確認してください。</p> <p>赤/白ランプ点滅</p> <p>4. 左右ペアリング時に充電ケースの1つは点滅が止まりますが別のイヤホンは赤/白ランプ交互に点滅します。</p>	<p><b>MFBボタン機能紹介</b></p> <p>1. 電源オン / 2. 受話 / 3. 受話拒否 / 4. 一時停止/再生 / 5. 音量+ / 6. 音量- / 7. Siri等の呼び出し</p> <p><b>注意:</b> 片耳として、曲戻りと音量減少をサポートできません。</p>	<p><b>Siri呼び出し</b></p> <p>iOSシステム端末または一部のAndroidシステムと接続状態で左耳イヤホンor右耳イヤホンを3回連続タッチし、赤と白のランプが点滅し、4回タッチすると、リセットが成功します。イヤホンはシャットダウンします。</p> <p>音声アシスタントは自動的にモバイルシステム内の別のOSに依存してアクティブになります。</p>	<p><b>イヤホン充電ステータス</b></p> <p>イヤホン充電ステータスを入れて、充電します。蓋を閉めてイヤホンは自動的にシャットダウンします。</p> <p>充電ステータス 充電ケース充電中: オレンジランプが点滅 充電ケース充電完了: オレンジランプが点滅 充電ケース充電完了: 白ランプが点滅 充電ケースオン/オフ: (低電圧警告ランプが点滅)</p>	<p><b>商品規格</b></p> <p>バージョン: V5.2+EDR プロファイル: A2DP/AVRCP/HFP/HSP 通信距離: 10 m 使用周波数: 2,402GHz-2,480GHz オーディオコーデック: SBC/AAC スピーカー: Ø10mm*2 電気抵抗: 32Ω 待機時間: 100時間 通話時間: 6時間 音楽再生時間: 7時間 イヤホンバッテリー容量: 45mAh イヤホンの遅延: 196.2ms 充電ケースバッテリー容量: 380mAh 充電時間: 約1時間 互換イヤホンの重要: 4.8 g</p>	<p><b>充電ケース充電中</b></p> <p>電圧量が10%以下で、白ランプの点滅数が点滅します。出力電圧はDC5V/1Aの充電器で充電してください。パソコンのUSBや他のUSBポートの充電器で充電できません。(正規メーカーが認証した充電器を選択しなければなりません。)</p> <p><b>注意:</b> 1. 充電ケースは電気がない場合、イヤホンを充電ケースに入れたときにイヤホンはシャットダウンしません。また、大きな音の状態で充電しています。そのときはすぐに充電ケースに充電してください。</p> <p>2. イヤホンの中に水分が残っている場合、音声はぼんやりと聞こえない場合があります。これは通常のことです。イヤホンを取り出して十分に乾燥させておきましょう。自然に乾かした後に、日光の照らさず2時間自然風乾した後、音が正常に戻ります。</p>	<p><b>充電ケース:</b> 充電ケースは防水ではありません。お湯で洗わないでください。</p> <p><b>注意:</b> 1. 製品の汚れがひどい場合は、直接洗わずに、お湯に浸して洗ってください。アルコールや漂白剤やフロッピーで耳垢を拭くのがおすすめです。 2. 水に落ちたら、自然に乾かしたり、日光の照らさず2時間自然風乾した後、音が正常に戻ります。</p>
<p><b>商品図面</b></p> <p>MFBタッチボタン イヤホンマイク マイク ケースインジケータ 磁気充電ポート Type-C充電口</p> <p>1. 両耳イヤホンを取り出して充電ポートに貼り付けている絶縁膜を剥いてください。</p> <p>2. 両耳イヤホンケースに装着してください蓋を閉めて充電します。(イヤホンは充電状態になります)</p>	<p><b>初めて使用する</b></p> <p>1. 両耳イヤホンを取り出して充電ポートに貼り付けている絶縁膜を剥いてください。</p> <p>2. 両耳イヤホンケースに装着してください蓋を閉めて充電します。(イヤホンは充電状態になります)</p>	<p>5. スマホのBluetooth機能を開き、デバイス一覧から「N06-A」というデバイスを選択して接続してください。</p> <p><b>ご注意:</b> 1. 両耳イヤホンがペアリングできない場合、どちらかのイヤホンが充電されていない場合、古いバージョンのソフトウェアをインストールして、2つのイヤホンの両方を充電してください。その後はペアリングが成功します。 2. 両耳イヤホンがペアリングできない場合は、MFBボタンを3回連続してタッチしてください。 3. スマホは必ず充電されているか確認してください。</p>	<p>1. 受話 / 2. 受話拒否 / 3. 一時停止/再生 / 4. 音量+ / 5. 音量- / 6. Siri等の呼び出し</p> <p><b>注意:</b> 片耳として、曲戻りと音量減少をサポートできません。</p>	<p><b>リセットしてください</b></p> <p>1. 携帯電話のBluetoothをオフにする。2つのイヤホンが赤と白のランプが点滅し、4回タッチすると、リセットが成功します。イヤホンはシャットダウンします。</p> <p>2. 携帯電話のBluetoothは古いペアリング名を削除して、イヤホンが起動したら接続すればいいです。</p>	<p><b>充電ケースインジケータ</b></p> <p>充電ステータス 充電ケース充電中: オレンジランプが点滅 充電ケース充電完了: オレンジランプが点滅 充電ケース充電完了: 白ランプが点滅 充電ケースオン/オフ: (低電圧警告ランプが点滅)</p>	<p><b>音声プロンプト</b></p> <p>電源オン: Power on 電源オフ: Power off 着信音: Incoming Call 接続を切断: Disconnected ペアリングモード: Pairing 音量が最大: Volume maximum 音量が最小: "Too" 前の曲/次の曲: "Volume" リモート切断: Disconnected 接続成功: Connected 低電力アラーム: Low battery please charge 充電/接続: "Too" TWSペアリング成功: Connected</p>	<p>もしイヤホンが音が出ない、音が出ないなどの場合は、イヤホンを取り出し、イヤホンをきれいにしてください。</p> <p>4. イヤホンは充電不良の場合、接続で充電電圧の位置を確認してください。イヤホンを充電してください。</p>	<p><b>注意事項</b></p> <ol style="list-style-type: none"> <li>腐食性の液体で洗わないでください。</li> <li>化学薬品に触れたら、手で洗ってください。</li> <li>本製品は10~60℃の環境で使用してください。</li> <li>爆発を防ぐため、本品を火から離れてください。</li> <li>爆発を防ぐため、本品を火から離れてください。</li> <li>イヤホンの電子部品の損傷を防ぐため、小物やイヤホンの中に落とさないでください。</li> <li>お客様からのご意見、ご感想などは絶対にやめてください。</li> <li>長時間使用する予定がない場合(1ヶ月以上)、本製品の性能を保護するために待機充電をしてください。</li> <li>2A以上の過大な電流は「バッテリー」に損害を与える恐れがあります。2A以上の充電アダプターのご使用は絶対にやめてください。</li> </ol> <p><b>バッテリーについて!</b> 本製品はリチウム電池を内蔵しています。爆発を防ぐため、必ずお湯や火気から離れてください。</p>

材質: 128g銅版紙  
 尺寸: 78\*64mm  
 装订: 风琴折再对折, 正反面  
 只做英日文

**FCC Caution:**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.