
成品尺寸: 75×110mm

材质: 105G双铜, 正反面单色印刷, 折页

BLUETOOTH SPEAKER AND ACCESSORIES

FUNCTIONS



Long press 2s: Power on/off Short press one time: Play/Pause; Pick up/Hang up Short press twice: Switch LED lighting mode Short press 3 times: Protect call privacy; Reject incoming call; TWS connect/disconnect

Short press one time: Volume"+" Long press 2s: Next song

Long press 2s: Previous song ②③ + — Short press : Bluetooth disconnection Long press 2s at the same time: Turn on/off SOS light

Short press one time: Volume"-"

Status indicator


DRIVEN

1. Power On/Off

Long press " の "button 2s to power on/off.

Long press " O "button 2s to power on with prompt tone, speaker will enter into bluetooth pairing mode, the blue indicator will flash. Choose "DRBTM4" in your bluetooth list, there will be a prompt tone once connected successfully, and the blue indicator will be normally on. Now, you can play music

OPERATIONS



OPERATIONS OPERATIONS

5. LED Lighting Mode

6. Calling

Short press" ()

After power on, short press " O "button twice to switch LED lighting mode (Mode 1 - Mode 2 - Mode 3 - Mode 4 - Mode 5 - turn off).

Long press" + "2 buttons 3s at the same time to turn on/off

When a phone call is incoming, short press " U "button to answer


During a phone call conversation, short press" O "button to hang up. Short press" O "button 3 times to protect call privacy (move call

(1) Power buttor

3. TWS Connection

After the power is on but before it is connected with any device,

button 3 times of any speaker to turn on TWS function, you will hear the prompt tone and the blue indicator will flash. There will be "du" once paired successfully, then the blue indicator of slave speaker will be normally on and the blue indicator of master speaker will flash, now you can connect speaker with device.



Short press " + "button one time for volume up, there will be prompt next song.

Short press " — "button one time for volume down. Long press " — "



7. Power Saving


OPERATIONS

Speaker will power off automatically to save battery when nothing is connected after 10 minutes.

8. Charging

Use supplied USB-C charging cable
Use an output source 5V/2A (or above)

Charge when you hear low battery prompt tone or the indicator flash red. The red indicator will be normally on while charging and switch off after fully charged.





FUNCTION INSTRUCTIONS

LED lighting	Total 5 LED lighting modes
Status indicator	Power on/ TWS (blue indicator)
	Low battery (red indicator flash)
	Charging (red indicator normally on)
	Fu ll y charged (red indicator off)

SPECIFICATIONS

Product Name

Speaker Unit

Product Size

Product Weight

Bluetooth Version 3.7V/2600mAh Battery Capacity 5-6 hours(70% volume, LED Playing Time lighting off) Talking Time 8-10 hours 3-5 hours Charging Time 5V <u>---</u>1A Charging Current

7.83" x 3.15" x 1.85"

501g±50

DRBTM4

FREQUENTLY ASKED QUESTIONS

Q1: What kind of charger should we use for the speaker? A: All common USB chargers can be used, while we suggest the ones 5V/2A or above 2A.

Q2: What if there is noise or discontinuous sound during playing? A: The speaker can be normally used within 3 FT under no obstruc-If it is beyond 10m or with obstruction, there might be noise or discon-

Q3: Why does the speaker power off automatically after power on vithout any operation? A: When there is no bluetooth pairing in 10 minutes, the speaker will

shut down automatically to reduce power consumption.

Q4: Why does the speaker not connect once-paired with the cellphone? A: First, remove the speaker's paired name from the cellphone's Bluetooth list and then restart pairing.

Q5: When the speaker can not be turned on or used normally. A: Please charge it for some time, then long press power on button

FREQUENTLY ASKED QUESTIONS

1. Please read this manual carefully before use and keep it safe. 2. For the first use, please fully charge the product.

3. Pls use certificated adapter that has passed national safety certifica-

4. If you do not use the product for a long time, be sure to charge it once within a month at least to maintain its performance.

5. Do not use this product in an extremely cold or hot environment, such as temperature beyond the range of 41 F - 95 F. If it is used beyond the above range, the product may stop automatically to protect the internal

6. When charging it in a high temperature environment, the product may automatically stop charging to protect the battery. At this time, the charging indicator usually ashes quickly to indicate that the charging environmental temperature or the product internal temperature is too 7. Storage environment temperature: 23°F - 95°F RH < 70% (recommended 77°F ±5).

Important safety instructions:

1. Do not disassemble or repair this speaker personally, otherwise it may

cause product damage or personal injury. 2. Do not use it in dusty, humid, dry, and high-temperature environment. 3. Do not place this product near a heat source, or a place with direct sunlight, a lot of dust, or mechanical vibration.

4. In order to reduce the risk of fire, please do not cover this product

with newspapers, tablecloths, curtains etc., during use.

5. If the product has a waterproof feature, please do not exceed the

nominal parameter range when using it.

6. When the product is damaged (such as the power cord or plug is damaged, liquid enters or objects fall into the device, unable to operate normally or falls), it must be repaired. 7. When the product is fully charged, do not connect it to the charger for

further long time charging.

8.The maximum ambient temperature should not exceed 104 F

*This speaker supports mobile phones/ tablets/ PCs etc. Here this User Manual is illustrated base on mobile phone

DRIVEN

FEDERAL COMMUNICATIONS COMMISSION (FCC) STATMENT

DRIVEN.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If his equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more

■Reorient or relocate the receiving antenna.

of the following measures:

•Increase the separation between the equipment and receiver.

•Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

•Consult the dealer or an experienced radio/TV technician for help. Warning: Changes or modifications made to this device not expressly approved by DB Research L.L.P may void the FCC authorization to operate this device

FEDERAL COMMUNICATIONS COMMISSION (FCC) STATMENT

Note: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

RF exposure statement:

This device complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. The device is installed and operated without restriction.

LIMITED WARRANTY

Driven warrants any products purchased in the U.S.A. from an authorized Driven dealer.

All Products are warranted to be free from defects in material and workmanship under normal use and service for a period of one (1) year. This warranty applies to the original

Driven will either repair or replace (at its own discretion) any unit that has been found to be defective and under warranty provided the defect occurs within the one (1) year warranty period.

This limited warranty does not extend to units that have been subjected to misuse, abuse, neglect, or accident. In Driven's judgment, products that show evidence of having under this warranty.

To Obtain warranty service please contact your retailer or visit our website at

