

Reelables User Manual for A-Label/0001



Use with barcode printers:

Step 1. Download Reelables Desktop app and ensure software connects to thermal barcode printer with barcode scanner.

Step 2. Load Reelables A-Labels into thermal barcode printer.

Step 3. Scan a barcode, QR code or other serialisation already printed on an inventory item. A Reelables A-Label is instantly printed with the same serialisation.

Step 4. Peel label backing and stick Reelables A-Label to box.

Use with Android or iPhone:

Step 1. Download Reelables App for Android or iPhone.

Step 2. Scan NFC with iPhone or Android.

Step 3. Peel label backing and stick Reelables A-Label to box.



Per FCC 15.19(a)(3) and (a)(4) This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Per FCC 15.21, The user manual or instruction manual for an intentional or unintentional radiator shall caution the user that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment."



Per FCC KDB 784748, Section A.8.: To satisfy RF exposure requirements, this device and its antenna must operate with a separation distance of at least 20cm from all persons.