



ITEM: **WTC926** UPC: **850013016273**

**Battery Charging:** We recommend charging the enema for a full 2 hours before use. The charging port is located on the side of the device and marked (DC). Gently press the tip of the charging cable into the charging port. The device will blink blue while charging.

**Cleaning:** The Cloud Enema should be cleaned before and after each use. We recommend using Cloud 9 toy cleaner or a warm soap and water solution.

**Warning:** To avoid injury or aggravation of pre-existing conditions, this device should not be used on swollen or inflamed areas, or on skin lacerations. No medical claims are warranted or implied by the use of this product. This device is splash proof  
- Do not completely submerge this device.  
30 day limited warranty.



ITEM: **WTC926** UPC: **850013016273**

**On/Off:** To turn on the enema press and hold the power button for 2 seconds. The power button will illuminate with a blue light and the device will be in standby mode. Repeat procedure to turn off.

**Cleaning Modes:** Click once to enter first cleaning mode; click again to switch the cleaning frequency. By clicking the cleaning mode you can cycle thru (3) cleaning modes from slow to fast cleaning.

**Vibration Cleaning Mode:** Double-click to switch to vibration cleaning. This feature provides vibration at the tip simultaneously with cleaning. Double click again to de-activate the vibration mode. The Vibration mode can be used without the cleaning mode.

**Remote Control Mode:** To turn on the enema press and hold the power button on the unit for 2 seconds. The power button will illuminate with a blue light and the device will be in standby mode. After the blue light is on, press the downward facing arrow button to cycle through the cleaning modes and the upward facing arrow button to activate the vibration mode.

**Off Mode:** To completely turn off the product, please press and hold the power button on the body of the product itself.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.