

PowerMag

S2105

Magnetic wireless charge

Switch

Power Light

Type-c(In/Out)

SIXTHGU

Note:Only works with iPhone compatible magnetic cases.

SIXTHGU

For FAQs and more information
Please visit:

sixthgu.com/pages/support

Sixthgu.official

Instagram

Sixthgu

TikTok

Support@sixthgu.com

Email

SIXTHGU

Focus efficient, safe charging.

NOTICE!

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

SPECIFICATIONS

Name Nombre	S05 Magnetic Battery (PowerMag)
Model: Modelo	S2105
Capaity Capacidad	5,000mAh/19.25Wh
In/Output:Type-C Entrada	5V≡3A 9V≡2.22A
Wireless Output Salida	5W/7.5W/10W/15W
Size Tamaño	102*70*10.3mm 4x2.7x0.4 inch
Weight Peso	128g/ 4.5oz

! Simultaneous charging and self-charging are not supported.

DE:

Gleichzeitiges Laden und Selbstladen werden nicht unterstützt.

ES:

No se admiten la carga simultánea y la autocarga.

FR:

La charge simultanée et la charge automatique ne sont pas prises en charge.

IT:

Non supporta la ricarica e l'auto-ricarica simultanea.

PT:

Carregamento simultâneo e carregamento automático não são suportados.

RU:

Одновременная зарядка и самозарядка не поддерживаются.

CN:

不支持同时充电和自充电。

TC:

不支持同時充電和自充電。

JP:

同時充電と自己充電はサポートされていません。

KO:

동시 충전 및 자체 충전은 지원되지 않습니다.

💡 When the power bank is full charged,all LED lights always on and stop flashing.

DE:

Wenn die Powerbank voll aufgeladen ist, leuchten alle LED-Leuchten immer und hören auf zu blinken.

FR:

Lorsque la banque d'alimentation est complètement chargée, toutes les LED s'allument toujours et arrêtent de clignoter.

IT:

Quando il power bank è completamente carico, tutti i LED si accendono sempre e smettono di lampeggiare.

ES:

Cuando el banco de energía está completamente cargado, todas las luces LED siempre se encienden y dejan de parpadear.

RU:

Когда блок питания полностью заряжен, все светодиоды горят постоянно и перестают мигать.

PT:

Quando o banco de energia está totalmente carregado, todos os LEDs ficam acesos e param de piscar.

CN:

移动电源充满电后，所有LED灯常亮停止闪烁。

TC:

當移動電源充滿電時，所有LED燈常亮並停止閃爍。

JP:

パワーバンクが完全に充電されると、すべてのLEDライトが常に点灯し、点滅を停止します。

KO:

보조 배터리가 완전히 충전되면 모든 LED가 항상 켜지고 깜박임을 멈춥니다..

SAFETY INSTRUCTIONS

1) It is prohibited to disassemble, open, shred or pierce the power bank with metal.

2) It is forbidden to expose the mobile power source to heat or flame, and it is forbidden to put the mobile power source into the fire.

Avoid storing in direct sunlight.

3) It is forbidden to short-circuit mobile power sources, and do not put multiple mobile power sources in a box or drawer at will.

Avoid short-circuiting between them or being short-circuited by other metal objects

4) It is forbidden to subject the mobile power supply to mechanical shock.

5) Once a leak occurs, do not directly contact the skin or eyes with the leaked liquid. If contact occurs,Use plenty of water to rinse the contact area.

6) The charging should be carried out in accordance with the manufacturer's instructions.

7) Pay attention to the logo on the power bank to ensure correct use.

8) Keep the power bank clean and dry.

9) Do not charge the power bank for a long time.

10) Keep the original product manual for future reference.

11) Dispose of waste mobile power supplies in accordance with national environmental protection regulations.

*This product uses lithium-ion batteries. It is strictly forbidden to open the product shell privately, and it is strictly forbidden to disassemble or squeeze it. The puncture prevents children from using the device without supervision to avoid swallowing small accessories.

*Do not put the equipment in fire or water to avoid explosion or damage to equipment components.

*Not applicable to children under five years old.

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.