acer

ACER *TAB V9-22*

USER'S MANUAL

Contents

1 .Brief introduction for Tablet PC

1.1Diagram for tablet complete machine

1 .2 Functional diagram

1.power key   2.Volume-

3.volume+   4.Front camera

5.SIM/TF Card slot   6&9. Speakers

7.Earphone port   8.Type-C port

10.Back camera   11.Flashlight

1 .3 Except Tablet PC, the following accessories are

included:

Power adaptor × 1

Type-C cable × 1

Earphone × 1

User's manual × 1

Ejection Pin × 1

2. Quick start

2.1Key function
Descriptions for key function:

Power key	Long press power key to start up. Under starting up state, long press power key to pop up shutdown option. Under starting up state, short press power key to close the screen.
Volume key	Press it can increase or decrease machine volume

2. 2 Homepage interface
The main interface can display wallpaper and frequently used APP,you can move the APP to the main interface according to you preference.

And you can also change wallpaper by yourself, enter setting→Wallpaper →Choose wallpaper from (live wallpapers/photos/wallpapers)to set wallpaper of your homepage interface.

Figure 2-1

2. 3 Access to application program
How to visit application program of tablet:
1. Swipe up on the main screen to enter
the application program (As shown in
Figure 2-2).

2. Select the application program you want to visit.

3. If you want to exit the program interface, press the return key to the

last interface, or press the homepage key to return homepage

interface directly.

Figure 2-2

2. 4 Character input

Use screen keyboard

When you start the program or select text edit box needing to

input characters or numbers, screen keyboard will show. The

following input methods are provided for the keyboard to select.

1. Keyboard

2. Input method of a third party (user can install them by himself)