



17ORA
AUT205



Manual

PLEASE READ ALL INSTRUCTIONS CAREFULLY AND RETAIN FOR FUTURE USE

Packing list



Reminder

- 1) Please do not disassemble and replace any components of earbuds.
- 2) Don't put the earbuds in the water or any other liquid. The earbuds are not waterproof.
- 3) If any liquid enters the product by accident, please disconnect immediately.
- 4) Please make sure that there is no water on your hands when disassembling the product to avoid electric shock.
- 5) Do not put the product near the heat source or expose it to the fire source directly.
- 6) Do not put the product in the environment with strong electromagnetic force, otherwise it will cause product malfunction.

Earbuds specification


Model : AUT205
Transmission distance: $2.10M$
Battery capacity: 40mAh
Playing time: about 7 hours (earbuds)
Charging time: about 1.5 hours (earbuds)
Rated input 5V=40mA
FCC ID : 3ARW-AUT205

Charging case specification

Battery capacity: 230mAh
Charging time: about 1.5 hours
Rated input 5V=260mA
(All technical information is subject to actual performance)

Charging the box

Charging status: flashing red light
Charge complete: steady red light
Low battery: green light flashes for 4 times, please charge



LED light guide


Earbuds	Put the earbuds in the charging case and the earbuds will charge automatically.	Battery status: Flashing red and white. Charging status: Steady red. Connection status: Light red. Charging case status: Light red and blue. Charging case status: Light red and blue.
Charging case	To charge the case, use a USB-C cable and USB adapter.	Charging status: Flashing red and white. Charging case status: Steady red. Charging case status: Steady red.

Product operation instructions

- Turn on
Method 1: Take out earbuds from the charging case and turn on automatically.
Method 2: Long press the touch key for 3 seconds to turn on earbuds.
- Turn off
Method 1: Put the earbuds back into the charging case until the earbuds turn off.
Method 2: Press and hold 5 seconds on the touch key to turn off.
- Call mode
Left/Right earbuds operation
• Pairing
Take out earbuds from the charging case, the earbuds will automatically enter the BT pairing mode. Side of the name of earbuds on your device's BT list to connect.



- The operation of the touch key Music play mode
- Left/Right earbuds operation



Call mode

- Left/Right earbuds operation
- Pause/Play: Tap on left earbuds
- Next track: Click the right earphone(R) to touch the function key
- Voice assistant (Sir) : Press and hold on 2 seconds

Warranty statement

For these occasions, we do not provide after-sale warranty services.
1. The validity period of 3 months of "Repair, replacement and return" exceeded.
2. Alteration of the warranty card and product code does not match the product body.
3. Causes caused by misuse, abuse or improper transportation, use, maintenance or storage (paired or damaged).
4. Failure or damage caused by force majeure (such as earthquake, war, fire, etc.) or accident loss.
5. The zipper and buckle are damaged due to excessive force.
6. Disconnection or bearing caused by excessive load.
7. Any damage caused by sharp objects.
8. Products with signs of burning or water immersion.
9. Damage caused by unauthorized disassembly.
10. Aging, discoloration, abrasion, rupture and other losses occurred during normal use of the product.
11. If the original identification label of the product is changed or damaged, the guarantee will be void. The completeness and appearance of the product and accompanying materials are not within the scope of the guarantee. You should check on the spot and raise objections to any discrepancies.

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
• Reorient or relocate the receiving antenna.
• Increase the separation between the equipment and receiver.
• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
• Consult the dealer or an experienced radio/TV technician for help.
The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure condition without restriction.