


3 IN 1 WIRELESS CHARGER User Manual

OJD-136



CEFCRoHS

Made in China

Product Introduction

Thank you for choosing to purchase this product! This product is a multi-functional wireless charger, the product integrates the magnetic wireless charge, Bluetooth speaker, night light function. It can provide you with convenient and fast exquisite life experience.

Wireless charging area for cell phones

RGB light

Touch switch

-Button
Pause/disconnect
button

+Button

Loudspeaker

Type-C input port

Product Parameters

Product name: Multi-function wireless charger

Product model: OJD-136

Product input: 9V \rightarrow 3A

Product size: 97*94*117mm

Phone output: 5W/7.5W/10W/15W

Product weight: 323g

Bluetooth+night light output: 4W (MAX)

Product color: White/Black


Bluetooth: 5.1

Transmission distance: \leq 10m

Usage Method

1. Please insert the Type-C data cable provided with the product and turn on the power.


2. Put the phone that supports magnetic wireless charging into the center of the charging area to which it belongs, and charging can begin.



3. Lighting touch switch on the right side of the product, you can click to open, the order is: RGB running lights \rightarrow music rhythm \rightarrow night lights \rightarrow close.

4. In night light mode, long pressing the touch button for the first time can increase the brightness of the night light, and long pressing the touch button again can decrease the brightness of the night light.

5. The steps to use the Bluetooth speaker are as follows:
(1)Open the cell phone settings, turn on the Bluetooth, find "OJD-136", click to connect, after hearing the Bluetooth announcement, it means the Bluetooth connection is successful.
(2)The "+" button supports increasing volume and switching to the next track. Click to increase volume; Long press for 3 seconds to switch to the next track.
(3)The "-" button supports reducing volume and switching to the previous track. Click to reduce volume; Long press for 3 seconds to switch to the previous track.

(4)“” The button supports playing/pausing songs and disconnecting Bluetooth. Click pause, then click again to resume playback. Long press for 3 seconds to forcibly disconnect the Bluetooth connection and clear the current connection information. Repairing is required for the next use.

LED Light

	State	Lighting Effect
RGB Light	Connecting the power supply	Green light on for 3 seconds, off
	Click 1st	RGB running horse lights
	Click 2st	Music Rhythm Mode
	Click 3st	Night light mode (first long press to increase brightness, second long press to decrease brightness)
	Click 4st	Closure

Matters Needing Attention

1. When you use this product for the first time, please read the user's manual in detail and use it according to the user's manual for correct operation.

2.Please use an adapter that meets local safety standards to avoid unstable charging.

3. Please do not place metal sundries or magnetic cards on the product to prevent product damage or abnormal charging.

4. Please do not use the product in high temperature, humid or corrosive environment to avoid damage to the circuit.

5. Please do not disassemble this product by yourself, when you need maintenance or repair, please hand it over to after-sales or professional maintenance personnel.

FAQ

Q1. The phone does not charge.
A: The phone is not aimed at the charging sensing area or the receiving coil is not installed correctly.

Q2. Charging fever.
A: It is normal for the receiving coil or transmitter to generate heat during wireless charging.

Q3. Mobile phone charging intermittently.
A: The charging current of the power adapter is insufficient or the voltage is unstable, please use a qualified adapter.
A: The charging position is too biased, the electromagnetic induction is not in place, and the charging position needs to be adjusted.

Q4. Slow charging.
A: The wireless charging current allowed by the mobile phone itself or the external receiving coil is different, or the standby power consumption of the mobile phone is large when charging, it is recommended to reduce the standby program of the mobile phone.

Q5. Bluetooth cannot be connected successfully.
A: Please re-plug the power supply, if you still can't connect, you can long press "square icon" for 3 seconds, the product will force to disconnect the connected Bluetooth device, you can try to re-pair the connection.

Q6. Other questions.
A: Please contact after-sales customer service directly.

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.


Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
—Reorient or relocate the receiving antenna.
—Increase the separation between the equipment and receiver.
—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
—Consult the dealer or an experienced radio/TV technician for help.

Note: The Grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. such modifications could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement.
To maintain compliance with FCC's RF exposure guidelines, the distance must be at least 20 cm between the radiator and your body, and fully supported by the operating and installation configurations of the transmitter and its antenna(s).

多功能无线充电器用户手册

OJD-136



CEFCRoHS

Made in China

产品介绍

感谢您选择购买本产品!本产品是一款多功能无线充电器,产品集成了手机无线充、蓝牙音箱、小夜灯功能。可为您提供方便、快捷的精致生活体验。

手机无线充区域

RGB灯

触摸开关

-按键
暂停/断开按键

+按键

蓝牙音响

Type-C输入接口

产品参数

产品名称: 多功能无线充电器

产品型号: OJD-136

产品输入: 9V \rightarrow 3A

产品尺寸: 97*94*117mm

手机输出: 5W/7.5W/10W/15W

产品重量: 323g

蓝牙+夜灯输出: 4W (MAX)

产品颜色: 白色/黑色


蓝牙: 5.1

传输距离: \leq 10M

使用方法

1. 请您插入产品配备的Type-C数据线,接通电源。


2. 将支持磁吸无线充电的手机放到所属充电区域的中心位置,即可开始充电。



3.灯光的触摸开关在产品右侧,可以通过单击开启,顺序是:RGB跑马灯 \rightarrow 音乐律动 \rightarrow 夜灯 \rightarrow 关闭。

4. 夜灯模式下,首次长按触摸按钮,可以提高夜灯亮度,再次长按触摸按钮,可以降低夜灯亮度。

5. 蓝牙音箱使用步骤如下:
(1)打开手机设置开启蓝牙,找到"OJD-136",点击连接,听到蓝牙播报后即代表蓝牙连接成功;
(2)"+"按键支持音量增加和切换下一曲,单击增大音量;长按3秒为切换下一曲;
(3)"-"按键支持音量减少和切换上一曲,单击减少音量;长按3秒为切换上一曲;

(4)"”按键支持 播放/暂停 歌曲和断开蓝牙,单击暂停,再次单击可恢复播放,长按3秒为强制断开蓝牙连接并清除当前连接信息,下次使用需要重新配对。

LED灯光

	状态	灯光效果
RGB 灯	连接电源	绿灯亮3秒,熄灭
	单击第1次	RGB跑马灯
	单击第2次	音乐律动模式
	单击第3次	夜灯模式,首次长按增强亮度,第二次长按降低亮度
	单击第4次	关闭

注意事项

1.首次使用本产品,请您详细阅读用户手册,并按照用户手册的使用方法正确操作使用。

2.产品请使用符合当地安规标准的适配器,避免充电不稳定。

3.请勿在本产品上放置金属杂物或磁卡,以防产品损害或充电异常。

4.请勿在高温、潮湿或腐蚀环境下使用本产品,避免损坏电路。

5.请勿自行拆卸本产品,需要维修或修理时,请将其交给售后或专业的维修人员。

常见问题解答

问题1. 手机放上不充电。
解答:手机未对准充电感应区域或接收线圈未正确安装。

问题2. 充电发热。
解答:无线充电过程接收线圈或发射出现发热为正常现象。

问题3. 手机充电断续。
解答:电源适配器充电电流不够或电压不稳定,请使用合格适配器。
解答:充电位置太偏,电磁感应不到位,可调整充电位置。

问题4. 充电比较慢。
解答:手机本身或者外围接收线圈允许无线充电电流的大小不一样,或者手机充电时待机耗电大,建议减少手机待机程序。

问题5. 蓝牙无法连接成功。
解答:请您重插电源,如果还是不能连接,可以长按"square icon"3秒,产品会强制断开已连接的蓝牙设备,您可以尝试重新配对连接;

其他问题
解答:请直接联系售后客服咨询。