


## VEIU Mini3S Smart Video Doorbell User Manual


The sample figure is for reference only  
Please read this manual carefully before using the product and keep it properly

# 01 Package Contents

---




Indoor LCD Screen ×1




Bracket ×1  
Cable Cover ×1



Outdoor Camera ×1



User Manual ×1



USB Cable ×1




M3X30 Bolts ×2    M3X55 Bolts ×2    M3X80 Bolts ×2


## 02 Component Diagram

---

### Indoor LCD Screen



## Outdoor Camera




## 03 Screw Selection

**Tips:** When choosing bolts to install the outdoor camera, you should confirm the thickness of the door first, Select the corresponding screw according to the door thickness.

Applicable door thickness:  
1.4in - 4.3in (35mm ~ 110 mm)

Applicable peephole:  
0.7in - 2.0in (18mm ~ 50mm)




Door thickness

Screw specification

1.4in-2.2in(35mm-55mm)

M3X30 

2.6in-3.7in(65mm-95mm)

M3X55 

3.7in-4.3in(95mm-110mm)

M3X80 

## 04 Installation

---

### Tips:


- Charge the battery fully before using it;
- When fastening the outdoor camera, attach bolts into its poles first;
- When fastening the LCD Screen, align it to the notch of the bracket, its magnet will attach to the bracket automatically.

### **Install Device with 1 screwdriver within 5 minutes**

- 1 Select the bolts depending on the door thickness, then screw them to the outdoor camera, peel off the protective film off the adhesive strips.
- 2 Pass the ribbon cable through the door hole, tighten the outdoor camera.
- 3 Take out the screen, push out the small bracket on the back of it with your finger, and then take off the guard board in the bottom of the bracket.
- 4 Slightly press the cable to the pin on the bottom of the large bracket, and then attach the guard board.

- 5 Pass the bolts through the bracket, then tighten the screws, put on the small bracket with your finger.
- 6 Suspend the LCD monitor on the bracket from top to bottom, its magnet will be attached automatically, press the power key for 5 seconds to turn on/off your doorbell.

### Installation Diagram





## CONTACT US

**CUSTOMER SERVICE EMAIL:**

[cs@eques.com.cn](mailto:cs@eques.com.cn)

**ADDRESS:**

Room 210, Building A, 4200 Humin Road,  
Minhang District, Shanghai, China

**WEBSITE:**

[www.eques.cn](http://www.eques.cn)





## WARRANTY CARD

Customer	Product
Name: _____	Color: _____
Tel No: _____	SN No: _____
Address: _____ _____	Error Description: _____ _____

CERTIFICATE

Model: \_\_\_\_\_

Inspector: \_\_\_\_\_

Date: \_\_\_\_\_



Warranty cards on this page can be cut along the dotted line

## 05 Product Guide

---

### 1 Main key

- 1.Long press the power key for 5 seconds to turn on/off your doorbell;
- 2.Short press the screen to turn on the screen while the power is on.

### 2 Install SD card

- 1.Insert the contact-side of the MicroSD card into the slot;
- 2.Use a MicroSD card with a capacity of 32GB or less from a licensed manufacturer;
- 3.The video stored on the memory card can only be viewed through the computer

### 3 Charge

- 1.For daily charging, please use the original USB data cable, take the host from the bottom to the top for charging, and then install it from top to bottom after completion.
- 2.If the device is placed for a long time, it is recommended to charge it once every 3 months.

## 06 App Guide

---

Scan QR code to download the app, or seach "Eques" on App store/Google play.



IOS




Android

\*The creenshots is for reference use only, differ in updates or mobile OS



**Add Your Device**

1. After installing the app, fill the information as pictured then click "sign up". After completed, use this account to login. Make sure you remember your login info.
2. Click "+" to add a new device, choose the device VEIU Mini3S




3.Input WiFi name and password as per UI prompt then click”next”

4.Turn on power key and go to setting,use the outdoor camera to scan the QR code.



## Live monitoring

Open camera anytime anywhere




## Remote Intercom

Answer by video or audio intercom when someone rings the doorbell




## Motion Detection

Auto photo snapshot and push notification



## Stay alert

Set the duration of stay alarm



## 07 Safety Guideline

---

- Try to avoid placing the device in high-temperature, high humidity, dusty or other harsh environments as this may reduce its lifespan.
- Don't forcibly squeeze the camera lens and the black ball on the top of the outdoor subcomponent; otherwise it can cause hardware damage.
- Treat the ribbon cable with care during installation, don't forcibly drag, scrape or cut the ribbon cable. (The device will be out of warranty if it is damaged by inappropriate installation.)
- Make sure you use the charger that is applicable. Unqualified chargers might cause damage to the device.



Our product is used for home anti-theft monitoring, Any illegal places are prohibited.



This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

#### Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.