





MUSIC DOME

BLUETOOTH SPEAKER



LED
Charging port



Power
on(Bluetooth) /off

Included:

1. Mini Speaker
2. Charging Cable
3. User Manual

Charing your MUSIC DOME:

Your Music Dome is powered by a rechargeable battery.

Please fully charge the battery before use it. And please turn off the unit before charging.

1. Use the USB cable provided to connect to any computer or power adapter.
2. When this is on charging, the red indicator lights up.
3. When the unit is fully charged, the red indicator will turn off. charging time is approximately 2 hours.
4. Making better battery life, turn off the MUSIC DOME when not in use.
5. Your MUSIC DOME will make a beep sound at every 30 seconds when the battery is low. Then, please recharge the battery.

Pairing device with your MUSIC DOME:

Before using the MUSIC DOME, please pair it with your smartphone, music player, computer or any Bluetooth-enabled device.

Set your Bluetooth device to search and select the BUYMORE.

1. Turn the MUSIC DOME on. It will then be automatically started to pair with the Bluetooth-enabled device. The blue indicator light will flash frequently, it means on pairing mode.
2. When the Bluetooth -enabled device searched the BUYMORE, press "OK" to pair with the MUSIC DOME. The blue indicator will switch to flash slowly, it means pairing is done.

Troubleshooting:

If the Bluetooth -enabled device fails to locate the MUSIC DOME, Check whether the unit is ON. Ensure that your device is within 10 meter range.

Restart your MUSIC DOME, to reactivate the pairing mode. Ensure that the unit is not connected or paired with any other Bluetooth devices; as the MUSIC DOME can only be paired with one device at a time.

Playing music:

After pairing is done, you can enjoy the music from your Bluetooth-enabled device. Music, songs and sound volume can be controlled by your device. Your MUSIC DOME will play up to 7 hours, depending on volume level.

FCC STATEMENT

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesirable operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with these instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorientate or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.