


<h1>Yeelight YeeTag</h1> <h2>USER MANUAL</h2> <p>Require system iOS 14.5 and iPhone 6s above</p>  <p>Works with Apple Find My</p>	<h3>Main Functions</h3> <p>2.2 Connect Your Yeelight YeeTag Locate your item The Apple Find My network provides an easy, secure way to locate compatible personal items using the Find My app on your iPhone, iPad, Mac, or the Find Items app on Apple Watch. Simply pair your compatible product with the Apple Find My app to view it right alongside your Apple devices. If your item ever goes missing, you can put it in Lost Mode to display a message and contact information to anyone who might find it. The Find My network is encrypted and anonymous, so no one else, not even Apple or the maker of your personal item, can view its location.</p> <p>3.1 Find Yeelight YeeTag When It's Nearby Open Find My app and select the "Items" tab or open the Find Items app on your Apple Watch. Tap your item from the list. Tap "Play Sound" to make your Yeelight YeeTag beep. Tap "Stop Sound" to stop the beeps once you find it.</p> <p>3.2 Find Yeelight YeeTag Location Open Find My app and select the "Items" tab or open the Find Items app on your Apple Watch. Tap your Yeelight YeeTag from the list. Your Yeelight YeeTag location will appear on the Map with a time stamp of when the item was located. To navigate to the Yeelight YeeTag's location, tap "Directions" to open Apple Maps.</p> <p>4.1 Notifications Enable "Notify When Left Behind". Open Find My app and select the "Items" tab or open the Find Items app on your Apple Watch. Tap on your item from the list. Under "Notifications", enable the "Notify When Left Behind" toggle. You will receive a notification when you leave your Yeelight YeeTag behind and it's no longer in range of your device.</p> <p>4.2 Enable "Notify When Found" Under "Notifications", enable the "Notify When Found" toggle. When your Yeelight YeeTag is seen by another Find My network device, you will receive a notification of its location. Note: "Notify When Found" can only be activated when your Yeelight YeeTag is out of range.</p> <p>5.1 When Your Yeelight YeeTag Is Lost / Enabling "Lost Mode" Open Find My app and select the "Items" tab or open the Find Items app on your Apple Watch. Tap on your item from the list. Under "Lost Mode" tap "Enable". A screen detailing Lost Mode will pop up, tap "Continue". Enter your phone number or email address and tap "Next". You may enter a message that will be shared with the person that finds your item.</p> <p>7.1 Unwanted tracking If any Find My network accessory separated from its owner is seen moving with you over time, you'll be notified. Find My will send a notification to your Apple devices. This feature is available on iOS or iPadOS 14.5 or later. These features were created specifically to discourage people from trying to track you without your knowledge.</p>	<h3>FAQ:</h3> <p>1. How the items are located? When an item is separated from its owner for a period of time, it can be found by other Apple devices in Find My network and the owner can start to get the location of the device.</p> <p>2. How to confirm whether the device is powered on? After you get the device, press the button in the center of the device, and the device will beep, indicating that the device has been started.</p> <p>3. How is the device designed to discourage unwanted tracking? If any Find My network accessory separated from its owner keeps going with you over time, you'll be notified in one of two ways:</p> <ol style="list-style-type: none"> If you have an iPhone, iPad, or iPod touch, Find My will send a notification to your Apple device. This feature is available on iOS or iPadOS 14.5 or later. If you don't have an iOS device or a smartphone, a Find My network accessory that isn't with its owner for a period of time will emit a sound when it's moved. These features were created specifically to discourage people from trying to track you without your knowledge. <p>4. Why I can't find device with Bluetooth connection? Try to reset the device by clicking the button 5 times and keep holding it until there is a beep OR you can try to replace the battery OR you have to disconnect the pairing between this device and other Apple ID first, then retry the connection.</p>										
<h3>Safety and handling</h3> <p>Important safety information to handle Yeelight YeeTag with care. It contains sensitive electronic components, including batteries, and can be damaged, impair functionality, or cause injury if dropped, burned, punctured, crushed, disassembled, or exposed to excessive heat or liquid or to environments with high concentrations of industrial chemicals. Don't use a damaged Yeelight YeeTag.</p> <h3>Environmentally friendly disposal</h3> <p>Old electrical appliances must not be disposed together with the residual waste, but have to be disposed of separately. The disposal at the communal collecting point via private persons is for free. The owner of old appliances is responsible to bring the appliances to these collecting points or to similar collection points. With this little personal effort, you contribute to recycle valuable raw materials and the treatment of toxic substances.</p> <p>The Apple Find My network provides an easy, secure way to locate compatible personal items using the Find My app on your iPhone, iPad, Mac, or the Find Items app on Apple Watch.</p> <p>To use the Apple Find My app to locate this item, the latest version of iOS, iPadOS, or macOS is recommended. The Find Items app on Apple Watch</p> 	<p>requires the latest version of watchOS.</p> <p>Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards.</p> <p>Apple, Apple Find My, Apple Watch, Find My, iPhone, iPad, iPadOS, Mac, macOS and watchOS are trademarks of Apple Inc., registered in the U.S. and other countries. iOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.</p> <p>Contact us! If you have any questions or problems with your product, please don't hesitate to reach us at:</p> <p>WARNING</p> <table border="1"> <tr> <td>• INGESTION HAZARD: This product contains a button cell or coin battery</td> <td></td> </tr> <tr> <td>• DEATH or serious injury can occur if ingested.</td> <td></td> </tr> <tr> <td>• A swallowed button cell or coin battery can cause Internal Chemical Burns in as little as 2 hours.</td> <td></td> </tr> <tr> <td>• KEEP new and used batteries OUT OF REACH OF CHILDREN</td> <td></td> </tr> <tr> <td>• Seek immediate medical attention if a battery is suspected to be swallowed or inserted inside any part of the body.</td> <td></td> </tr> </table> <p>a) The statement "Remove and immediately recycle or dispose of used batteries according to local regulations and keep away from children. DO NOT dispose of batteries in household trash or incinerate."</p> <p>b) The statement "Even used batteries may cause severe injury or death."</p> <p>c) The statement "Call a local poison control center for treatment information."</p> <p>d) A statement indicating the compatible battery type (e.g., LR44, CR2032).</p> <p>e) A statement indicating the nominal battery voltage.</p> <p>f) The statement "Non-rechargeable batteries are not to be recharged."</p> <p>g) The statement "Do not force discharge, recharge, disassemble, heat above (manufacturer's specified temperature rating) or incinerate. Doing so may result in injury due to venting, leakage or explosion resulting in chemical burns."</p> <p>h) The statement "Ensure the batteries are installed correctly according to polarity (+ and -)."</p> <p>i) The statement "Do not mix old and new batteries, different brands or types of batteries, such as alkaline/carbon-zinc, or rechargeable batteries."</p> <p>j) The statement "Remove and immediately recycle or dispose of batteries from equipment not used for an extended period of time according to local regulations."</p> <p>k) The statement "Always completely secure the battery compartment. If the battery compartment does not close securely, stop using the product, remove the batteries, and keep them away from children."</p>	• INGESTION HAZARD: This product contains a button cell or coin battery		• DEATH or serious injury can occur if ingested.		• A swallowed button cell or coin battery can cause Internal Chemical Burns in as little as 2 hours.		• KEEP new and used batteries OUT OF REACH OF CHILDREN		• Seek immediate medical attention if a battery is suspected to be swallowed or inserted inside any part of the body.		<p>FCC Statement</p> <p>1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:</p> <p>(1) This device may not cause harmful interference.</p> <p>(2) This device must accept any interference received, including interference that may cause undesired operation.</p> <p>2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</p> <p>Note: This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.</p> <p>This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</p> <ul style="list-style-type: none"> Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help. <p>The device has been evaluated to meet general RF exposure requirement.</p> <p>The device can be used in portable exposure condition without restriction.</p> <p>YEELIGHT</p>
• INGESTION HAZARD: This product contains a button cell or coin battery												
• DEATH or serious injury can occur if ingested.												
• A swallowed button cell or coin battery can cause Internal Chemical Burns in as little as 2 hours.												
• KEEP new and used batteries OUT OF REACH OF CHILDREN												
• Seek immediate medical attention if a battery is suspected to be swallowed or inserted inside any part of the body.												