

---

# Bluetooth speaker

---

Model Name: BS01

FCC ID: 2ABFFBS01

## User Manual

Thank you for buying the Bluetooth Speaker BS01. This speaker is designed to be convenient, stylish and provide high quality audio playback from any Bluetooth enabled audio device or wired only device.

The Bluetooth Speaker BS01 can also be used to receive telephone calls while in use and will automatically pause the audio playback in order to receive the call and when the call ends audio Playback will resume.


Please read this user guide thoroughly before use so that you can understand the setup and functions.

### Accessories

1. Line-In Audio cable
2. USB Charging cable

### Overview

The speaker contain the following parts as shown



### Switch the speaker on or off

1. To switch on: Press and hold the on/off button for 2 seconds, the Blue indicator light will start to flash.
2. To switch off: Press and hold the on/off button for 2 seconds until the Red indicator light displays briefly.

### Connecting with Bluetooth

1. Hold down the on/off Button for 7 seconds and the Blue and Red indicator light will flash quickly and you'll hear an audio tone. The Speaker is ready to connect to the device.
2. Go to the Bluetooth option in the settings of your Bluetooth Audio device or Smartphone and in the list of Devices select **BS01**.

3. The speaker is now ready to use

## Getting Started Guide

### Two kinds of connections

1. Bluetooth wireless connection
2. 3.5mm audio cable connection

### Connection indication

3.5mm audio cable connection

Plug one end of the 3.5mm audio cable into speaker audio AUX port on the speaker and the other end into the device you want to connect.(such as mobile, MP3, ipad, etc.)

### LED indication status

**Power on:** Blue light flash 5 times

**Power off:** Red light flash 5 times.

**Pairing:** Blue and Red light flash quickly

**Standby:** Blue light flash 2 times every 7 seconds.

**Incoming call:** Blue light flash 1 times every 1 seconds

**During a call:** Blue light flash 1 times every 7 seconds

**Charge:** Red light remains on.

**Charge finish:** Red light turn to Blue.

### Basic operation

- 1) Answer a call: After connection is successful, short press the MFB button to answer an incoming call.you will hear an indication tone.
- 2) End a call: When the call is connected successfully , short press the MFB button to hang up , with an indication tone.
- 3) Reject a call: Hold the MFB button for 3 seconds to reject an incoming call , you will hear an indication tone.
- 4) Voice transfer: During a call , hold the MFB button for 3 seconds until hear an tone, then the voice begin to be transferred from the Bluetooth speaker to your phone , the same operation can transfer the sound from your phone to a Bluetooth speaker
- 5) Last number redial: In the standby mode , press the “Multi-function” button for 3 seconds will redial the last outgoing number. you will hear an indication tone.
- 6) Voice dial: In the standby mode, Double click the MFB button to start voice dial,you will hear an indication tone.(Need the support of the mobile phone

Bluetooth)

- 7) Adjust the volume: when answering, dialing or during a call, short press "+" button to increase volume, and you will hear an indication tone when increase to maximum volume. Similarly, short press "-" button to decrease the volume, and also an indication tone when decrease to minimum volume.
- 8) Pause/Play/Next/Previous:  
Pause / Play: Short press the multifunction button to play or pause music.  
Previous / Next Song: During playing music, long press "+" button to play next song and press "-" button to play previous song.
- 9) Automatic reconnection: The speaker will reconnect with the phone that paired before when turn on.

### **Battery low-voltage alert**

Red light will remains on during charging, will change to Blue light when charging finished. It will take around 2 hours to finish charging. please charge the battery in time When red light flash and alert tone sounds once every 1 minute.

### **Note:**

1. Pairing mode will last 5 minutes. other mobile phone cannot search out the bluetooth speaker.
2. Re-connecting automatically(includes two cases)
  - 2.1 If the Bluetooth speaker turned off, it will connected to the pre-set Bluetooth speaker automatically When turn on manually.
  - 2.2 When the Bluetooth speaker disconnects to mobile phone owing to exceeding effective range(normally Link loss if exceed 10M), the bluetooth speaker will re-connect to mobile phone if back to effective range within about 5 minutes.

### **About battery**

The Bluetooth speaker is powered by a rechargeable battery , new battery achieve the best performance only after two or three complete charge and discharge cycles. The battery can be charged and discharged hundreds of times , but it will eventually wear. When not charging , disconnect it with Bluetooth speaker. Do not leave a fully charged battery connected to a charging circuit since overcharging may shorten battery life. If a fully charged battery is left unused, the battery itself will be discharged after a period of time. If place the battery in hot or cold places , such as a closed car in summer or winter , will reduce the battery capacity and lifetime. Battery temperature should be maintained at between 15-25 centigrade. Bluetooth speaker battery too hot or cold may make it not work temporarily , even if the battery is fully charged. Battery performance is particularly limited in temperatures well below freezing . Do not dispose of batteries in a fire in order to avoid battery explosion. Impaired batteries may also explode.

- Avoid placing this product near extreme temperatures or humidity.

- Do not use this product while operating a motor vehicle
- Do not submerge or allow this product to come into contact with water. Use in dry locations only.
- An adult should supervise young children when using this product.
- Use of any attachment or accessory with this product not recommended or sold by White Label may result in risk of fire, electrical shock or injury to persons or product.
- Do not clean any parts with alcohol, cleaning solutions containing alcohol or strong abrasives. Use a soft cloth and a little water
- There are no user serviceable parts within this product. Tampering with this product will invalidate your warranty.

#### **FCC NOTICE**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference; and
2. This device must accept any interference received, including interference that may cause.

#### **FCC CAUTION**

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.