

Instruction

Many thanks for your acceptance of our Wireless Bluetooth Music/ Phoner Speaker. Please read the below specification before you use this product.

1、Introduction


1.1 Please charging the Wireless Bluetooth Music Loudspeaker in full condition before you use it, then match the Bluetooth Device which you selected, and setting it. All of the part which with the function of Bluetooth could match our speaker, like your mobile phone. You could received the signal within 10 meters, like in the bedroom or living room, you turning on the Bluetooth and Music Player on your mobile phone, our speaker can auto-induction its signal then receives the signal so the music sounded out from our speaker.

1.2 Technical Specifications:

- 1.2.1. Bluetooth support: V3.0 + EDR.
- 1.2.2. Bluetooth valid distance: 10 meters range
- 1.2.3. operating time: approx 10 hours of music or talking
- 1.2.4. Transmitting frequency:2.4G Hz
- 1.2.5. Charger Power supply:DC5V 500mA Max
- 1.2.6. Battery:1100mAh lithium

2、Usage

2.1 Assembling: The Wireless Bluetooth Music Loudspeaker inside the Speaker Or Used alone



2.2 Matching with bluetooth device: “M8” is our standard name for our music shower, please select “M8” as bluetooth signal to match

2.3 LED light instruction--- transprant button above

Matching process: the blue light flashing

Matching Successful: the blue light is in stable.

2.4 Charging for the Wireless Bluetooth Music Loudspeaker

2.4.1 1 Lithium ion batteries(1100mA) included in the Wireless Bluetooth Music Loudspeaker, need to be charging before you use it. The charging time is around 4

hours.

2.4.2 You could use the Batteries USB wire (included) to charging the speaker, it could make sure that around 11.5 hours or standby 15 days when you use it to enjoy music or receive call.The speaker will sound a hurried warning tone(di didi) when it is in the lower power, then you need to charge it in time.

3、Attention:

- 3.1 Please match the Batteries USB wire in right way, do not squeeze it too hard
- 3.2 In common, the maximum output voltage is 5.5 V, otherwise the Wireless Bluetooth Music Loudspeaker. Would be damaged

4、Note

Please according to the below methods to matching if the Wireless Bluetooth Music Loudspeaker do not work:

- 4.1 Make sure the Wireless Bluetooth Music peaker is in enough power and in open condition;
- 4.2 Make sure the Bluetooth function is in open condition;
- 4.3 Make sure the distance between speaker and Bluetooth Device is within 10 meters.

5. Warning

5.1 Changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

- 1. this device may not cause harmful interference, and
- 2. this device must accept any interference received, including interference that may cause undesired operation.