


A pair of black over-ear headphones with a flexible headband and large ear cups. The headphones are shown from a side profile, highlighting the headband and the circular ear cups. The background is white.

 **Bluetooth®**
Bluetooth wireless headset

1

User should not change any components of the headphone and will lose the after sale rights if changes or re-equips the headphone without permission.

2

- Bluetooth headphone
Micro USB charging cable
3.5mm audio cable
- 

- 



Authorise devices to make
connections
automatically




A screenshot of the iTunes application window. The top bar shows the title 'iTunes - Music on the Mac'. Below it are three tabs: 'Music', 'Radio', and 'Library'. The main area displays a music player interface. At the top of the player is a progress bar. Below that is a large image of a man playing an electric guitar. At the bottom of the player, the song title 'SING ALEXIS' is visible. The bottom of the iTunes window features a standard Mac OS X dock with icons for iTunes, Finder, and other applications.




picture (2)


4



- 1 Power
- 2 Previous/Volume+
- 3 Pause/Play
- 4 Next/Volume-
- 5 LED indicator
- 6 Micro USB jack
- 7 3.5mm audio jack
- 8 Microphone



The headband is adjustable at the two sides of the headphone to allow you to adjust the length to your favor to enjoy music more comfortably and freely;



4

Operation/State	LED indicator status	Operating method/Result
Power on	Blue LED glittering	Press the power key for 3s until the blue LED on and glittering;
Pairing	Blue/red LED glittering in turn	Press the power key for 8s until the blue and red LED glittering in turn when in the modes of power off;
Power off	Red LED on and then extinguish	Press the power key for 3s until the blue LED on and extinguish
Charge indicator	Red LED on	Connect the headphone with computer via the micro USB cable, the red LED glittering and then on;
Fully charged	Red LED extinguish	The red LED extinguish;
Pairing successfully	Blue LED glittering	The blue LED glittering every 5s
Call receiving	Blue LED glittering fast	The blue LED glittering quickly when call comes in and press the power key to answer the call;
In conversation	Blue LED glittering	The blue LED glittering every 5s

6

● Speaker diameter:	φ40mm
● Impedance:	32Ω
● S.P.L.:	93dB S.P.L.at 1KHz
● Rated power:	20mW
● Aggregate capability:	40mW
● Frequency Response:	20Hz-20,000Hz

● MicrophoneUnit:	φ6*5mm
● Directivity:	360degree S.P.L:-42±3dB
● Impedance:	≤2.2KΩ
● Frequency Response:	30Hz-16,000Hz
● Operating voltage:	4.5V

- In the mode of music playing or call talking, adjust the switch forward can increase the volume to the maximum and downward the switch will decrease the volume to the minimum;
- 7 Pause/Play:
When playing music, pressing the switch for one time, the music will be paused and will continue to play to press the switch once again;
The blue LED will be glitter every 5s and it will lasts on 2s every time in music playing state;
- 8 Previous/Next
In the mode of music playing, adjust the switch forward twice continually will to the previous song and backward the switch twice continually will to be next song;
- 9 Key Lock: When the headphone is in the state of standby or music playing, pressing the switch twice continually can let all the functional key locked ; When pressing, there will be with implication sounds; If the sounds decrease from loud to dimmer, it means the open up of the Key locks; And if the sounds increase from dim to louder, it means the close up of the key locks;

1.

Please correctly wear the headphone to ensure the best listening effects. "L" on the headphone stands for left and "R" stands for right. Do not detach the hardware of the headphone. Using the dry and soft cloth to clean the product.

The following preventative measures can be taken:

- 1、Ensure the first time for battery charge is not less than 4 hours.If it will not be used for a long time, please ensure there is enough electricity in the battery.
- 2、Ensure the battery is the original one and do not change another one.
- 3、Do not place the headphone under the temperature which is equal or higher than 45.
- 4、Do not detach the product unless you are the professional in this field.
- 5、Under charging,the common charging time is about 2-3 hours.After full of power,it can be used about 10 hours under the condition of maximum sound.Starting charging,the LED light shows the red color and ending charging,the LED light is quenched.
When it is nearly out of power,the red LED light is glittering as 30s.Besides,there is warning sound.If it's time to charge.

Note:Pls don't use the equipments under charging(Charging by the micro USB cable)

WARNING