


The ISO/IEC 15693 systems Reader operate at the 13.56 MHz \pm 7KHz frequency, and offer maximum read power of 0.5 watts.


When the cards come into the 13.56 MHz RF field, the Reader receives the card ID and sends out to the RS232 interface




9. How to Play

- Explanation of Playing

- ① Insert coins. Play can be started after reached set-up coin quantity.
- ② There are balls marked with its numbers on the turning table. A figurine standing in the middle of the table moves forward after press a button. Try to move the figurine at the right time to push high score balls well. If the button is not pressed within 60 seconds, the figurine will be automatically moved forward after sounding the warning.



- ③ Press the button, the doll will move forward and push the ball to the front enclosed space.



④ After the ball drops into the space, tickets will be issued according to numbers marked on the ball. If succeeded in dropping JP ball, player can get scores mentioned on JP 7 SEG.

