

User's manual

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: The user is cautioned that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

1. Installation method

- ①When using the temperature sensor and the external current sensor, they should be connected to the device in advance.
- ②If the battery is not inserted, remove the battery cover on the back of the device to insert the CR2450 battery and replace the battery lid.

2. Operating instructions

- ①Press the switch to start.
- ②Place the device where it is needed.
- ③To stop the operation, press the switch once again. In the stop mode, the green LED will start to flash.

3. Radio specification

Wireless output power: 20mW

Operating frequency: 0.0166Hz

Operation channel: 926.8MHz

Operation mode: The radio transmission to the operation mode

Data rate: 25kbps