

2.4GHz Wireless Receiver

SE11D

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

LIMITED WARRANTY


Adesso provides a one year limited warranty for all of its products against defects in material and workmanship.

During this period, Adesso will repair or replace any product which proves to be defective. However, Adesso will not warranty any product which has been subject to improper freight handling, shipping abuse, neglect, improper installation or unauthorized repair. The warranty will not cover products installed with components not approved by Adesso and products where the sealed assembly trace has been broken.

If you discover a defect, Adesso will, at its option, repair or replace the product at no charge to you provided you return it during the warranty period with freight charges pre-paid to Adesso. Before returning any product, you must obtain a Return Merchandise Authorization number (RMA). This RMA # must be clearly marked on the outside of the package you are returning for warranty service. Be certain to also include your name, shipping address (no PO Boxes), telephone number, and a copy of the invoice showing proof of purchase in the package.

INSTALLATION

1. Plug the Wireless Receiver into your computer's available USB port.



2. Your computer's operating system will automatically detect and connect the device (this device is plug and play, no driver is required). Your wireless device is now ready to use.

TROUBLESHOOTING:

If you cannot get your wireless device to work after installation try the following:

1. Make sure you are using new batteries and verify they are properly installed in battery compartment.
2. Ensure Power Switch on your wireless device is set to **ON**. Then press the **Connect** Button to establish wireless connection.
3. Ensure that the Wireless Receiver is securely plugged into a properly powered USB port on your computer.

①

②

③