

!

100.00 mm

70.00 mm

ICON Q CORPORATION

User Guide

Y062

I. Introduction


Great job on purchasing your new Joha Bluetooth speaker! Using it should be easy and fun, so please read through this user guide fully to make sure that's the case. If you're not familiar with Bluetooth, check out the function on the device you plan to use with the speaker, consult the user guide, or simply ask someone who can help you get acquainted.

And of course, safety first. Make sure to stick to the safety rules at all the times to get the most out of your speakers.

For best sound quality, charge fully before first use.
PAIRING ID: Y062


II. What's Inside

Y062 speaker
USB Cable (micro USB)
User Guide




1

III. Unit at a Glance



- 1 Play/Pause/Call
- 2 Previous/VOL-
To play the previous song, press once.
To decrease the volume, hold for several seconds.
- 3 Next/VOL+
To play the next song, press once.
To increase the volume, hold for several seconds.



2

IV. Usage

A. CHARGING YOUR DEVICE

The Joha speaker offers convenient charging via a micro USB port. For best sound quality, you must charge the product fully before using it for the first time.

- Steps:
- Find the USB cable included with this product.
 - Connect the micro connector to the speaker's micro USB port.
 - Connect the other end to your computer's USB port. Make sure your computer is turned on. You can also connect the cable to a USB power adapter for charging with an electrical outlet.
 - When charging, the charging indicator light on the bottom of the speaker will turn red.
 - When fully charged, the charging indicator light will turn off.

B. PAIRING DEVICES

To use your Bluetooth speaker, you must first pair it with a Bluetooth-enabled device, such as a smartphone or a computer. In the future, the speaker will automatically recognize and connect to the Bluetooth device it has been paired to previously.

3

IV. Usage (Continued)

- Steps:
- Make sure the speaker is charged. Turn on the speaker.
 - The status indicator light on the bottom of the speaker will flash red and blue rapidly. The speaker is in pairing mode.
 - Turn on your Bluetooth device and ensure its Bluetooth function is activated. You will find this option on most devices under Settings or Options.
 - Follow your device's instructions to search for Bluetooth devices. After a few seconds, your Bluetooth device will list the speaker as a discovered device. The speaker ID is "Y062".
 - Select the speaker, and pair the two devices. If asked for a passcode, enter "0000".
 - When the status indicator light blinks blue, it means your Bluetooth-compatible device has been successfully connected.

C. PLAYING AUDIO AND TAKING CALLS

Select the program on your Bluetooth device that you want to use with the speaker, and press play from that program.

Once the speaker is playing, use the speaker's PLAY/PAUSE button to pause and restart audio.

During an incoming call, press the same button to answer

4

the call. Press again to end the call. The speaker will resume playing.

D. CHANGING SONGS AND ADJUSTING THE VOLUME

See Part III., "Unit at a Glance".

E. AUX INPUT

In addition to playing audio via Bluetooth, this product also supports AUX input.

To use, connect a 3.5mm line-in cable from the speaker to any device with a headphone jack or audio output. If you choose to disconnect the cable and resume Bluetooth mode, press the speaker's PLAY/PAUSE button to restart the audio in Bluetooth mode.

V. Safety Guidelines

Please follow the safety guidelines below at all times when operating or caring for your device.

- Listen to music at a proper volume to avoid hurting your hearing and the speakers.
- Do not connect an external amplifier to the AUX input.
- Avoid storage in high temperatures, such as in a hot vehicle or in direct sunlight.
- Do not expose the speaker or any of its supplied parts to rain or other liquids.
- Do not drop or cause undue impact to the speaker.

5

- Do not modify, repair, or dismantle the product on your own.

VI. Specifications

Model Number:	Y062
Bluetooth version:	v2.1 + EDR (Enhanced Data Rate)
Range:	10 m (approx. 33 ft.)
Frequency range:	100Hz-20KHz
Signal-to-Noise:	≥ 95dB
Driver:	45mm
Rating power:	RMS 3W (THD≤0.5%)
Battery specification:	3.7V, 450mAh
Input voltage:	DC5V
Playing mode:	Bluetooth/AUX
Size:	60mm x 60mm x 50mm
Weight:	230g

VII. Support

If your device is not functioning correctly, please visit www.johausa.com for customer support, and we will be more than happy to help you.

VIII. Limited Warranty

For more information and instructions on how to get warranty service, visit www.johausa.com.

6

FCC Statement:
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for Class B digital devices, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Use of shielded cable is required to comply with Class B limits in Subpart B of Part 15 of the FCC rules. Do not make any changes or modifications to the equipment unless otherwise specified in the manual. If such changes or modifications should be made, you could be required to stop operation of the equipment.
QDID: 49207

©2014 Icon Q Corporation
1225 Franklin Avenue, Suite 325 Garden City, NY 11530

7