

## **Cube Bluetooth Speaker** **USER MANUAL (Read before proceeding)**

### **LED**

- Power on: Red & Blue light starts flashing at intervals.
- Ready for pairing: Red & Blue light is flashing quickly.
- Connected: Only blue light is flashing at intervals.
- Charging: Red light is always on.
- Red light off: Power charging complete.

### **Charge**

1. Your "TS-006B / TS-007B" (unit) should come with enough power to pair with your device. If you are having trouble pairing or powering on the "TS-006B / TS-007B", please make sure it is fully charged.
2. Use the USB charge cable connect your "TS-006B / TS-007B" from its micro charging port to your computer.
3. The red light is off when power charging completed.

Note: Battery life varies by use and settings.

### **Switch on/off & Connect/disconnect**

1. Press the "Power" button for 2 seconds to switch on/off. The red & blue light starts flashing.
2. Press the "Phone" button on the top, the red and blue light is flashing quickly, which means the devices is ready for pairing.
3. On the Bluetooth device, switch on Bluetooth and search for "Vivitar Infinite". For the first-time connection, select "Vivitar infinite" to start connection. If necessary, enter the passcode 0000 or 1234.
4. To connect "TS-006B / TS-007B" to another Bluetooth device, switch off Bluetooth on current Bluetooth device.

### **Play & Speakerphone**

1. After successful connection, start music play on the Bluetooth device. You can listen to music from "TS-006B / TS-007B" wirelessly (< 33 ft.). The music streaming may be interrupted by obstacles between the device and "TS-006B / TS-007B", such as walls, metallic casing that covers the device, or other devices nearby that operate in the same frequency.
2. Press "+" or "-" ONCE to swipe forwards or backwards to skip songs.
3. Long press "+" or "-" to control the volume.
4. When there is an incoming call, music play pauses. Pick up the phone call by press "Phone" button. You can talk through the microphone on "TS-006B / TS-007B". Music play resumes when your call ends.
5. You can also use the 3.5 mm audio cable connect your "TS-006B / TS-007B" from its audio port to your device 3.5 mm port. Then you can listen to the music.

### **FCC Warning Statement**

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a

particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.