

**TCL NXTPAPER 11 Plus**

## QUICK START GUIDE


9469X



CJB76P1LCAAA


Printed in China

# Your device



# 2 Charging

Your new tablet is partially charged. Charge the battery with the included USB-C cable.



Note: Charger not included with your device. Refer to the Safety guide for information on compatible chargers.

# 3 Home screen

You can bring all of the items (applications, shortcuts, folders) that you use most frequently to your Home screen for quick access.

Swipe up from the thin line at the bottom of the screen to take you back to the main Home screen.

Drag a finger up from the thin line and hold it for a while to get recent apps.

Swipe from the left or right edge of the screen and an arrow pops out, then release to return to the previous screen.

## **Status bar**

- Status/Notification indicators
- Drag down to open the notification panel



Tap an icon to open an application, folder, etc.

## **Favorite applications tray**

- Tap to enter the application
- Long press to move or change applications

The Home screen is provided in an extended format to allow more space for adding application icons, shortcuts etc. Swipe left and right on the Home screen to view the extended screens.


## **Status bar**

In the status bar, you can see the notifications on the left side and the connection service status on the right side.

Swipe downward from the Status bar to access the Notification panel or the Quick Settings panel. To close the panel, touch and drag upward.

## **Notification panel**


Tap on the notification to view it in the app.



Tap to clear all event-based notifications. On-going notifications will remain on the panel.

## Quick settings panel

From the Quick Settings panel you can enable or disable functions or change modes by tapping the icons.




Tap to access the full Settings menu, where you can manage other items.

Tap to edit Quick Settings panel.

# 4 Contacts

Contacts are stored in your tablet with the Contacts app. Add, edit, or delete contacts on your tablet and synchronize them with the contacts in other accounts that support contact syncing.

You can also import or export your contacts from different locations such as an external storage, email, or other account.



## Adding a contact


Open Contacts  from applications list, then tap  to add a new contact.

## Synchronizing contacts in multiple accounts

Contacts, data or other information can be synchronized from multiple accounts, depending on the applications installed on your tablet.

# 5 Gmail

When you first set up your tablet, it is automatically synchronized with your Google account. Use Gmail to create, send, and receive emails directly on your tablet. The Gmail app will allow you to add several email accounts.




## To open Gmail

From the Home screen, tap **Gmail**  in the Google folder.

Gmail displays messages and conversations from one single Gmail account at a time. If you own additional email accounts, you can add an account by tapping Menu  > **Settings** > **Add account**.

Switch to another account by tapping the icon in the top right corner, then select the name of the account you want to view.

## To create and send emails

1. Tap  from the Inbox screen.
2. Enter the recipient(s)'s email address in "To" field.
3. If necessary, tap  to copy (CC) or blind copy (BCC) a recipient to the message.
4. Enter the subject and the content of the message.
5. Tap  icon and select **Attach file** to add an attachment.
6. Tap  to send.

If you do not want to send the email right away, tap  > **Save draft**. To view the draft later, tap Menu  and select the **Drafts** folder.

**NOTE:** Software is constantly evolving, the screen images and icons you see here are for reference only.

## 6 Getting connected

To connect to the Internet with this tablet, you will need to have an internet connection via Wi-Fi.

### Wi-Fi

To turn Wi-Fi on and connect to a Wi-Fi network:

1. Go to **Settings** > **Wi-Fi**.
2. Tap the switch  to turn on Wi-Fi.
3. Tap a Wi-Fi network to connect. If the network you selected is a secured network, you will need to enter a password or other credentials. When finished, tap **CONNECT**.
4. For hidden network, slide up the screen and select **Add network**. Enter the SSID of the network, password and its secured credentials. Then, tap **SAVE**.

## 7 Disclaimer

There may be certain differences between the user manual description and the device's operation, depending on the software release of your device or specific operator services. TCL Communication Ltd. shall not be held legally responsible for such differences, if any, nor for their potential consequences, which responsibility shall be borne by the operator exclusively.

# 8 Help

- Check out the TCL website at [www.tcl.com](http://www.tcl.com) for tutorials and answers to frequently asked questions, and to download the User Manual.
- To get support for your tablet, visit the TCL website ([www.tcl.com](http://www.tcl.com)) or dial the number listed below:

Canada- 1-855-224-4228

United States- 1-855-224-4228

- Update your tablet's software

Go to **Settings > System > System Update** to check software updates.

- Back up your personal data

Go to **Settings > System > Backup** to back up your device.

- Reset your tablet

Go to **Settings > System > Reset options > Erase all data (factory reset) > Erase all data.**