

# TCL GFLIP2

AT&T



Let's get started



AT&T 3-Star  
Eco-Rating 2.0  
[att.com/ecospace](http://att.com/ecospace)

WIRELESS  
EMERGENCY  
ALERTS  
CAPABLE™

AT&T Eco Rating 2.0 only applies to **TCL GFLIP2**. For limited factors evaluated visit [att.com/EcoSpace](http://att.com/EcoSpace). Wireless Emergency Alerts is a registered Trademark and Service Mark of CTIA.

TCL is a registered trademark of TCL Technology Group Corporation. LTE is a trademark of ETSI. 4G LTE not available everywhere. Contains lithium-ion battery - recycle or dispose of properly. © 2021 AT&T Intellectual Property. All rights reserved. AT&T, the AT&T logo and all other AT&T marks contained herein are trademarks of AT&T Intellectual Property. All other marks are the property of their respective owners.

## What else is in the box?

- [device name]
- USB-C data cable
- Wall charger
- Pre-installed SIM card
- Lithium-ion battery
- Safety & warranty information

## Get Connected

### Connect to Wi-Fi®

1. From the Home screen, press **OK** > **Settings** > **Wireless & network** > **Wi-Fi**.
2. Press **Left Menu** to turn on or off.
3. **Navigate down** to Available Networks > press **OK** to select your preferred network.
4. **Navigate down** to enter a password, if required > press **OK** .

### Use Bluetooth®

1. From the Home screen, press **OK** > **Settings** > **Wireless & network** > **Bluetooth**.
2. Press **Left Menu** to turn on or off.
3. **Navigate down** to the name of the device to pair > press **OK** .

## Setting Up Email

From the Home screen, press **OK** > **Tools** > **E-Mail** .

An email wizard will guide you to set up an email account, press **Right Menu** to continue.

1. Enter your email address of the account you want to setup.
2. Press **Right Menu** to access **Next**, enter the password and press **Right Menu** .
3. You may be prompted to manually setup your email account.

## Send E-Mail

Press **Left Menu** to compose a new email from the Inbox screen.

1. Enter recipient(s) email address(es) in the **To** field, press **OK** to confirm and add new recipient(s).
2. Type the subject and the content of the message.
3. If necessary, press **Right Menu** to add **Cc/Bcc** or add attachment to the message.
4. If you do not want to send the mail right away, press **Right Menu** and select **Save as draft** to save a copy.
5. Finally, press **Left Menu** to send.

## Find More Information

### Manage Your Account with myAT&T

- On your phone: **OK** > **My AT&T**
- On the web: [att.com/myATT](http://att.com/myATT)

Compatible device and online account required. Data and messaging rates may apply for app usage.



### Need More Help?

- On the web: [att.com/DeviceHowTo](http://att.com/DeviceHowTo)

### Give us a call

- 611 from any AT&T wireless phone
- 800.331.0500 or prepaid 800.901.9878

## Your New Phone



Need more help?  
Go to **Apps > myAT&T**

## Speed Dial

### Quickly Set Up Speed Dial

1. From the Home screen, long press a keypad number, 2-9. Voicemail is automatically assigned to 1 and cannot be changed.
2. A window will appear on the screen, press **Right Menu** to confirm assign an action.
3. Use **Navigation** to scroll to the one of 2-9 keypad number, press **OK** to set.
4. Use **Navigation** to scroll to the desired contact. Press **OK** to confirm the contact and phone number.
5. When complete, a notification will appear in the status bar: "Speed dial set."

### Use Speed Dial

1. From the Home screen, long press the keypad number to dial the assigned contact.

## Call Family & Friends

### Make a Call

1. From the Home screen, begin dialing a number.
2. Press **OK** or **Place/Answer Call** to place the call.
3. To hang up the call, press **Power/Hang Up** .

### Set Up Voicemail Box

1. From the Home screen, press **OK** > **Settings** > **Call settings** > **Voice mail** > **Setup**.
2. Enter Voicemail number, press **OK** to save.


### Call Voicemail

1. From the Home screen, press and hold for at least three seconds.

## Using Navigation

### Getting Started

- **Navigate** is located above the number pad that frames **OK** .
- Press Up, Down, Left, or Right on the ring to navigate the screen.
- To make a selection, press **OK** .
- Shortcuts accessible from the Home screen:
  - **Navigate up** to access **Settings**.
  - **Navigate down** to access **Recent apps**.
  - **Navigate left** to access Email providers, such as Gmail, Outlook, and more.
  - **Navigate right** to access **Contacts**.
- Press **OK** to access the App tray.



## Text Messaging

### Send a Text/Multimedia Message

1. From the Home screen, press **OK** > **Messages** .
2. Press **Left Menu** to create a new message.
3. Enter the phone number of the recipient in the **To** bar, or press **Right Menu** > **Select from contact** or **Select contact group**.
4. Press **Navigate down** to access SMS bar to type in the message.
5. Press **OK** to send.

### Use En KT9 to Quickly Type Words

1. En KT9 is a default input method.
2. When forming a word, press each key only once for each letter.
3. Once the word of your choice appears, use **Navigation** to highlight the word. Press **0** to add a space and proceed to the next word.
4. Press to toggle between the other types of input methods: abc, Abc, ABC, 123, or to return to En KT9.

## Capture Life's Moments

### Take a Picture

1. From the Home screen, press **OK** > **Camera** .
2. Press **OK** to take a photo.

### Record a Video

1. With the **Camera** open, press **Right Menu** > **Take video** to switch to video mode.
2. Press **OK** to start/stop recording.

### Share a Picture or Video

1. From the Home screen, press **OK** > **Gallery** .
2. Select a photo or video, press **Right Menu** > **Share** to send the picture or video.