

User Guide



hajen

English

1. Getting to Know Your Device

fixta is Alexa Voice Service enabled LTE mobile hotspot. You can enjoy Alexa voice service with all Alexa skills wherever you have LTE or WiFi signal.
Learn more about the device setting like connecting to your car or to your network as a multi room speaker, fixta hotspot connection and so on.
www.fixta.com

1. Wake Word On/Off Button
Disable or Enable microphone.

2. Power Button

Status	Short Press	Long Press(3s)
System ON	Show Battery Level	Power OFF
System OFF	No Response	Power ON

3. LTE On/Off Button, LED Status
Pressing the button, turns on and off the LTE mode. When LTE is off, the device changes to WiFi mode.

Status	Visuals
LTE Signal Strong	Blue
LTE Signal Middle	Green
LTE Signal Normal	Orange
LTE Signal Weak	Red
Connecting	Flashed Green
Authentication Fail / Out of range	Flashed Red
LTE Off	LED Off

4. Volume Control (+/-) Button

Short Press	Long Press
Adjust volume 1 level	Adjust volume continuously

5. Action Button

Short Press	Long Press
Wake up Alexa	Device Searching Mode

6. Battery LED

Status	Details	Visuals
Fully Charged	100%	LED Off
Battery High	81~99%	Blue
Battery Normal	50~80%	Green
Battery Low	20~49%	Orange
Need to charge	5~19%	Red
Discharged	~5%	Power Off


7. Sim Card Slot **8. Charging Port**

2. Setting Up Your Device

1. Install fixta app.
Download fixta app. on your mobile device.




2. Charging
Charge the device before using.
(DC 5V, 2A, USB-C Type Jack)



3. Insert USIM Card

※ Check out SIM Card direction.
※ Use Nano SIM.
(Mini or Micro SIM size is not available)




4. Setup

Open fixta app on your mobile device and follow the instruction to complete the device set up and Alexa log in.

- 1) Turn on the fixta device and press action button for 4 seconds
- 2) Select your device FIXTA-XXXX & click Next
- 3) Device connected to your phone
- 4) Sign in with Amazon
- 5) Click get started amazon account log in
- 6) Sign in your amazon account
- 7) Select alexa language
- 8) To access additional features download Amazon alexa app.
- 9) Setup completed

5. Network Mode Change

Press LTE button on the device to change network mode from WiFi to LTE or LTE to WiFi. Or change the mode button on fixta app.



3. Using Amazon Alexa

1. Connect fixta Device to internet

Using LTE Mode with your valid using card.
Using WiFi Mode with your AP Router.

2. Login Amazon account in FIXTA app


3. Say 'Hello' to your FIXTA

4. Alexa Status LED


Group	Status	Color
Idle	Idle	-
Core	Listening / Thinking / Speaking	Cyan & Blue
Microphone Off	Microphone Off	Red
Alerts	Timers / Alarms / Reminders	Cyan & Blue
Notifications	Notification Arrives / Queued	Yellow
Do Not Disturb	Do Not Disturb Enabled	Purple
Pairing & Discovery	Bluetooth	Blue
Errors	System and Device Errors	Red
	Alexa Service Unavailable	
	No Internet Connection	

4. Using LTE Hotspot


1. Go to the Settings Page




2. Press Network Menu



3. Select LTE and activate hotspot




4. Select hotspot WiFi band(Optional)




※ 5GHz Band is recommended for optimal performance.
※ You cannot search or connect to your hotspot if your device doesn't support 5GHz.

5. Using Bluetooth & Spotify

1. Enter Bluetooth Menu



2. Choose Available Device




Spotify Connect



Use your phone, tablet or computer as a remote control for Spotify. Go to [Spotify.com/connect](https://spotify.com/connect) to learn how.

The Spotify Software is subject to third party's licenses found here:
www.spotify.com/connect/third-party-licenses.



Important Safe Instruction

As with general electronic product, precautions should be observed during handling and use.

- Read this instruction carefully and keep it.
- Do not use the Product near water.
- Clean only with dry cloth.
- Do not install near any heat sources such as stoves.
- Protect the USB cable from pressing by heavy substances or pulled by excessive power.
- Unplug the Product during lightning storms or when unused for long periods of time.
- Keep away magnetic recording devices from the Product as there may be a small amount of magnetic flux leakage.
- Only use under 122°F(50°C) of environment to prevent any damage to built-in battery.
- Do not dispose of in the household waste, as the product contains a built-in battery and should be treated and disposed according to regulations on waste disposal.
- Sudden movement from cold to hot environment may cause moisture condensing on the Product and degrade system performance and decrease product life span.
- Protect product from direct sun light.
- Do not use solvents to clean the Product and keep away from dusty environment.
- Do not attempt to disassemble the Product.
- AC adaptor is not supplied with the Product. Damages caused by improper power adaptors is not compensated.
- Always leave sufficient space around the Product for ventilation. Do not place Product in or on a bed, in a bag that may prevent air flow through vent openings.
- Don't place lighted candles, cigarettes, etc. on the Product.
- Be care that heavy objects do not fall into the Product.
- To completely disconnect the power input, the USB cable should be disconnected from the Product.
- Use of the Product in moderate climates. Use under extreme temperature may degrade system performance and product life span.

Certification and Warnings

The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device types HAJEN SPRINT AI Speaker (FCC ID: 2ACFTRT1505NN) has also been tested against this SAR limit. The highest SAR value reported under this standard during product certification for use when properly worn on the body is 0.74 W/kg. Simultaneous RF exposure is 1.303 W/Kg. This device was tested for typical body-worn operations with the back of the handset kept 10mm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 10mm separation distance between the user's body and the back of the handset. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.

FCC statements: This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications or changes to this equipment. Such modifications or changes could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

한국어

사용설명서



hajen

1. 외관 및 기능

fixta 는 Amazon Alexa 인공지능 서비스를 탑재한 LTE 핫스팟 제품입니다. LTE 와 WiFi 를 이용하여 어디서나 Alexa 서비스를 이용 할 수 있습니다.

차안에서의 연결, 네트워크 멀티룸 스피커 기능 및 핫스팟 연결 등에 대한 세부 사용 설정은 www.fixta.com 을 방문해 주세요.

1. 마이크 On/Off 버튼
마이크를 끄거나 켜니다.

2. 전원 버튼

상태	1번 누름	길게 누름(3초)
전원 On	배터리 잔량 표시	전원 꺼짐
전원 Off	-	전원 켜짐

3. LTE On/Off 버튼, 상태표시 LED
버튼을 누르면 LTE 모드를 켜고 끌 수 있습니다. LTE를 끄면 디바이스는 WiFi 모드로 전환합니다.

상태	표시
LTE 신호 강함	파란색
LTE 신호 보통	녹색
LTE 신호 약함	황색
LTE 신호 아주 약함	빨간색
연결 중	초록색 점멸
인증 실패 / 연결 불가능한 지역	빨간색 점멸
LTE 꺼짐	LED 꺼짐

4. 볼륨 조절(+/-) 버튼

짧게 누름	길게 누름
볼륨 1단계 조절	연속으로 볼륨 조절

5. 액션 버튼

짧게 누름	길게 누름
Alexa 음성인식 시작	디바이스 찾기 모드

6. 배터리 상태 표시 LED

배터리 상태	잔량	표기
완충	100%	LED 꺼짐
높음	81~99%	파란색
보통	50~80%	녹색
낮음	20~49%	황색
충전 필요	5~19%	빨간색
방전	~5%	전원 꺼짐


7. USIM 소켓 **8. 충전 포트**

2. 디바이스 설정

1. fixta 앱 설치
휴대폰에 fixta 앱을 다운로드 합니다.




2. 충전
사용전 충분히 충전 합니다.
(DC 5V, 2A, USB-C Type)



3. USIM 카드 삽입

※ USIM 카드 방향에 주의하세요.
※ Nano SIM 사용.
(Mini / Micro SIM 은 사용할 수 없습니다.)




4. 설정

휴대폰에서 fixta 앱을 열고 디바이스 설정 및 Alexa 로그인을 완료 하세요.

- 1) 디바이스의 전원을 켜 후 액션버튼을 4초이상 누르세요.
- 2) 사용자의 디바이스(FIXTA_XXXX)를 확인하고 Next 버튼을 누르세요.
- 3) 제품이 휴대폰과 연결 됩니다.
- 4) Amazon 계정이 없으면 새로운 계정을 생성합니다.
- 5) Amazon 계정 로그인으로 시작합니다.
- 6) Amazon 계정에 로그인 합니다.
- 7) 원하는 Alexa 언어를 선택합니다.
- 8) 부가적인 기능 설정을 위해 Amazon Alexa 앱을 다운로드 합니다.
- 9) 설정이 완료 되었습니다.

5. 네트워크 모드 변경

디바이스의 LTE 버튼을 누르거나 앱에서 네트워크를 변경하면, LTE모드에서 WiFi 모드로 전환하거나 WiFi모드에서 LTE 모드로 전환합니다.



3. Amazon Alexa 사용

1. fixta 디바이스를 인터넷에 연결 합니다.

LTE 모드 사용 시 인증된 유심을 사용하세요.
WiFi 모드 사용 시 무선 공유기에 접속하세요.

2. fixta 앱에서 Amazon 계정에 로그인 합니다.


3. Alexa 를 호출해 보세요.

4. Alexa 상태표시 LED


그룹	상태	색상
대기	사용자 명령 대기	-
코어	듣기/ 처리 / 말하기	Cyan & Blue
마이크	마이크 Off	Red
경보	타이머 / 알람 / 리마인더	Cyan & Blue
알림	알림 도착	Yellow
방해 금지	방해 금지 모드 활성화	Purple
블루투스	연결 & 장치 찾기	Blue
오류	시스템 또는 기기 오류	Red
	Alexa서비스 사용 오류	
	인터넷 연결 불가	

4. LTE 핫스팟 사용


1. 설정 화면으로 이동




2. Network 메뉴 클릭



3. LTE 선택 및 Hotspot 활성화




4. Hotspot WiFi 밴드 선택(옵션)




※ 최적의 성능을 위해 5GHz Band로 설정하는 것을 권장합니다.
※ 기기가 5GHz를 지원하지 않을 경우 Hotspot을 검색하거나 연결 할 수 없습니다.

5. 블루투스 & Spotify 사용

1. 블루투스 설정 메뉴로 이동



2. 사용가능한 스피커 디바이스 선택




Spotify Connect



휴대폰, 태블릿, 컴퓨터로 Spotify 원격 제어 기능을 사용하세요. 사용 방법을 알아보려면 [Spotify.com/connect](https://spotify.com/connect) 로 방문하세요.

Spotify 소프트웨어는 타사 라이선스의 적용을 받을 자체의 보기:
www.spotify.com/connect/third-party-licenses



중요 안전 지침

전자 제품 취급 및 사용에 대한 일반적인 주의 사항들이므로 주의깊게 읽어 주시길 바랍니다.

- 본 사용 설명서를 필독하신 후 보관하여 주십시오.
- 제품을 물 근처에서 사용하지 않아 주십시오.
- 제품 외관을 마른걸레로 닦아 주십시오.
- 난방기구나 발열기가 근처에 두지 마십시오.
- 전원케이블 위에 무거운 물체를 올려두거나 무리한 힘을 가하지 않도록 주의 하십시오.
- 제품은 평평한 곳에서 사용에 주십시오.
- 번개가 치는 날이나 오래 사용하지 않을 경우에는 전원 (USB) 케이블을 분리하십시오.
- 본 제품은 소량의 누설 자기장이 있으므로 마그네틱카드 등 자기 기록이 있는 물건을 접촉하지 마십시오.
- 본 제품은 내장 배터리가 들어있습니다. 주변 온도가 50°C 이상의 환경에서 사용하지 마십시오.
- 본 제품을 폐기해야 할 때는 법에서 지정한 적절한 폐기 절차를 통해 처리되어야 하며, 가정용 쓰레기와 일격히 분리되어야 합니다.
- 주원환경에서 더운환경으로 갑자기 제품을 옮기면 결로 현상에 의해 성능과 수명이 감소할 수 있습니다.
- 제품이 직접 직사광선에 닿지 않도록 주의 바랍니다.
- 제품을 닦을때 솔벤트와 같은 용제를 사용하지 않아 주십시오. 또한 먼지가 많은 곳을 피해 주십시오.
- 제품의 분해는 지정된 AS 센터에서만 가능합니다.
- 본 제품은 아답터를 제공하지 않습니다. 규격에 맞지 않는 아답터를 사용하여 발생한 문제에 대해 책임지지 않습니다.
- 물기가 있는 작은 화면이나 이불속, 책꽂이, 가방등 공기기의 흐름이 나쁜 곳에서 사용하지 않아 주십시오.
- 물 붙은 장소, 담배등을 올려 놓지 않아 주십시오.
- 마그네틱 물체가 떨어지지 않도록 주의하십시오.
- 제품을 임의로 분해하지 않아 주십시오.
- 제품으로 부터 완전히 전원을 제거하기 위해서는 전원케이블을 제거하십시오.
- 일반적인 온도에서 사용에 주십시오. 사용 온도가 너무 높거나 낮으면 성능과 수명이 저하됩니다.

인증정보 & 주의사항

미국(FCC)의 SAR 한계는 조직 1g에 대한 평균 1.6 W/kg입니다.

장치 유형 HAJEN SPRINT AI Speaker (FCC ID: 2ACFTRT1505NN) 도 이 SAR 한계에 대해 시험했습니다. 본 제품에 따라 제품 인증 중 보고된 가장 높은 SAR 값은 신체에 적절한하게 착용했을 때 신체 기준 0.74 W/kg 이고, 동시 RF 노출은 1.303 W/kg입니다.

이 장치는 핸드셋의 뒷면이 본체에서 10mm 떨어진 상태에서 일반적인 신체 착용 작동에 대해 테스트 되었습니다. FCC RF 노출 요구사항을 준수하려면 사용자 몸과 단말기 뒷면 사이에 10mm 거리를 유지하는 부속품을 사용하십시오. 벨트 클립, 홀스터 및 이와 유사한 액세서리를 사용하는 경우 조립품에 금속 부분이 포함되어서는 안됩니다.

이러한 요구 사항을 충족하지 않는 액세서리를 사용하면 FCC RF 노출 요구 사항을 준수하지 않을 수 있으므로 피해야 합니다.

FCC 규정: 이 장치는 FCC 규정의 15 부를 준수합니다. 다음 두 상태에서 작동되어야 합니다.
(1)이 장치는 유해한 방해 전파를 일으키지 않으며,
(2)장치의 오작동을 일으킬 수 있는 방해전파를 포함하여 수신되는 모든 방해 전파를 수용해야 합니다.

참고: 제조업체는 이 장비의 무단 개조 또는 변경으로 인한 라디오 또는 TV 간섭에 대해 책임지지 않습니다. 이러한 수정/변경으로 인해 장비 작동 권한이 무효화 될 수 있습니다.

참고: 이 장비는 FCC 규정 15 부에 따라 테스트되었으며 클래스 B 디지털 장치의 제한을 준수하는 것으로 확인되었습니다. 이러한 제한은 주거 지역 설치시 유해한 간섭으로부터 적절한 보호를 제공하기 위해 고안되었습니다. 이 장비는 무선 주파수 에너지를 생성하고 방출 할 수 있으며 지침에 따라 설치 및 사용하지 않을 경우 무선 통신에 유해한 간섭을 일으킬 수 있습니다.

그러나 특정 설치에서 간섭이 발생하지 않을 것이라는 보장은 없습니다.
이 장비가 라디오 또는 TV 수신에 유해한 간섭을 일으키는 경우 (장비를 끄다 커서 확인할 수 있는 경우) 다음 조치 중 하나 이상을 사용하여 간섭을 수정하는 것이 좋습니다.

- 수신 안테나의 방향을 바꾸거나 재배치하십시오.
- 장비와 수신기 사이의 거리를 늘립니다.
- 장비를 다른 회로의 콘센트에 연결하십시오.
- 판매점이나 숙련 된 라디오 / TV 기술자에게 도움을 요청하십시오.

경고: 이 제품에는 심박 조율기 착용자에게 해가 될 수 있는 자석이 포함되어 있습니다.

경고: 이 장비는 무선 주파수 에너지를 생성하거나 사용할 수 있습니다. 사용 설명서에서 명시 적으로 승인되지 않은 경우 이 장비를 변경하거나 개조하면 유해한 간섭을 일으킬 수 있습니다. 무단으로 변경하거나 개조하면 사용자는 이 장비를 작동 할 권한을 잃을 수 있습니다.

FCC ID : 2ACFTRT1505NN

인증받은자의 상호 : (주)하젠
제조사 : (주)하젠
제조국 : China

사용 전원 : 5V=2A
충전 온도 : 23° ~ 140°F (-5° ~ 60°C)
사용 온도 : 14° ~ 140°F (-10° ~ 60°C)

App Store는 Apple Inc.의 서비스 표시 및 등록 상표입니다.
Google Play 로고는 Google Inc.의 서비스 표시 등록 상표입니다.
Bluetooth 단어 표시와 로고는 Bluetooth SIG, Inc.의 등록 상표입니다.

