


**WIRELESS SMARTPHONE
MULTIFUNCTION REMOTE CONTROL**

User Manual
Product Model : HSRC001



Button function list

Button	Function	
	iOS	Android
iOS ↔ Power Off ↔ Android	Refer to the middle position for power off, left side for IOS power on.	Refer to the middle position for power off, right side for Android power on.
Camera	This button is for camera/Video recording.	This button is for camera/Video recording.
Play/Pause	1. Music Play/Pause. 2. SIRI function activated when pressing longer than 2s.	Music Play/Pause.
VOL +/-	Volume +/Volume-.	1. Camera Mode: Zoom in and Zoom out . 2. Other Mode: Volume +/Volume-.
Music selection	1. Music selection up/next. 2. Small keypad will pop-up or close in Chinese words input status after long pressing 2 seconds.	1. Music selection up/next. 2. Small keypad will pop-up or close in Chinese words input status after long pressing 2 seconds (for Samsung) .

How to use

1. Switch the Mode Button according to your smart device operation system (iOS ↔ Android), and then the shutter is power on.
2. Press the Camera and Play/Pause button simultaneously, the shutter is in matching status, the green LED will flash quickly. Switch on Bluetooth in your device and search Bluetooth device, select "Remote helper" for matching and connecting.
3. The shutter will connect to the device which was matched last time automatically when power on. Clicking any button will wake it up and the shutter will connect to your device again.
4. Switch power button off when not in use to ensure that the battery can be used for a long time.
5. Open the circular cover on the backside and replace a new CR2032 Button cell.

Compatible

Apple	iOS5.0 of iPhone 4S, 5, 5S/5C, iPad 3rd/4rd generation, iPad Air, iPad Mini 1/2 and iPad Touch 5th generation or later
Samsung	Galaxy S3/S4/Note II/Note III/T399 or later
Other device	Other Android 4.0 device or Later (Phone and pad)

Remark:

If your device uses VOL+ button to take photos for Android phone, just refer to left side for iOS power on.
APP needed if your Android device isn't compatible with this shutter.

APP downloaded:
<http://apk.hiapk.com/html/2014/01/2302254.html>



8x6CM

FCC ID: 2ACGQHSRC001

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.