

## PACKAGE CONTENTS

- Rugged speaker system
- AC adapter
- User's Guide

## CHARGING THE SPEAKER

Charge speaker with the included AC adapter. Plug the adapter into any wall socket or power strips. The adapter's dc end can plug into the "DC IN" port on the side of the speaker to charge the speaker. When charging, a red led will illuminate, it will turn off when the speaker is fully charged. This adapter is made specifically for this speaker, please do not use for other accessories or products.

## PLAYING MUSIC VIA BLUETOOTH MODE

1. Make sure the speaker is fully charged.
2. Turn the speaker on by the switch on the side of the speaker. A blue led will illuminate and begin to flash.
3. Follow the instructions for pairing that came with your Bluetooth enabled device. You may have to go into your settings and turn Bluetooth ON. Make sure your device is discoverable or in search mode.
4. Your device should discover "PBT6005" or "SBT605". Select this profile. Once connected, the blue led will blink slowly.
5. You are now connected and play your audio content wirelessly
6. You may chose to play the next song, replay the same song, pause or play music by the buttons located on the side of the speaker

## PLAYING MUSIC VIA AUX IN MODE

1. Make sure the speaker is charged
2. Turn the speaker on by switching the power button at the side to on. A blue LED will appear when on.
3. Connect one end of a 3.5 mm audio cable to the "AUX IN" port on the side of the unit. Connect the other end to the 3.5mm headphone jack of your audio device.

Note: Connecting the audio cable will override Bluetooth mode. speaker will automatically switch to auxillary when the audio cable is connected.

4. Make sure the volume of your audio device and the volume of speaker are both set to medium/low.

## VOLUME CONTROL & CONTROL BUTTON

Adjust the volume by the switches on the side of the speaker

The side panel also includes the buttons for play, pause, next song & last song. Press the button according to activate the functions.

## **CHARGING PRODUCT**

To charge any product, please use the USB port on the side of the speaker . The rugged speaker will charge any smart phone or pad product that uses up to 1 a output. Speaker contains 4000 mah rechargeable Li-Ion batterie. In average speaker will fully charge any smart phone product 1 time.

Charging a product while the music is playing will drain the battery in a much faster rate.

## **TROUBLE SHOOTING**

**Problem: Bluetooth not connecting.**

**Solution: Please consult the User Guide of your Bluetooth enabled audio device for instructions. Make sure that both of your audio device and power rock speaker are discoverable and charged. Try rebooting the speaker by turning it off then back on. Make sure someone else is not already connected to the speaker.**

**Federal Communications Commission (FCC) Interference Statement**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

**RF exposure warning**

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

The equipment must not be co-located or operating in conjunction with any other antenna or transmitter.