

Charging

Full charge your tablet for 6 hours before the first use.



Use the included 5V wall charger.



The battery indicator will show that your device is charging.

Screen Basics



Connecting to Wi-Fi®



Enter the settings app located in the apps menu. Tap the switch for Wi-Fi.



Choose your network and enter your password using the on-screen keyboard.


Google™ Account

The first time you use the Google Play™ Store app you will be prompted to create a Google account. If you already have a Gmail™ account, you have the option to use your Gmail address and password to sign in. If you do not have a Gmail account, follow the prompts to create an account.

At the end of the setup you will be asked to setup a credit card with Google Wallet™. You can skip this step and enter your information when you want to make a purchase.

Adding other accounts

If your primary email account is not gmail you can add your email account to receive. You can also add accounts from other social networking and messaging apps you have installed. Go to Settings and tap the + under Accounts.




Connecting to a Computer




Connect to your computer by USB.




PC



The device driver will install.




Choose open folder to view files or select the removable disk.




You will now be able to drag and drop files from your computer on to your tablet just as you would with a USB flash drive.

Computer




Tap Turn on USB Storage.



Tap OK to allow USB Storage.

4 You will now be able to drag and drop files from your computer onto your tablet just as you would a USB flash drive.

Reset/Restore



Factory Restore
Select Backup & reset in the settings app to restore factory settings. This will erase all data on the tablet.

-Operational steps for Learnit Tablet.
Make sure that LEARNIT is fully charged before using.
(Green light indicates full charge, unplug not to overcharge and reduce battery life)
Try not to use LEARNIT while charging to avoid damage to charging pin or charging port.
Turn on device from the switch located on top right side where unit is plugged in to charge.
After turning on the device allow a few minutes for the device to download preloaded applications.(If not all applications may not appear on screen)
Touch and slide lock on opening screen to the right to view home screen
Touch the circled dots on right hand side of home screen to see applications.
Scroll from right to left to see more applications.
Touch the arrow on left bottom screen to go back to front screen.
TO ACCES KIDS PLACE -CARIBBEAN eBook
Unlike other tablets, the LEARNIT does not require an Internet connection, so applications are always available and ready for students to use!
Touch” Kids Place” on home screen to go to “kids place – Caribbean eBook” screen (this locks the device from internet use).
Touch anyone of the Category listings to get to “Kids Place Caribbean eBook” home page
Touch the three dots to the far right and select “Show category list”, and then choose application.
Touch Category of interest.
Touch application you wish to use
Listen for instructions (wait until voice giving instructions stop)
Follow instructions completely to get maximum results from all applications
Scroll from left to right to see full version applications that are available in Kids Place
SIMPLY: TOUCH – LISTEN- DO- LEARN
To exit kids place type in password 7603
Connect Learnit to the internet
To connect device to the internet click “settings”
Turn on “Wi-Fi” on the other side of the same screen
find the internet connection available and click on it
Type in “pass word” and click connect.
When connected scroll down from Wi-Fi to “+ Add account”
“Add account” box will appear.
Click on “Google” and another box will appear
click “existing” and type in Gmail account and password.
Follow steps until full set up is completed
“Browse” the internet.

check with retailer for all customer support needs

FCC Information and Copyright

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates,

uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference

to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does

cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is

encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

15.19 Labelling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC RF warning statement: the device has been evaluated to meet general RF exposure requirement , The device can be used in portable exposure condition without restriction.