

Cubitt

User Manual




Open Earbuds


Gen2

Bluetooth V5.3

Support iOS & Android System




Operation Guide



- | | |
|------------------------------------|------------------------------------|
| L/R One Touch: | Play/Pause/Answer/Hang Up |
| L/R Long Touch 2 Seconds: | Power On/Rejection/Voice Assistant |
| L/R Touch 4 times: | Game Mode |
| L/R Long Touch 5 Seconds: | Power Off |
| L Double Touch: Volume Down | R Double Touch: Volume Up |
| L Triple Touch: Prev Song | R Triple Touch: Next Song |

L/R Game mode: When Earbuds are connected with the phone, touch the L or R earbud for 4 times. When hear a "game mode" voice prompt, you have entered the game mode. Touch the L or R earbud 4 times again, hear "game mode off" to exit game mode.

Note: Turn on game mode, the RF signal will deteriorate!




Connection Forcibly Cleared:


When take out the earbuds, it will directly connect with the old device. Just tap the L or R earbud 5 times to hear a "du" Sound. The old device connection is forcibly cleared. After the clearing, the earbuds will enter to the waiting state, other devices can find it and connect it too.

Easy Pairing

- Put the Left and Right earbud into the charging box to wake it up; When the LED indicators indicating White and charged normally, the earbuds are activated!
- Take the Left and Right earbud out of the charging box, The earbuds's LED indicator lights up white and will flash quickly. The earbuds pair together automatically and the LED indicator will flash slowly.
- Open the Bluetooth setting on your device and connect to "Cubitt Reebok Open Earbuds" The LED indicators turn off to confirm the pairing was successful.




Note: If Needed, Please Off the Earbuds to Repeat the above Steps to Re-Pairing Again.



- Auto Power On/Off: Two earbuds will power on automatically once you take it out from the charging box; And will auto power off when you put it back to the charging box.

Note: The earbuds will power off automatically after 5 minutes if they have not been paired with a device via Bluetooth.

Charging Diagram



Power Level	Light Indicate
0-25%	Flash 1 times
25-50%	Flash 2 times in a row
50-75%	Flash 3 times in a row
75-100%	Flash 4 times in a row


Earbuds

When Charging: Earbuds bright white lights, Charging box White light out.
Full Charge: Charging box light turns off
Charging time: 1.5 hour
Low Battery: White light flash slowly and warning

Charger Box

Charging Time: 2.5hours


Product Detail



Packing Detail:

Earbuds
Charging Box
Charging Cable
User Manual
Gift Box & EVA Tray

Wearing Diagram




Specification

Pairing Name:	Cubitt Reebok Open Earbuds
Bluetooth Version:	V5.3
Charging Voltage:	5V
Li-Battery:	3.7V/60mAh
Playing Time:	6.5H(Base on 50% Volume)
Charging Time:	1.5 Hour for earbuds
Profile Support:	HSP/HFP/A2DP/AVRCP
Sensitivity:	97±3dB


Charging Box Input Power:	DC=5V 1000mA
Charging Box Output Power:	DC=5V 100mA
Charging Box Li-Battery:	3.7V/500mAh
Charging Hole:	USB Type C
Charging Box Charger Time:	2.5 Times

FAQ:

- Cellphone can not search the Bluetooth earbuds
Delete all Bluetooth pairing names stored on the phone, and search again.
- The earbuds sound is jammed or disconnected when talking or playing music
1) Cellphone & Bluetooth earbuds have large areas of shielding, such as walls.
2) Low power of TWS Earbuds.
3) The distance between cellphone and TWS earbuds is more than 10 meters.
- When L & R earbud can not connected together
Touch the L and R Earbud 6 times at the same time to pair directly together



Multi-Device Operation Guide



Cubitt


Manual del usuario




Open Earbuds
Gen2

Bluetooth V5.3


Compatible con sistemas IOS y Android



Guía de funcionamiento



L R Un toque:	Reproducir/Pausa/Contestar/Colgar
L R Toque largo 2 segundos:	Encendido/Rechazo/Asistente de voz
L R Toque 4 veces:	Modo de juego
L R Toque largo 5 segundos:	Apagado
L Doble toque: Bajar volumen	R Doble toque: Subir volumen
L Triple Touch: Canción anterior	R Triple Touch: Siguiente canción
L R Modo de juego: Cuando los auriculares estén conectados al teléfono, toca el auricular L o R durante 4 veces. Cuando oigas el mensaje de voz "modo juego", estarás entrando en el modo juego. Toque el auricular L o R 4 veces de nuevo, escuche "modo juego off" para salir del modo de juego. Nota: Al activar el modo de juego, la señal de radiofrecuencia se deteriorará.	




Eliminar conexión a la fuerza:


Al sacar los auriculares, se conectarán directamente con el dispositivo antiguo. Basta con tocar el auricular izquierdo o derecho 5 veces para escuchar un sonido "du". La conexión se borrará a la fuerza. Después del borrado, los auriculares pasarán al estado de espera, otros dispositivos podrán encontrarlo y conectarse a el también.

Fácil emparejamiento

- Coloque el auricular izquierdo y derecho en la caja de carga para activarlo; Cuando los indicadores LED indiquen blanco y carga normal, los auriculares estarán activados.
- Saque los auriculares izquierdo y derecho de la caja de carga. indicador LED de los auriculares se ilumina en blanco y parpadea rápidamente. Los auriculares se emparejan automáticamente y el indicador LED parpadeará lentamente.
- Abra la configuración Bluetooth de su dispositivo y conéctese a "Cubitt Reebok Open Earbuds" Los indicadores LED se apagan para confirmar que el emparejamiento se ha realizado correctamente.




Nota: Si es necesario, apague los auriculares y repita los pasos anteriores para volver a emparejarlos.



- Encendido y apagado automático: Los dos auriculares se encenderán automáticamente cuando los saques de la caja de carga; y se apagarán automáticamente cuando los introduzas en la caja de carga.

Nota: Los auriculares se apagarán automáticamente transcurridos 5 minutos si no se han emparejados con un dispositivo a través de Bluetooth.

Diagrama de carga



Nivel de potencia	Indicador luminoso
0-25%	Flash 1 vez
25-50%	Flash 2 veces seguidas
50-75%	Flash 3 veces seguidas
75-100%	Flash 4 veces seguidas


Auriculares

Durante la carga: Auriculares con luz blanca brillante, caja de carga luz blanca apagada.
Carga completa: La luz de la caja de carga se apaga
Tiempo de carga: 1,5 horas
Batería baja: La luz blanca parpadea lentamente

Caja del cargador

Tiempo de carga: 2,5 horas


Detalle del producto



Detalle del embalaje:

Auriculares
Caja de carga
Cable de carga
Manual del usuario
Caja de regalo y bandeja de EVA

Diagrama de desgaste




Especificación

Nombre de emparejamiento:	Cubitt Reebok Open Earbuds
Versión de Bluetooth:	V5.3
Voltaje de carga:	5V
Li-Batería:	3.7V/60mAh
Tiempo de reproducción:	6.5H(Base en 50% Volumen)
Tiempo de carga:	1,5 horas para los auriculares
Soporte de perfiles:	HSP/HFP/A2DP/AVRCP
Sensibilidad:	97±3dB


Potencia de entrada de la caja de carga:	DC=5V 1000mA
Caja de carga Potencia de salida:	DC=5V 100mA
Batería de litio de la caja de carga:	3.7V/500mAh
Agujero de carga:	Tipo C
Caja de carga Tiempo de carga:	2.5 Horas

PREGUNTAS FRECUENTES:

- El móvil no puede buscar los auriculares Bluetooth
Borra todos los nombres de emparejamiento Bluetooth almacenados en el teléfono y vuelve a buscar.
- El sonido de los auriculares se atasca o se desconecta al hablar o reproducir música
1) Los auriculares de teléfonos móviles y Bluetooth tienen grandes zonas de blindaje, como las paredes.
2) Baja potencia de los auriculares TWS.
3) La distancia entre el teléfono móvil y los auriculares TWS es superior a 10 metros.
- Cuando los auriculares izquierdo y derecho no pueden conectarse juntos
Toca los auriculares izquierdo y derecho 6 veces al mismo tiempo para emparejarlos directamente.



Multi-Device Operation Guide



FCC Caution.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

* RF warning for Portable device:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.